



NLS-EM2037 Series

Embedded 2D Barcode Scan Engine

User Guide



Disclaimer

© 2013 Fujian Newland Auto-ID Tech. Co., Ltd. All rights reserved.

Please read through the manual carefully before using the product and operate it according to the manual. It is advised that you should keep this manual for future reference.

Do not disassemble the device or remove the seal label from the device. Otherwise, Fujian Newland Auto-ID Tech. Co., Ltd. does not assume responsibility for the warranty or replacement.

All pictures in this manual are for reference only and actual product may differ. Regarding to the product modification and update, Fujian Newland Auto-ID Tech. Co., Ltd. reserves the right to make changes to any software or product to improve reliability, function, or design at any time without notice. Besides, the information contained herein is subject to change without prior notice.

The products depicted in this manual may include software copyrighted by Fujian Newland Auto-ID Tech. Co., Ltd or a third party. The user, corporation or individual, shall not duplicate, in whole or in part, distribute, modify, decompile, disassemble, decode, reverse engineer, rent, transfer or sublicense such software without prior written consent from the copyright holders.

This manual is copyrighted. No part of this publication may be reproduced or used in any form without written permission from Newland.

Fujian Newland Auto-ID Tech. Co., Ltd. reserves the right to make final interpretation of the statement above.

Fujian Newland Auto-ID Tech. Co., Ltd.

3F, Building A, No.1, Rujiang Xi Rd., Mawei, Fuzhou, Fujian, P.R. China. 350015.

<http://www.nlscan.com>

Revision History

Version	Description	Date
V1.0.0	Initial release.	January 4, 2013
V1.0.1	Corrected inappropriate expressions and misspellings	January 17, 2013
V1.0.2	Replaced hard-to-read barcodes	April 9, 2013

Table of Contents

Revision History	- 3 -
Chapter 1 Getting Started	1
Introduction	1
About This Guide	1
Document Set	1
Connecting EVK to PC.....	1
Barcode Scanning.....	2
Programming Barcodes	2
Factory Defaults	3
Custom Defaults.....	3
Product Information.....	4
Chapter 2 Communication Interfaces	5
Introduction	5
Serial Communication Interface	5
Baud Rate	6
Parity Check.....	7
Data Bit	7
Stop Bit.....	8
Hardware Flow Control	8
USB Interface.....	9
USB-DataPipe.....	9
USB HID-KBW	9
USB Country Keyboard Types	10
Country Code Table (Appendix 5)	10
Beep on Unknown Character	11
Emulate ALT+Keypad	11
Function Key Mapping	12
Inter-Keystroke Delay	13
Caps Lock.....	13
Convert Case.....	14
Emulate Numeric Keypad	15
USB COM Port Emulation.....	16
HID-POS.....	16

Acquire Scanned Data	17
VID/PID	17
IBM SurePOS(Tabletop).....	18
IBM SurePOS (Handheld).....	18
Chapter 3 Scan Mode	19
Trigger Mode	19
Auto Mode	19
Decode Session Timeout	20
Timeout Between Decodes (Same Barcode)	21
Continuous Mode	22
Timeout Between Decodes (Same Barcode)	23
Chapter 4 Scanning Preferences	24
Introduction	24
Regular Mode/Mobile Phone Mode	24
Decode Area	24
Whole Area Decoding	24
Central Area Decoding	25
Specify Central Area	26
Chapter 5 Illumination & Aiming	27
Illumination	27
Aiming	28
Chapter 6 Beep & LED Indications.....	29
Introduction	29
Startup Beep	29
Beep after Good Decode.....	29
Beep Type	30
Beep Volume.....	30
Additional Settings for Type 1	31
Beep Duration	31
Beep Frequency.....	32
LED Notification	33
LED Notification for Good Decode	33
LED Notification Duration for Good Decode.....	33
Chapter 7 Data Formatting.....	34
Introduction	34

General Settings	35
Enable/Disable All Prefix/Suffix	35
Prefix Sequences	35
AIM ID Prefix	36
Code ID Prefix	36
Restore All Default Code IDs	37
Modify Code ID	37
Custom Prefix	41
Enable/Disable Custom Prefix	41
Set Custom Prefix	41
Custom Suffix	42
Enable/Disable Custom Suffix	42
Set Custom Suffix	42
Data Packing	43
Normal Pack	43
Terminating Character Suffix	44
Enable/Disable Terminating Character Suffix	44
Set Terminating Character Suffix	45

Chapter 8 Symbolologies..... 46

General Settings	46
Enable/Disable All Symbolologies	46
Enable/Disable 1D Symbolologies	46
Enable/Disable 2D Symbolologies	46
1D Symbolologies	47
Code 128	47
Restore Factory Defaults	47
Enable/Disable Code 128	47
Set Length Range for Code 128	47
GS1-128 (UCC/EAN-128)	48
Restore Factory Defaults	48
Enable/Disable GS1-128	48
EAN-8	49
Restore Factory Defaults	49
Enable/Disable EAN-8	49
Transmit Check Digit	49
Add-On Code	50
EAN-8 Extension	51

EAN-13	52
Restore Factory Defaults	52
Enable/Disable EAN-13	52
Transmit Check Digit.....	52
Add-On Code	53
ISBN.....	54
Restore Factory Defaults	54
Enable/Disable ISBN	54
Set ISBN Format.....	54
UPC-E.....	55
Restore Factory Defaults	55
Enable/Disable UPC-E.....	55
Transmit Check Digit.....	55
Add-On Code	56
Transmit System Character “0”	56
UPC-E Extension	57
UPC-A.....	58
Restore Factory Defaults	58
Enable/Disable UPC-A.....	58
Transmit Check Digit.....	58
Add-On Code	59
Transmit Preamble Character “0”	59
Interleaved 2 of 5	60
Restore Factory Defaults	60
Enable/Disable Interleaved 2 of 5	60
Set Length Range for Interleaved 2 of 5	60
Parity Check	61
Set Discrete Lengths for Interleaved 2 of 5.....	62
ITF-14	63
ITF-6	64
Matrix 2 of 5	65
Restore Factory Defaults	65
Enable/Disable Matrix 2 of 5	65
Set Length Range for Matrix 2 of 5	65
Parity Check	66
Code 39	67
Restore Factory Defaults	67
Enable/Disable Code 39	67

Set Length Range for Code 39	67
Parity Check	68
Transmit Start/Stop Character	69
Enable/Disable Code 39 Full ASCII	69
Codabar	70
Restore Factory Defaults	70
Enable/Disable Codabar	70
Set Length Range for Codabar	70
Parity Check	71
Transmit Start/Stop Character	72
Start/Stop Character Format	72
Code 93	73
Restore Factory Defaults	73
Enable/Disable Code 93	73
Set Length Range for Code 93	73
Parity Check	74
GS1-Databar (RSS)	75
Restore Factory Defaults	75
Enable/Disable GS1 Databar	75
Transmit Application Identifier "01"	75
GS1 Composite Code	76
Restore Factory Defaults	76
Enable/Disable GS1 Composite Code	76
EAN/UPC Composite	76
Code 11	77
Restore Factory Defaults	77
Enable/Disable Code 11	77
Set Length Range for Code 11	77
Transmit Check Digit	78
Parity Check	78
Industrial 2 of 5	79
Restore Factory Defaults	79
Enable/Disable Industrial 2 of 5	79
Set Length Range for Industrial 2 of 5	79
Parity Check	80
Standard 25	81
Restore Factory Defaults	81
Enable/Disable Standard 25	81

Set Length Range for Standard 25.....	81
Parity Check	82
Plessey	83
Restore Factory Defaults	83
Enable/Disable Plessey	83
Set Length Range for Plessey	83
Parity Check	84
MSI-Plessey	85
Restore Factory Defaults	85
Enable/Disable MSI-Plessey.....	85
Set Length Range for MSI-Plessey.....	85
Transmit Check Digit.....	86
Parity Check	86
2D Symbolologies	87
PDF 417.....	87
Restore Factory Defaults	87
Enable/Disable PDF 417.....	87
Set Length Range for PDF 417	87
PDF 417 Inverse	88
PDF417 Twin Code.....	89
QR Code	90
Restore Factory Defaults	90
Enable/Disable QR Code.....	90
Set Length Range for QR Code	90
QR Twin Code.....	91
Aztec Code	92
Restore Factory Defaults	92
Enable/Disable Aztec Code	92
Set Length Range for Aztec Code.....	92
Read Multi-barcodes of an Image	93
Set the Number of Barcodes.....	94
Data Matrix.....	95
Restore Factory Defaults	95
Enable/Disable Data Matrix	95
Set Length Range for Data Matrix.....	95
Rectangular Barcode	96
Data Matrix Inverse.....	96
Data Matrix Twin Code.....	97

Maxicode.....	98
Restore Factory Defaults	98
Enable/Disable Maxicode	98
Set Length Range for Maxicode	98
Chinese Sensible Code.....	99
Restore Factory Defaults	99
Enable/Disable Chinese Sensible Code	99
Set Length Range for Chinese Sensible Code	99
Chinese Sensible Code Inverse.....	100
Chapter 9 Troubleshooting.....	101
FAQ.....	101
Appendix	103
Appendix 1: Factory Defaults Table.....	103
Appendix 2: AIM ID Table	109
Appendix 3: Code ID Table.....	110
Appendix 4: ASCII Table.....	111
Appendix 5: Country Code Table.....	115
Appendix 6: ASCII Function Key Mapping Table	116
Appendix 7: Symbology ID Number	118
Appendix 8: Parameter Programming Examples	119
a. Program the Decode Session Timeout.....	119
b. Program the Timeout between Decodes (Same Barcode)	119
c. Program the Central Area.....	119
d. Program the Duration of Good Decode Beep (Type 1)	120
e. Program the Frequency of Good Decode Beep (Type 1)	120
f. Program the LED Notification Duration for Good Decode	120
g. Program the Custom Prefix/Suffix	121
h. Program the Terminating Character Suffix	121
i. Program the Code ID	121
j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology	122
k. Program the Discrete Lengths for Interleaved 2 of 5	123
Appendix 9: F-Key Barcodes.....	124
Appendix 10: Digit Barcodes	126
Appendix 11: Save/Cancel Barcodes	128



Chapter 1 Getting Started

Introduction

The EM2037 series embedded 2D barcode scan engines are armed with CMOS image capturer and the Newland patented **UIMG**, a computerized image recognition system, featuring fast scanning and accurate decoding on barcodes on virtually any medium - paper, magnetic card, mobile phones and LCD displays. The EM2037s can be easily integrated into OEM equipments or systems, such as hand-held, portable, or stationary barcode scanners.

Moreover, the EM2037s open image acquisition interface, data interface and I/O interface to OEM developers to allow their special integration needs. EM2037 Software Development Kit is provided for easy and quick development of OEM applications.

About This Guide

This guide provides programming instructions for the EM2037. Users can configure the EM2037 by scanning the programming barcodes included in this manual.

The EM2037 has been properly configured for most applications and can be put into use without further configuration. Users may check the Factory Defaults Table in Appendix for reference. Throughout the manual, programming barcodes marked with asterisks (**) are factory default values.

Document Set

EM2037 related documents include:

NLS-EM2037 Series Embedded 2D Barcode Scan Engine Integration Manual:

Describes how to integrate the EM2037.

NLS-EM2037 Series Embedded 2D Barcode Scan Engine User Guide:

Describes how to use and program the EM2037.

Sample Barcodes:

Provides sample barcodes for testing the EM2037.

Connecting EVK to PC

The supplied EM2037 EVK tool can assist users in application development for the EM2037. You can connect EM2037 EVK to PC via a USB connection or an RS-232 connection. In case of USB connection, a driver is required and EVK can communicate with EM2037 and receive decoded data through virtual serial port.





Enter Setup

Barcode Scanning

Powered by area-imaging technology and Newland patented **UIMG** technology, the EM2037 features fast scanning and decoding accuracy. Barcodes rotated at any angle can still be read with ease. When scanning a barcode, simply center the aiming beam or pattern projected by the EM2037 over the barcode.

Programming Barcodes

Scanning the **Enter Setup** barcode can enable the engine to enter the setup mode. Then you can scan a number of programming barcodes to configure your engine. To exit the setup mode, scan the **Exit Setup** barcode.

If the engine has exit the setup mode, only some special programming barcodes, such as the **Enter Setup** barcode and **Restore All Factory Defaults** barcode, can be read.



Enter Setup



**** Exit Setup**

Programming barcode data can be transmitted to the Host. Scan the appropriate barcode below to enable or disable the transmission of programming barcode data (programming commands) to the Host.



Transmit Programming Barcode Data



**** Do Not Transmit Programming Barcode Data**



**** Exit Setup**



Factory Defaults

Scanning the following barcode can restore the engine to the factory defaults. See **Appendix 1: Factory Defaults Table** for more information.

Restoring the engine to factory defaults will not remove custom defaults stored on the engine.



Restore All Factory Defaults

Note: Use this feature with discretion.

Custom Defaults

Scanning the **Restore All Custom Defaults** barcode can reset all parameters to the custom defaults. Scanning the **Save as Custom Defaults** can set the current settings as custom defaults.

Custom defaults are stored in the non-volatile memory.



Save as Custom Defaults



Restore All Custom Defaults





Product Information

Obtain Product Information: Transmit the product information to the Host straight away via the communication interface.



Obtain Product Information

Send Product Information at Startup: Transmit the product information to the Host when the engine is powered on. This feature only applies to engines using a serial communication interface.



Send Product Information at Startup



Do Not Send Product Information at Startup



**** Exit Setup**



Chapter 2 Communication Interfaces

Introduction

The EM2037 engine provides a TTL-232 interface and a USB interface to communicate with the host device. The host device can receive scanned data and send commands to control the engine or to access/alter the configuration information of the engine via the TTL-232 or USB interface.

Serial Communication Interface

Serial communication interface is usually used when connecting the engine to a host device (like PC, POS). However, to ensure smooth communication and accuracy of data, you need to set communication parameters (including baud rate, parity check, data bit and stop bit) to match the host device.

The serial communication interface provided by the engine is based on TTL signals. TTL-232 can be used for most application architectures. For those requiring RS-232, an external conversion circuit is needed. The conversion circuit is available only to some models.



Serial Communication

Default serial communication parameters are listed below. Make sure all parameters match the host requirements.

Parameter	Factory Default
Serial Communication	Standard TTL-232
Baud Rate	9600
Parity Check	None
Data Bits	8
Stop Bits	1
Hardware Auto Flow Control	None





0006010

Enter Setup


Baud Rate

Baud rate is the number of bits of data transmitted per second. Set the baud rate to match the Host requirements.



0100030

**** Baud Rate 9600**



0100050

Baud Rate 19200



0100000

Baud Rate 1200



0100060

Baud Rate 38400



0100010

Baud Rate 2400



0100070

Baud Rate 57600



0100020

Baud Rate 4800




0100080

Baud Rate 115200



0100040

Baud Rate 14400




0006000

**** Exit Setup**



Parity Check



0101000

**** None**



0101010

Even Parity



0101020

Odd Parity

Data Bit



0103030

**** 8 Data Bits**



0103010

6 Data Bits



0103020

7 Data Bits



0103000

5 Data Bits



0006000


****Exit Setup**



0006010

Enter Setup

Stop Bit



0102000

**** 1 Stop Bit**



0102010

2 Stop Bits

Hardware Flow Control

If this feature is enabled, the engine determines whether to transmit data based on CTS signal level. When CTS signal is at a low level which means the serial port's cache memory of receiving device (such as PC) is full, the engine will not send data through RS-232 port until CTS signal is set to high level by receiving device. When the engine is not ready for receiving, it will set RTS signal to low level. When sending device (such as PC) detects it, it will not send data to the engine any more to prevent data loss.

If this feature is disabled, reception/transmission of serial data will not be influenced by RTS/CTS signal.



0104010

Enable Hardware Flow Control



0104000

**** Disable Hardware Flow Control**

Note: Before enabling this feature, make sure that RTS/CTS signal line is contained in RS-232 cable. Without the signal line, serial communication errors will occur.



0006000

**** Exit Setup**



USB Interface

USB-DataPipe

A driver is required when using this protocol to communicate with the engine. Its advantages include fast data transmission and easy to use.



USB-Datapipe

USB HID-KBW

When you connect the engine to the Host via a USB connection, you can enable the USB HID-KBW feature by scanning the barcode below. Then engine's transmission will be simulated as USB keyboard input. The Host receives keystrokes on the virtual keyboard. It works on a Plug and Play basis and no driver is required.



USB HID-KBW





USB Country Keyboard Types

Keyboard layouts and country codes vary from country to country. All supported keyboard types are listed in the Country Code Table. The default setting is US keyboard type.

To learn how to select a keyboard type, see the example below.



Select Country Code

Country Code Table (Appendix 5)

Country/Language	Code	Country/Language	Code
US	0	Netherlands(Dutch)	14
Belgium	1	Norway	15
Brazil	2	Poland	16
Canada(French)	3	Portugal	17
Czechoslovakia	4	Romania	18
Denmark	5	Russia	19
Finland(Swedish)	6	Slovakia	21
France	7	Spain	22
Germany/Austria	8	Sweden	23
Greece	9	Switzerland(German)	24
Hungary	10	Turkey F	25
Israel(Hebrew)	11	Turkey Q	26
Italy	12	UK	27
Latin-American	13	Japan	28





Example: Program the engine to emulate Norwegian keyboard (Norway)

1. Scan the **Enter Setup** barcode.
2. Scan the **Select Country Code** barcode.
3. Check the country code for Norway in the Country Code Table. (Norway: 15)
4. Scan the numeric barcodes “1” and “5”.
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode.

Beep on Unknown Character

Due to the differences in keyboard layouts, some characters contained in barcode data may be unavailable on the selected keyboard. As a result, the engine fails to transmit the unknown characters.

Scan the appropriate barcode below to enable or disable the emission of beep when an unknown character is detected.



Beep on Unknown Character



**** Do Not Beep on Unknown Character**

Emulate ALT+Keypad

When Emulate ALT+Keypad is turned on, any ASCII character (0x00 - 0xff) is sent over the numeric keypad no matter which keyboard type is selected. Since sending a character involves multiple keystroke emulations, this method appears less efficient.



Emulate ALT+Keypad ON



**** Emulate ALT+Keypad OFF**





0006010

Enter Setup

Function Key Mapping

When Function Key Mapping is enabled, function character (0x00 - 0x1F) are sent as ASCII sequences over the numeric keypad. For more information, see **Appendix 6: ASCII Function Key Mapping Table**.

A shortcut to send a function key (F1-F12) is to scan the corresponding barcode in **Appendix 9: F-Key Barcodes**.

Note: Emulate ALT+Keypad ON prevails over Enable Function Key Mapping.



1103140


Enable Function Key Mapping



1103130

**** Disable Function Key Mapping**

Example: Barcode data 0x16

 T	Enable Function Key Mapping	Ctrl +V
	Disable Function Key Mapping	F1



0006000

**** Exit Setup**

Inter-Keystroke Delay

This parameter specifies the delay between emulated keystrokes.



1103050

**** No Delay**



1103051

Short Delay (20ms)



1103052

Long Delay (40ms)

Caps Lock

The **Caps Lock ON** option can invert upper and lower case characters contained in barcode data. This inversion occurs regardless of the state of Caps Lock key on the Host's keyboard.



1103020

Caps Lock ON



1103010

**** Caps Lock OFF**

Note: Emulate ALT+Keypad ON/ Convert All to Upper Case/ Convert All to Lower Case prevails over Caps Lock ON.

Example: When the **Caps Lock ON** is selected, barcode data "AbC" is transmitted as "aBc".



0006010

Enter Setup

Convert Case

Scan the appropriate barcode below to convert all bar code data to your desired case.



1103040

**** No Case Conversion**



1103041

Convert All to Upper Case



1103042

Convert All to Lower Case

Example: When the **Convert All to Lower Case** feature is enabled, barcode data "AbC" is transmitted as "abc".



0006000

**** Exit Setup**



Emulate Numeric Keypad

When this feature is disabled, sending barcode data is emulated as keystroke(s) on main keyboard.

To enable this feature, scan the **Emulate Numeric Keypad** barcode. Sending a number (0-9) is emulated as keystroke(s) on numeric keypad, whereas sending other character like "+", "_", "*", "/" and "." is still emulated as keystrokes on main keyboard.

Numeric keypad is usually situated at the right of the main keyboard. The state of Num Lock on the simulated numeric keypad is determined by its equivalent on the Host. If Num Lock on the Host is turned off, the output of simulated numeric keypad is function key instead of number.



Emulate Numeric Keypad



**** Do Not Emulate Numeric Keypad**

Note: Make sure the Num Lock light of the Host is turned ON before enabling this feature.

Simulate ALT+Keypad ON prevails over **Emulate Numeric Keypad**.

Example: Supposing the **Emulate Numeric Keypad** feature is enabled:

if Num Lock on the Host is ON, "A4.5" is transmitted as "A4.5";

if Num Lock on the Host is OFF, "A4.5" is transmitted as follows:

1. "A" is sent as is because it is not included in numeric keypad;
2. "4" is sent as the function key "Cursor Move to Left";
3. "." is sent as the function key "Delete After the Cursor";
4. "5" is not sent as it does not correspond to any function key.





USB COM Port Emulation

If you connect the engine to the Host via a USB connection, the USB COM Port Emulation feature allows the Host to receive data in the way as a serial port does. However, you need to set communication parameters on the engine to match the Host requirements.



USB COM Port Emulation

HID-POS

The HID-POS interface is recommended for new application programs. It can send up to 56 characters in a single USB report and appears more efficient than keyboard emulation.

Features:

- ✧ HID based, no custom driver required.
- ✧ Way more efficient in communication than keyboard emulation and traditional RS-232 interface.

Note: HID-POS does not require a custom driver. However, a HID interface on Windows 98 does. All HID interfaces employ standard driver provided by the operating system. Use defaults when installing the driver.



HID-POS

Access the engine with your program:

1. Use CreateFile to access the engine as a HID device.
2. Use ReadFile to deliver the scanned data to the application program.
3. Use WriteFile to send data to the engine.

For detailed information about USB and HID interfaces, go to www.USB.org.





Acquire Scanned Data

After a barcode is decoded, the engine sends an input report as below:

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Report ID = 0x02							
1	Barcode Length							
2-57	Decoded Data (1-56)							
58-61	Reserved (1-4)							
62	Symbology ID Number (Appendix 7) or N/C: 0x00							
63	-	-	-	-	-	-	-	Decode Data Continued

VID/PID

USB uses VID (Vendor ID) and PID (Product ID) to identify and locate a device. The VID is assigned by USB Implementers Forum. Newland's vendor ID is 1EAB (Hex). A range of PIDs are used for each Newland product family. Every PID contains a base number and interface type (keyboard, COM port, etc.).

Product	Interface	PID (Hex)	PID (Dec)
EM2037	Base	0000	0
	HID-POS	0010	16






0006010

Enter Setup

IBM SurePOS(Tabletop)



1100090

IBM-SurePOS (Table-Top)

IBM SurePOS (Handheld)



1100100

IBM-SurePOS (Hand-Held)



0006000

**** Exit Setup**



Chapter 3 Scan Mode

Trigger Mode

If the Trigger Mode is enabled, receiving a valid trigger signal activates a decode session. The session continues until the barcode is decoded as long as the trigger signal remains valid; the session stops when the signal becomes invalid. For good decode, the engine transmits decoded data via communication port. To activate another session, the Host first terminates the trigger signal, waits 20ms or longer and then makes the signal valid.



Trigger Mode

Auto Mode

If the Auto Mode is enabled, the engine activates a decode session every time it detects a change in ambient illumination. The decode session continues until the barcode is decoded or the Decode Session Timeout occurs.

Receiving a trigger signal can also activate a decode session. The decode session continues until the trigger signal becomes invalid or the barcode is decoded or the Decode Session Timeout occurs. The trigger signal needs to be terminated before the engine is able to monitor ambient illumination again.



**** Auto Mode**





0006010

Enter Setup

Decode Session Timeout

This parameter sets the maximum time decode session continues during a scan attempt in the Auto Mode. It is programmable in 1ms increments from 500ms to 3600000ms. The default timeout is 3000ms. To learn how to program this parameter, see the “**a. Program the Decode Session Timeout**” section in Appendix.



0313000

Decode Session Timeout



0006000

** Exit Setup

Timeout Between Decodes (Same Barcode)

In order not to decode a barcode repeatedly, you can program this parameter to prevent the engine from rereading the same barcode in a given period of time.

This parameter sets the timeout between decodes for the same barcode in the Auto Mode. It is programmable in 1ms increments from 1ms to 3600000ms. The default timeout is 1500ms.

To learn how to program this parameter, see the “**b. Program the Timeout between Decodes (Same Barcode)**” section in Appendix.



Timeout Between Decodes (Same Barcode)

Disable Timeout Between Decodes: Allow the engine to re-read the same barcode.

Enable Timeout Between Decodes: Do not allow the engine to re-read the same barcode before the Timeout Between Decodes (Same Barcode) occurs.



**** Disable Timeout Between Decodes**



Enable Timeout Between Decodes



Continuous Mode

This mode enables the engine to scan/capture, decode and transmit over and over again.

If the Continuous Mode is enabled, the engine activates/suspends/resumes barcode reading through control over the trigger signal. When barcode reading is in progress, terminating the trigger signal after having kept it valid for 30ms or longer will suspend barcode reading; when barcode reading is suspended, performing the same control over the trigger signal will resume barcode reading.



Continuous Mode



**** Exit Setup**



Timeout Between Decodes (Same Barcode)

In order not to decode a barcode repeatedly, you can program this parameter to prevent the engine from rereading the same barcode in a given period of time.

This parameter sets the timeout between decodes for the same barcode in the Continuous Mode. It is programmable in 1ms increments from 1ms to 3600000ms. The default timeout is 1500ms.

To learn how to program this parameter, see the “**b. Program the Timeout between Decodes (Same Barcode)**” section in Appendix.



Timeout Between Decodes (Same Barcode)

Disable Timeout Between Decodes: Allow the engine to re-read the same barcode.

Enable Timeout Between Decodes: Do not allow the engine to re-read the same barcode before the Timeout Between Decodes (Same Barcode) occurs.



**** Disable Timeout Between Decodes**



Enable Timeout Between Decodes





Chapter 4 Scanning Preferences

Introduction

This chapter contains information as to how to adapt your engine to various applications with preference setting. For instance, to improve barcode reading performance off mobile phones and LCD displays; or to narrow the field of view of the engine to make sure it reads only those barcodes intended by the user.

Regular Mode/Mobile Phone Mode

The engine can capture barcodes printed on paper labels or displayed on the screen of a mobile phone. Select a mode as per actual need.

Regular Mode: Read barcodes printed on paper or plastic.

Mobile Phone Mode: Read barcodes off mobile phones or LCD displays.



**** Regular Mode**



Mobile Phone Mode

Decode Area

Whole Area Decoding

When this option is enabled, the engine attempts to decode barcode(s) within its field of view, from the center to the periphery, and transmits the barcode that has been first decoded.



**** Whole Area Decoding**



**** Exit Setup**



Central Area Decoding

The engine attempts to decode barcode(s) within a specified central area and transmits the barcode that has been first decoded. This option allows the engine to narrow its field of view to make sure it reads only those barcodes intended by the user. For instance, if multiple barcodes are placed closely together, central area decoding in conjunction with appropriate pre-defined central area will insure that only the desired barcode is read.




Central Area Decoding





Specify Central Area

The default central area is a (Width*20%) by (Height*20%) area in the center of the engine's field of view, as shown in the figure below. You can define the central area by scanning the **Specify Central Area** barcode and numeric barcode(s) corresponding to a desired percentage (1-100). If Central Area Decoding is enabled by scanning the **Central Area Decoding** barcode, the engine only reads barcodes that intersect the predefined central area.



To learn how to program this parameter, see the “c. Program the Central Area” section in Appendix.



Specify Central Area





Chapter 5 Illumination & Aiming

Illumination

A couple of illumination options are provided to improve the lighting conditions during every image capture:

Normal: Illumination LEDs are turned on during image capture.

Always ON: Illumination LEDs keep ON after the engine is powered on.

OFF: Illumination LEDs are OFF all the time.



**** Normal**



Always ON



OFF





Aiming

When scanning/capturing image, the engine projects an aiming pattern which allows positioning the target barcode within its field of view and thus makes decoding easier.

Normal: The engine projects an aiming pattern only during barcode scanning/capture.

Always ON: Aiming pattern is constantly ON after the engine is powered on.

OFF: Aiming pattern is OFF all the time.





Chapter 6 Beep & LED Indications

Introduction

Besides communication output, the engine can also generate a PWM signal and a pulse signal. Those outputs in conjunction with external circuits are able to drive the beeper/LED indicator.

This chapter describes how to program the beep/LED notification feature.

Startup Beep

If startup beep is enabled, the engine will beep after being turned on.



**** Enable Startup Beep**



Disable Startup Beep

Beep after Good Decode

The engine can be configured to beep after good decode. Beep type (frequency) and volume (duty circle of PWM) are also user programmable.



**** Beep after Good Decode**



Do Not Beep after Good Decode





0006010

Enter Setup

Beep Type



0203020

** Type 1



0203021

Type 2



0203022

Type 3

Beep Volume



0203030

** Loud



0203032

Low



0203031

Medium



0006000

** Exit Setup

Additional Settings for Type 1

Beep duration and frequency settings are designed only for Type 1 (which is a single tone) to serve specific applications.

Beep Duration



To learn how to program the parameter, see the “**d. Program the Duration of Good Decode Beep (Type 1)**” section in Appendix.





0006010

Enter Setup

Beep Frequency



0203060

800Hz



0203061

1600Hz



0203062

**** 2730Hz**



0203063

4200Hz

You may select the frequency same as the center frequency of your buzzer. To learn how to program this parameter, see the “e. Program the Frequency of Good Decode Beep (Type 1)” section in Appendix.



0203064

Custom (20~20000 Hz)



0006000

**** Exit Setup**

LED Notification

LED Notification for Good Decode

Note: This feature is applicable to all scan modes.



Good Decode LED Notification OFF



**** Good Decode LED Notification ON**

LED Notification Duration for Good Decode



**** Short (20ms)**



Medium (120ms)



Long (220ms)



Prolonged (320ms)

To learn how to program this parameter, see the “f. Program the LED Notification Duration for Good Decode” section in Appendix.



Custom (1 - 10000ms)



0006010
Enter Setup

Chapter 7 Data Formatting

Introduction

In many applications, barcode data needs to be edited and distinguished from one another.

Usually AIM ID and Code ID can be used as identifiers, but in some special cases customized prefix and terminating character suffix like Carriage Return or Line Feed can also be the alternatives.

Data editing refers to appending prefix/suffix, data packing, etc.

Data formatting may include:

- ✧ Append AIM ID/Code ID/custom prefix before the decoded data
- ✧ Append custom suffix after the decoded data
- ✧ Pack data
- ✧ Append terminating character to the end of the data



0006000
**** Exit Setup**



General Settings

Enable/Disable All Prefix/Suffix

Disable All Prefix/Suffix: Transmit barcode data with no prefix/suffix.

Enable All Prefix/Suffix: Allow user to append Code ID prefix, AIM ID prefix, custom prefix/suffix and terminating character to the barcode data before the transmission.



Enable All Prefix/Suffix



**** Disable All Prefix/Suffix**

Prefix Sequences



****Code ID+Custom Prefix+AIM ID**



Custom Prefix+Code ID+AIM ID





AIM ID Prefix

AIM (Automatic Identification Manufacturers) IDs and ISO/IEC 15424 standards define symbology identifiers and data carrier identifiers. (For the details, see the “**Appendix 2: AIM ID Table**” section). If AIM ID prefix is enabled, the engine will add the symbology identifier before the scanned data after decoding.



Enable AIM ID Prefix



**** Disable AIM ID Prefix**

Code ID Prefix

Code ID can also be used to identify barcode type. Unlike AIM ID, Code ID is user programmable. Code ID can only consist of one or two English letters.



Enable Code ID Prefix



**** Disable Code ID Prefix**





Restore All Default Code IDs

For the information of default Code IDs, see the “**Appendix 3: Code ID Table**” section.



Restore All Default Code IDs

Modify Code ID

Code ID of each symbology can be programmed separately. See the following example to learn how to program a Code ID.

Example: Set the Code ID of PDF417 to “p”

1. Check the hex value of “p” in the **Appendix 4: ASCII Table**. (“p”: 70)
2. Scan the **Enter Setup** barcode.
3. Scan the **Modify PDF417 Code ID** barcode.
4. Scan the numeric barcodes “7” and “0”.
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode.




****Exit Setup**



0006010

Enter Setup



0005000

Modify PDF 417 Code ID



0005030

Modify Data Matrix Code ID



0005010

Modify QR Code ID



0005040

Modify Maxicode Code ID



0005020

Modify Aztec Code ID



0005070

Modify Chinese Sensible Code ID




0004040

Modify EAN-8 Code ID



0004050

Modify EAN-13 Code ID



0004060

Modify UPC-E Code ID



0004070

Modify UPC-A Code ID



0006000

**** Exit Setup**



Modify Code 128 Code ID



Modify UCC/EAN-128 Code ID



Modify Code 39 Code ID



Modify Code 93 Code ID



Modify Interleaved 2 of 5 Code ID



Modify ITF-14 Code ID



Modify ITF-6 Code ID



Modify Codabar Code ID



Modify Industrial 25 Code ID



Modify Standard 25 Code ID





0006010

Enter Setup



0004280

Modify Code 11 Code ID



0004270

Modify Plessey Code ID



0004290

Modify MSI-Plessey Code ID



0004310

Modify GS1 Databar Code ID



0004300

Modify Composite Code ID



0004240

Modify ISBN Code ID



0006000

**** Exit Setup**



Custom Prefix

Enable/Disable Custom Prefix

If custom prefix is enabled, you are allowed to append to the data a user-defined prefix that cannot exceed 10 characters.



Enable Custom Prefix



**** Disable Custom Prefix**

Set Custom Prefix

To set a custom prefix, scan the **Set Custom Prefix** barcode and then the numeric barcodes corresponding to the hexadecimal value of a desired prefix. To save the settings, scan the **Save** barcode.

Note: A custom prefix cannot exceed 10 characters.



Set Custom Prefix

Example: Set the custom prefix to "CODE"

1. Check the hex values of "CODE" in the ASCII Table. ("CODE": 43, 4F, 44, 45)
2. Scan the **Enter Setup** barcode.
3. Scan the **Set Custom Prefix** barcode.
4. Scan the numeric barcodes "4", "3", "4", "F", "4", "4", "4" and "5".
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode.





Enter Setup

Custom Suffix

Enable/Disable Custom Suffix

If custom suffix is enabled, you are allowed to append to the data a user-defined suffix that cannot exceed 10 characters.



Enable Custom Suffix



** Disable Custom Suffix

Set Custom Suffix

To set a custom suffix, scan the **Set Custom Suffix** barcode and then the numeric barcodes corresponding to the hexadecimal value of a desired suffix. To save the settings, scan the **Save** barcode.

Note: A custom suffix cannot exceed 10 characters.



Set Custom Suffix

Example: Set the custom suffix to "CODE"

1. Check the hex values of "CODE" in the ASCII Table. ("CODE": 43, 4F, 44, 45)
2. Scan the **Enter Setup** barcode.
3. Scan the **Set Custom Suffix** barcode.
4. Scan the numeric barcodes "4", "3", "4", "F", "4", "4", "4" and "5".
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode.



** Exit Setup

Data Packing

For some applications that require high data integrity and reliability, data packing can help you accomplish that.

Transmission of packed data needs to work with certain software on the Host.

Data packing influences data format and is not recommended for general applications.



**** Disable Data Packing**

Normal Pack

Normal Pack format: [STX + ATTR + LEN] + [AL_TYPE + DATA] + [LRC]

- ✧ STX: 0x02
- ✧ ATTR: 0x00
- ✧ LEN: Barcode data length is expressed in 2 bytes, ranging from 0 to 65535.
- ✧ AL_TYPE: 0x36
- ✧ DATA: Raw barcode data.
- ✧ LRC: Check digit.

LRC calculation algorithm: computation sequence: $0xFF + \text{LEN} + \text{AL_TYPE} + \text{DATA}$; computation method is XOR, byte by byte.



Normal Pack



0006010

Enter Setup

Terminating Character Suffix

A terminating character can be used to mark the end of data, which means nothing can be added after it.

A terminating character suffix can contain one or two characters.

Enable/Disable Terminating Character Suffix

To enable/disable terminating character suffix, scan the appropriate barcode below.



0309010

Enable Terminating Character Suffix



0309000

**** Disable Terminating Character Suffix**



0006000

**** Exit Setup**



Set Terminating Character Suffix

The engine provides a shortcut for setting the terminating character suffix to 0x0D or 0x0D,0x0A by scanning the following barcode.



Terminating Character 0x0D



Terminating Character 0x0D,0x0A

To set a terminating character suffix, scan the **Set Terminating Character Suffix** barcode and then the numeric barcodes corresponding to the hexadecimal value of a desired terminating character. To save the settings, scan the **Save** barcode.

Note: A terminating character suffix cannot exceed 2 characters.



Set Terminating Character Suffix

Example: Set the terminating character suffix to 0x0D

1. Scan the **Enter Setup** barcode.
2. Scan the **Set Terminating Character Suffix** barcode.
3. Scan the numeric barcodes "0" and "D".
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode.





Chapter 8 Symbologies

General Settings

Enable/Disable All Symbologies

If the **Disable All Symbologies** feature is enabled, the engine can only identify the programming barcodes.



Enable All Symbologies



Disable All Symbologies

Enable/Disable 1D Symbologies



Enable 1D Symbologies



Disable 1D Symbologies

Enable/Disable 2D Symbologies



Enable 2D Symbologies



Disable 2D Symbologies



**** Exit Setup**



1D Symbolologies

Code 128

Restore Factory Defaults



Restore the Factory Defaults of Code 128

Enable/Disable Code 128



**** Enable Code 128**



Disable Code 128

Set Length Range for Code 128

The engine can be configured to only decode Code 128 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “**j. Program the Length Range (Maximum/Minimum Lengths) for a Symbolology**” section in Appendix.



Set the Minimum Length (Default: 1)



Set the Maximum Length (Default: 48)





0006010
Enter Setup

GS1-128 (UCC/EAN-128)

Restore Factory Defaults



0412000

Restore the Factory Defaults of GS1-128

Enable/Disable GS1-128




0412020

**** Enable GS1-128**



0412010

Disable GS1-128



0006000
**** Exit Setup**

EAN-8

Restore Factory Defaults



Restore the Factory Defaults of EAN-8

Enable/Disable EAN-8



**** Enable EAN-8**



Disable EAN-8

Transmit Check Digit

EAN-8 is 8 digits in length with the last one as its check digit used to verify the accuracy of the data.



**** Transmit EAN-8 Check Digit**



Do Not Transmit EAN-8 Check Digit



Add-On Code

An EAN-8 barcode can be augmented with a two-digit or five-digit add-on code to form a new one. In the examples below, the part surrounded by blue dotted line is an EAN-8 barcode while the part circled by red dotted line is add-on code.



Enable 2-Digit Add-On Code



**** Disable 2-Digit Add-On Code**



Enable 5-Digit Add-On Code



**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of EAN-8 barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes EAN-8 and ignores the add-on code when presented with an EAN-8 plus add-on barcode. It can also decode EAN-8 barcodes without add-on codes.





EAN-8 Extension

Disable EAN-8 Zero Extend: Transmit EAN-8 barcodes as is.

Enable EAN-8 Zero Extend: Add five leading zeros to decoded EAN-8 barcodes to extend to 13 digits.



Enable EAN-8 Zero Extend



**** Disable EAN-8 Zero Extend**






0006010
Enter Setup

EAN-13

Restore Factory Defaults



0402000

Restore the Factory Defaults of EAN-13

Enable/Disable EAN-13



0402020

** Enable EAN-13



0402010

Disable EAN-13

Transmit Check Digit



0402040

** Transmit EAN-13 Check Digit



0402030

Do Not Transmit EAN-13 Check Digit



0006000
** Exit Setup

Add-On Code

An EAN-13 barcode can be augmented with a two-digit or five-digit add-on code to form a new one.



Enable 2-Digit Add-On Code



**** Disable 2-Digit Add-On Code**



Enable 5-Digit Add-On Code



**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of EAN-13 barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes EAN-13 and ignores the add-on code when presented with an EAN-13 plus add-on barcode. It can also decode EAN-13 barcodes without add-on codes.



0006010

Enter Setup

ISBN

Restore Factory Defaults



0416000

Restore the Factory Defaults of ISBN

Enable/Disable ISBN



0416020

Enable ISBN



0416010

** Disable ISBN

Set ISBN Format



0416030

**ISBN-13



0416040

ISBN-10



0006000

** Exit Setup

UPC-E

Restore Factory Defaults



Restore the Factory Defaults of UPC-E

Enable/Disable UPC-E



** Enable UPC-E



Disable UPC-E

Transmit Check Digit



** Transmit UPC-E Check Digit



Do Not Transmit UPC-E Check Digit



Add-On Code

A UPC-E barcode can be augmented with a two-digit or five-digit add-on code to form a new one.



Enable 2-Digit Add-On Code



**** Disable 2-Digit Add-On Code**



Enable 5-Digit Add-On Code



**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of UPC-E barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes UPC-E and ignores the add-on code when presented with a UPC-E plus add-on barcode. It can also decode UPC-E barcodes without add-on codes.

Transmit System Character “0”

The first character of UPC-E barcode is the system character “0”.



Transmit System Character “0”



**** Do Not Transmit System Character “0”**





UPC-E Extension

Disable UPC-E Extend: Transmit UPC-E barcodes as is.

Enable UPC-E Extend”: Extend UPC-E barcodes to make them compatible in length to UPC-A.



Enable UPC-E Extend



**** Disable UPC-E Extend**





0006010
Enter Setup

UPC-A

Restore Factory Defaults



0404000
Restore the Factory Defaults of UPC-A

Enable/Disable UPC-A



0404020
** Enable UPC-A



0404010
Disable UPC-A

Transmit Check Digit



0404040
** Transmit UPC-A Check Digit



0404030
Do Not Transmit UPC-A Check Digit



0006000
** Exit Setup

Add-On Code

A UPC-A barcode can be augmented with a two-digit or five-digit add-on code to form a new one.



Enable 2-Digit Add-On Code



**** Disable 2-Digit Add-On Code**



Enable 5-Digit Add-On Code



**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of UPC-A barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes UPC-A and ignores the add-on code when presented with a UPC-A plus add-on barcode. It can also decode UPC-A barcodes without add-on codes.

Transmit Preamble Character “0”



Transmit Preamble Character “0”



**** Do not Transmit Preamble Character “0”**

Note: The preamble character “0” usually does not appear in printed UPC-A barcodes.



Interleaved 2 of 5

Restore Factory Defaults



Restore the Factory Defaults of Interleaved 2 of 5

Enable/Disable Interleaved 2 of 5



**** Enable Interleaved 2 of 5**



Disable Interleaved 2 of 5

Set Length Range for Interleaved 2 of 5

The engine can be configured to only decode Interleaved 2 of 5 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “**j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology**” section in Appendix.



Set the Minimum Length (Default: 6)



Set the Maximum Length (Default: 80)



Parity Check

A check digit is optional for Interleaved 2 of 5 and can be added as the last digit. It is a calculated value used to verify the accuracy of the data.

No Parity Check: The engine transmits Interleaved 2 of 5 barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Interleaved 2 of 5 barcode as check digit. Barcodes passing the check will be transmitted except the last digit, whereas those failing it will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Interleaved 2 of 5 barcode as check digit. Barcodes passing the check will be transmitted, whereas those failing it will not be transmitted.



**** No Parity Check**



Do Not Transmit Check Digit After Parity Check



Transmit Check Digit After Parity Check

Note: If the **Do Not Transmit Check Digit After Parity Check** option is enabled, Interleaved 2 of 5 barcodes with a length that is less than the configured minimum length after having the check digit excluded will not be decoded. (For example, when the **Do Not Transmit Check Digit After Parity Check** option is enabled and the minimum length is set to 4, Interleaved 2 of 5 barcodes with a total length of 4 characters including the check digit cannot be read.)



Set Discrete Lengths for Interleaved 2 of 5

The engine can be configured to only decode Interleaved 2 of 5 barcodes within a specific length range or with a couple of discrete lengths.

The length must be an even number not greater than 64 and consist of three digits (a leading zero or zeros may need to be added to meet the length requirement). For more information, see the “**k. Program the Discrete Lengths for Interleaved 2 of 5**” section in Appendix.



Enable the Discrete Lengths



**** Disable the Discrete Lengths**

The discrete lengths become valid only when the **Enable the Discrete Lengths** option is enabled.



Set the Discrete Length



Delete the Discrete Length



ITF-14

ITF-14 is a special kind of Interleaved 2 of 5 with a length of 14 characters and the last character as the check character.



**** Disable ITF-14**



Enable ITF-14 But Do Not Transmit Check Digit



Enable ITF-14 and Transmit Check Digit

Note: It is advisable not to enable ITF-14 and Interleaved 2 of 5 at the same time.



0006010
Enter Setup

ITF-6

ITF-6 is a special kind of Interleaved 2 of 5 with a length of 6 characters and the last character as the check character.



0405110
**** Disable ITF-6**




0405120
Enable ITF-6 But Do Not Transmit Check Digit



0405130
Enable ITF-6 and Transmit Check Digit

Note: It is advisable not to enable ITF-6 and Interleaved 2 of 5 at the same time.



0006000
**** Exit Setup**

Matrix 2 of 5

Restore Factory Defaults



Restore the Factory Defaults of Matrix 2 of 5

Enable/Disable Matrix 2 of 5



Enable Matrix 2 of 5



** Disable Matrix 2 of 5

Set Length Range for Matrix 2 of 5

The engine can be configured to only decode Matrix 2 of 5 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 4)



Set the Maximum Length (Default: 80)



0006010
Enter Setup

Parity Check

A check digit is optional for Matrix 2 of 5 and can be added as the last digit. It is a calculated value used to verify the accuracy of the data.

No Parity Check: The engine transmits Matrix 2 of 5 barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Matrix 2 of 5 barcode as check digit. Barcodes passing the check will be transmitted except the last digit, whereas those failing it will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Matrix 2 of 5 barcode as check digit. Barcodes passing the check will be transmitted, whereas those failing it will not be transmitted.



0406050
** No Parity Check



0406060
Do Not Transmit Check Digit After Parity Check



0406070
Transmit Check Digit After Parity Check



0006000
** Exit Setup

Code 39

Restore Factory Defaults



Restore the Factory Defaults of Code 39

Enable/Disable Code 39



**** Enable Code 39**



Disable Code 39

Set Length Range for Code 39

The engine can be configured to only decode Code 39 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “**j. Program the Length Range (Maximum/Minimum Lengths) for a Symbol**” section in Appendix.



Set the Minimum Length (Default: 4)



Set the Maximum Length (Default: 48)



Parity Check

A check digit is optional for Code 39 and can be added as the last digit. It is a calculated value used to verify the accuracy of the data.

No Parity Check: The engine transmits Code 39 barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Code 39 barcode as check digit. Barcodes passing the check will be transmitted except the last digit, whereas those failing it will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Code 39 barcode as check digit. Barcodes passing the check will be transmitted, whereas those failing it will not be transmitted.



**** No Parity Check**



Do Not Transmit Check Digit After Parity Check



Transmit Check Digit After Parity Check



**** Exit Setup**



Transmit Start/Stop Character



**** Transmit Start/Stop Character**



Do not Transmit Start/Stop Character

Enable/Disable Code 39 Full ASCII

By default, the engine is only able to read some ASCII characters. You can configure your engine to identify all ASCII characters by scanning the appropriate barcode below.



Enable Code 39 Full ASCII



**** Disable Code 39 Full ASCII**





Codabar

Restore Factory Defaults



Restore the Factory Defaults of Codabar

Enable/Disable Codabar



**** Enable Codabar**



Disable Codabar

Set Length Range for Codabar

The engine can be configured to only decode Codabar barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “**j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology**” section in Appendix.



Set the Minimum Length (Default: 2)



Set the Maximum Length (Default: 60)



Parity Check

A check digit is optional for Codabar and can be added as the last digit. It is a calculated value used to verify the accuracy of the data.

No Parity Check: The engine transmits Codabar barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Codabar barcode as check digit. Barcodes passing the check will be transmitted except the last digit, whereas those failing it will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Codabar barcode as check digit. Barcodes passing the check will be transmitted, whereas those failing it will not be transmitted.



**** No Parity Check**



Do Not Transmit Check Digit After Parity Check



Transmit Check Digit After Parity Check



Transmit Start/Stop Character



**** Transmit Start/Stop Character**



Do not Transmit Start/Stop Character

Start/Stop Character Format

You can choose your desired start/stop characters format by scanning the appropriate barcode below.



**** ABCD/ABCD as the Start/Stop Character**



ABCD/TN*E as the Start/Stop Character



**** Start/Stop Character in Uppercase**



Start/Stop Character in Lowercase



**** Exit Setup**

Code 93

Restore Factory Defaults



Restore the Factory Defaults of Code 93

Enable/Disable Code 93



Enable Code 93



** Disable Code 93

Set Length Range for Code 93

The engine can be configured to only decode Code 93 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 1)



Set the Maximum Length (Default: 48)



Parity Check

Check digits are optional for Code 93 and can be added as the last two digits, which are calculated values used to verify the accuracy of the data.

No Parity Check: The engine transmits Code 93 barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run parity checks using the last two digits of Code 93 barcode as check digits. Barcodes passing the checks will be transmitted except the last two digits, whereas those failing them will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run parity checks using the last two digits of Code 93 barcode as check digits. Barcodes passing the checks will be transmitted, whereas those failing them will not be transmitted.



**** No Parity Check**



Do Not Transmit Check Digit After Parity Check



Transmit Check Digit After Parity Check



**** Exit Setup**



GS1-Databar (RSS)

Restore Factory Defaults



Restore the Factory Defaults of GS1-Databar

Enable/Disable GS1 Databar



**** Enable GS1-DataBar**



Disable GS1-DataBar

Transmit Application Identifier "01"



**** Transmit Application Identifier "01"**



Do Not Transmit Application Identifier "01"





GS1 Composite Code

Restore Factory Defaults



Restore the Factory Defaults of GS1 Composite Code

Enable/Disable GS1 Composite Code



Enable GS1 Composite Code



** Disable GS1 Composite Code

EAN/UPC Composite

When EAN/UPC Composite is enabled, the engine will not be able to read standard EAN/UPC barcodes.



Enable EAN/UPC Composite



** Disable EAN/UPC Composite





Code 11

Restore Factory Defaults



Restore the Factory Defaults of Code 11

Enable/Disable Code 11



Enable Code 11



** Disable Code 11

Set Length Range for Code 11

The engine can be configured to only decode Code 11 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 4)



Set the Maximum Length (Default: 48)





0006010

Enter Setup

Transmit Check Digit



0415120

**** Transmit Check Digit**



0415110

Do Not Transmit Check Digit

Parity Check



0415050

No Parity Check



0415060

**** One Check Digit, MOD11**



0415070

Two Check Digits, MOD11/MOD11



0415080

Two Check Digits, MOD11/MOD9



0415090

**One Check Digit, MOD11 (Len<=10)
Two Check Digits, MOD11/MOD11 (Len>10)**



0415100

**One Check Digit, MOD11 (Len<=10)
Two Check Digits, MOD11/MOD9 (Len>10)**



0006000

**** Exit Setup**

Industrial 2 of 5

Restore Factory Defaults



Restore the Factory Defaults of Industrial 2 of 5

Enable/Disable Industrial 2 of 5



Enable Industrial 2 of 5



** Disable Industrial 2 of 5

Set Length Range for Industrial 2 of 5

The engine can be configured to only decode Industrial 2 of 5 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 6)



Set the Maximum Length (Default: 48)



Parity Check

A check digit is optional for Industrial 2 of 5 and can be added as the last digit. It is a calculated value used to verify the accuracy of the data.

No Parity Check: The engine transmits Industrial 2 of 5 barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Industrial 2 of 5 barcode as check digit. Barcodes passing the check will be transmitted except the last digit, whereas those failing it will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Industrial 2 of 5 barcode as check digit. Barcodes passing the check will be transmitted, whereas those failing it will not be transmitted.



**** No Parity Check**



Do Not Transmit Check Digit After Parity Check



Transmit Check Digit After Parity Check



**** Exit Setup**

Standard 25

Restore Factory Defaults



Restore the Factory Defaults of Standard 25

Enable/Disable Standard 25



Enable Standard 25



** Disable Standard 25

Set Length Range for Standard 25

The engine can be configured to only decode Standard 25 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 6)



Set the Maximum Length (Default: 48)



Parity Check

A check digit is optional for Standard 25 and can be added as the last digit. It is a calculated value used to verify the accuracy of the data.

No Parity Check: The engine transmits Standard 25 barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Standard 25 barcode as check digit. Barcodes passing the check will be transmitted except the last digit, whereas those failing it will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Standard 25 barcode as check digit. Barcodes passing the check will be transmitted, whereas those failing it will not be transmitted.



**** No Parity Check**



Do Not Transmit Check Digit After Parity Check



Transmit Check Digit After Parity Check



Plessey

Restore Factory Defaults



Restore the Factory Defaults of Plessey

Enable/Disable Plessey



Enable Plessey



** Disable Plessey

Set Length Range for Plessey

The engine can be configured to only decode Plessey barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 4)



Set the Maximum Length (Default: 48)



Parity Check

Check digits are optional for Plessey and can be added as the last two digits, which are calculated values used to verify the accuracy of the data.

No Parity Check: The engine transmits Plessey barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run parity checks using the last two digits of Plessey barcode as check digits. Barcodes passing the checks will be transmitted except the last two digits, whereas those failing them will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run parity checks using the last two digits of Plessey barcode as check digits. Barcodes passing the checks will be transmitted, whereas those failing them will not be transmitted.



No Parity Check



Do Not Transmit Check Digit After Parity Check



**** Transmit Check Digit After Parity Check**



MSI-Plessey

Restore Factory Defaults



Restore the Factory Defaults of MSI-Plessey

Enable/Disable MSI-Plessey



Enable MSI-Plessey



** Disable MSI-Plessey

Set Length Range for MSI-Plessey

The engine can be configured to only decode MSI-Plessey barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 4)



Set the Maximum Length (Default: 48)



0006010

Enter Setup

Transmit Check Digit



0420100

**** Transmit Check Digit**



0420090

Do Not Transmit Check Digit

Parity Check



0420050

No Parity Check



0420060

**** One Check Digit, MOD10**



0420070

Two Check Digits, MOD10/MOD10



0420080

Two Check Digits, MOD10/MOD11



0006000

**** Exit Setup**

2D Symbolologies

PDF 417

Restore Factory Defaults



Restore the Factory Defaults of PDF 417

Enable/Disable PDF 417



**** Enable PDF 417**



Disable PDF 417

Set Length Range for PDF 417

The engine can be configured to only decode PDF 417 barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “**j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology**” section in Appendix.



Set the Minimum Length (Default: 1)



Set the Maximum Length (Default: 2710)



0006010
Enter Setup

PDF 417 Inverse

Regular Barcode: Dark bars on a bright background.

Inverse Barcode: Bright bars on a dark background.



0501320

**** Decode Regular PDF417 Barcodes Only**



0501321

Decode Inverse PDF417 Barcodes Only



0501322

Decode Both



0006000
**** Exit Setup**



PDF417 Twin Code

PDF417 twin code is 2 PDF417 barcodes paralleled vertically or horizontally. Two of them must have the same direction and similar specifications and be placed closely together.

There are 3 options for reading PDF417 twin codes:

Single PDF417 Only: Read either PDF417 code.

Twin PDF417 Only: Read both PDF417 codes. Transmission sequence: left (upper) PDF417 code followed by right (lower) PDF417 code.

Both Single & Twin: Read both PDF417 codes. If successful, transmit as twin PDF417 only. Otherwise, try single PDF417 only.



**** Single PDF417 Only**



Twin PDF417 Only



Both Single & Twin





QR Code

Restore Factory Defaults



Restore the Factory Defaults of QR Code

Enable/Disable QR Code



**** Enable QR Code**



Disable QR Code

Set Length Range for QR Code

The engine can be configured to only decode QR Code barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “**j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology**” section in Appendix.



Set the Minimum Length (Default: 1)



Set the Maximum Length (Default: 7089)





QR Twin Code

QR twin code is 2 QR barcodes paralleled vertically or horizontally. Two of them must have the same direction and similar specifications and be placed closely together.

There are 3 options for reading QR twin codes:

Single QR Only: Read either QR code.

Twin QR Only: Read both QR codes. Transmission sequence: left (upper) QR code followed by right (lower) QR code.

Both Single & Twin: Read both QR codes. If successful, transmit as twin QR only. Otherwise, try single QR only.



**** Single QR Only**



Twin QR Only



Both Single & Twin





Aztec Code

Restore Factory Defaults



Restore the Factory Defaults of Aztec Code

Enable/Disable Aztec Code



Enable Aztec Code



**** Disable Aztec Code**

Set Length Range for Aztec Code

The engine can be configured to only decode Aztec Code barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “**j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology**” section in Appendix.



Set the Minimum Length (Default: 1)



Set the Maximum Length (Default: 3832)





Read Multi-barcodes of an Image

There are three modes:

Mode 1: Read one barcode only.

Mode 2: Read fixed number of barcodes only.

Mode 3: Composite Reading. Read fixed number of barcodes first. If unsuccessful, read one barcode only.





0006010

Enter Setup

Set the Number of Barcodes



0503060

** 1



0503061

2



0503062

3



0503063

4



0503064

5



0503065

6



0503066

7



0503067

8



0006000

** Exit Setup

Data Matrix

Restore Factory Defaults



Restore the Factory Defaults of Data Matrix

Enable/Disable Data Matrix



****Enable Data Matrix**



Disable Data Matrix

Set Length Range for Data Matrix

The engine can be configured to only decode Data Matrix barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “**j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology**” section in Appendix.



Set the Minimum Length (Default: 1)



Set the Maximum Length (Default: 3116)



0006010

Enter Setup

Rectangular Barcode



0504110

**** Enable Rectangular Barcode**



0504100

Disable Rectangular Barcode

Data Matrix Inverse



0504320

**** Decode Regular Data Matrix Barcodes Only**



0504321

Decode Inverse Data Matrix Barcodes Only



0504322

Decode Both



0006000

**** Exit Setup**

Data Matrix Twin Code

Data Matrix twin code is 2 Data Matrix barcodes paralleled vertically or horizontally. Two of them must have the same direction and similar specifications and be placed closely together.

There are 3 options for reading Data Matrix twin codes:

Single Data Matrix Only: Read either Data Matrix code.

Twin Data Matrix Only: Read both Data Matrix codes. Transmission sequence: left (upper) Data Matrix code followed by right (lower) Data Matrix code.

Both Single & Twin: Read both Data Matrix codes. If successful, transmit as twin Data Matrix only. Otherwise, try single Data Matrix only.



**** Single Data Matrix Only**



Both Single & Twin



Twin Data Matrix Only



Maxicode

Restore Factory Defaults



Restore the Factory Defaults of Maxicode

Enable/Disable Maxicode



Enable Maxicode



** Disable Maxicode

Set Length Range for Maxicode

The engine can be configured to only decode Maxicode barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 1)



Set the Maximum Length (Default: 150)





Chinese Sensible Code

Restore Factory Defaults



Restore the Factory Defaults of Chinese Sensible Code

Enable/Disable Chinese Sensible Code



Enable Chinese Sensible Code



**** Disable Chinese Sensible Code**

Set Length Range for Chinese Sensible Code

The engine can be configured to only decode Chinese Sensible barcodes with lengths that fall between (inclusive) the minimum and maximum lengths. To accomplish it, you need to set the minimum and maximum lengths.

For more information, see the “j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology” section in Appendix.



Set the Minimum Length (Default: 1)



Set the Maximum Length (Default: 7827)





0006010

Enter Setup

Chinese Sensible Code Inverse



0508080

**** Decode Regular Chinese Sensible Barcodes Only**



0508081

Decode Inverse Chinese Sensible Barcodes Only



0508082

Decode Both



0006000

**** Exit Setup**

Chapter 9 Troubleshooting

FAQ

Q: How to show barcode data in a text file (output data in a cursor)?

A: Enable the USB HID-KBW feature. But only characters and digits available on the keyboard can be sent.

Q: What are compatible/supported barcode types?

A: See the User Guide.

Q: How to change the format from ISBN-13 into ISBN-10?

A: Disable EAN-13 and then enable ISBN and ISBN-10.

Q: Some barcodes can't be read.

- a) Find out the barcode type and check if the barcode type is enabled. See Appendix 1: Factory Defaults Table for default barcode types.
- b) If the barcode type is enabled, check whether the parity check and length range settings match the barcodes.
- c) If the barcodes are stained, defaced, torn, distorted or poorly printed, try barcodes of good print quality. If you need to scan barcodes off mobile phones, enable the Mobile Phone Mode.
- d) Provide such information as model number, firmware version and barcode type when contacting our technical support.

Q: Some barcodes are decoded incorrectly.

- a) Check whether the parity check and length range settings match the barcodes..
- b) Provide such information as model number, firmware version and barcode type when contacting our technical support.

Q: Barcodes can be read, but cannot be displayed.

A: If barcodes contain non-alphanumeric character(s), change the communication mode (USB COM Port Emulation recommended).

Q: The device is frozen or unresponsive.

- a) Check if the device is properly connected and powered up.
- b) Send the Restore All Factory Defaults command to the device via a serial cable or USB cable.

Q: How to enable/disable terminating character (Carriage Return or Line Feed)?

A: See the User Guide.

Q: The device fails to communicate with QuickSet or UExpress.

A: Enable the USB Datapipe or USB COM Port Emulation feature.

Appendix

Appendix 1: Factory Defaults Table

Parameter	Factory Default	Remark
System Settings		
Barcode Programming	Disabled	
Programming barcode data	Do not send	
Illumination	Normal	
Aiming Beam	Normal	
Decode Beep	Enabled Type 1, 80ms (Duration), 2730Hz (Frequency), Loud (Volume)	
Startup Beep	Enabled	
LED Notification for Good Decode	Enabled, 20ms (Duration)	
Scan Mode	Auto Mode	
Decode Session Timeout	3000ms	Range: 500- 3600000ms
Timeout between Decodes (Same Barcode)	Disabled, 1500ms	Range:1-3600000ms
Scanning Preference	Regular Mode (scan barcodes on paper)	
Decode Area	Whole Area Decoding	
Central Area	20%	
Send Product Information upon Startup	Disabled	
Communication Interfaces		
Baud Rate	9600	Serial Communication Interface
Parity Check	None	Serial Communication Interface
Data Bits	8	Serial Communication Interface
Stop Bit	1	Serial Communication Interface
USB Country Keyboard Type	US	USB HID-KBW
Beep on Unknown Character	Disabled	USB HID-KBW
Emulate ALT+Keypad	Disabled	USB HID-KBW

Function Key Mapping	Disabled	USB HID-KBW
Inter-Keystroke Delay	No Delay	USB HID-KBW
Caps Lock/Unlock	Unlock	USB HID-KBW
Convert Case	No Case Conversion	USB HID-KBW
Emulate Numeric Keypad	Disabled	USB HID-KBW
Data Formatting		
All Prefix/Suffix	Disabled	
Prefix Sequence	Code ID+Custom Prefix+AIM ID	Code ID+ Custom Prefix+ AIM ID+Data+ Custom Suffix + Terminating Character
AIM ID Prefix	Disabled	
Code ID Prefix	Disabled	1 or 2 English letters
Custom Prefix	Disabled	Max. 10 characters
Custom Suffix	Disabled	Max. 10 characters
Terminating Character Suffix	Disabled	Max. 2 characters
Data Packing	Disabled	
Symbologies		
Code 128		
Code 128	Enabled	
Maximum Length	48	
Minimum Length	1	
EAN-8		
EAN-8	Enabled	
Check Digit	Transmit	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Extend to EAN-13	Disabled	
EAN-13		
EAN-13	Enabled	
Check Digit	Transmit	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
UPC-E		

UPC-E	Enabled	
Check Digit	Transmit	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Extend to UPC-A	Disabled	
System Character "0"	Do not transmit	
UPC-A		
UPC-A	Enabled	
Check Digit	Transmit	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Preamble Character "0"	Do not transmit	
Interleaved 2 of 5		
Interleaved 2 of 5	Enabled	
Parity Check	No Parity Check	
Check Digit	Do not transmit	
Maximum Length	80	
Minimum Length	6	Minimum length supported: 4
Discrete Length	Disabled	
ITF-6		
ITF-6	Disabled	
ITF-14		
ITF-14	Disabled	
Code 39		
Code 39	Enabled	
Parity Check	Disabled	
Start/Stop Character	Transmit	
Code 39 Full ASCII	Disabled	
Maximum Length	48	
Minimum Length	4	Minimum length supported: 4 (including start/stop characters and check digit)

Codabar		
Codebar	Enabled	
Parity Check	Disabled	
Start/Stop Character	ABCD/ABCD format Uppercase Transmit	
Maximum Length	60	
Minimum Length	2	
Code 93		
Code 93	Disabled	
Parity Check	Enabled	
Check Digit	Do not transmit	
Maximum Length	48	
Minimum Length	1	Minimum length supported: 1
GS1-128 (UCC/EAN-128)		
GS1-128 (UCC/EAN-128)	Enabled	
GS1 Databar(RSS)		
GS1 Databar(RSS)	Enabled	
Application Identifier "01"	Transmit	
GS1 Composite (EAN-UCC Composite)		
GS1 Composite	Disabled	
UPC/EAN Composite	Disabled	
Code 11		
Code 11	Disabled	
Check Digit	Transmit	
Parity Check	1 Check Digit, MOD11	
Maximum Length	48	
Minimum Length	4	Minimum length supported: 4
ISBN		
ISBN	Disabled	
ISBN Format	ISBN-13	
Matrix 2 of 5(European Matrix 2 of 5)		
Maxtrix 2 of 5	Disabled	

Parity Check	Disabled	
Maximum Length	80	
Minimum Length	4	Minimum length supported: 4
Industrial 25		
Industrial 25	Disabled	
Parity Check	Disabled	
Maximum Length	48	
Minimum Length	6	Minimum length supported: 4
Standard 25		
Standard 25	Disabled	
Parity Check	Disabled	
Maximum Length	48	
Minimum Length	6	Minimum length supported: 4
Plessey		
Plessey	Disabled	
Parity Check	Enabled	
Check Digit	Transmit	
Maximum Length	48	
Minimum Length	4	Minimum length supported: 4
MSI-Plessey		
MSI-Plessey	Disabled	
Parity Check	1 Check Digit, MOD10	
Check Digit	Transmit	
Maximum Length	48	
Minimum Length	4	Minimum length supported: 4
PDF 417		
PDF 417	Enabled	
Read Single PDF417 Only	Enabled	
Maximum Length	2710	
Minimum Length	1	
PDF 417 Inverse	Decode regular PDF417 barcodes only	
QR Code		

QR Code	Enabled	
Read Single QR Only	Enabled	
Maximum Length	7089	
Minimum Length	1	
Aztec		
Aztec	Disabled	
Read Multi-barcodes of an Image	Disabled	
Maximum Length	3832	
Minimum Length	1	
Data Matrix		
Data Matrix	Enabled	
Read Single Data Matrix Only	Enabled	
Read Rectangular Barcode	Enabled	
Data Matrix Inverse	Decode regular Data Matrix barcodes only	
Maximum Length	3116	
Minimum Length	1	
Maxicode		
Maxicode	Disabled	
Maximum Length	150	
Minimum Length	1	
Chinese Sensible Code		
Chinese Sensible Code	Off	
Chinese Sensible Code Inverse	Decode regular Chinese Sensible barcodes only	
Maximum Length	7827	
Minimum Length	1	

Appendix 2: AIM ID Table

Symbology	AIM ID	Possible AIM ID Modifiers (m)
Code 128]C0	
GS1-128 (UCC/EAN-128)]C1	
EAN-8]E4	
EAN-13]E0	
EAN-13 with Addon]E3	
UPC-E]E0	
UPC-E with Addon]E3	
UPC-A]E0	
UPC-A with Addon]E3	
Interleaved 2 of 5]Im	0,1,3
ITF-6]Im	1,3
ITF-14]Im	1,3
Matrix 2 of 5]X0	
Code 39]Am	0,1,3,4,5,7
Codabar]Fm	0,2,4
Code 93]G0	
Code 11]Hm	0,1,3
ISBN]X0	
Industrial 25]S0	
Standard 25]R0	
Plessey]P0	
MSI-Plessey]Mm	0,1
GS1 Databar(RSS)]e0	
GS1Composite Code]em	0-3
PDF417]Lm	0-2
QR Code]Qm	0-6
Aztec]zm	0-9, A-C
Data Matrix]dm	0-6
Maxicode]Um	0-3
Chinese Sensible Code]X0	

Note: “m” represents the AIM modifier character. Refer to ISO/IEC 15424:2008 Information technology – Automatic identification and data capture techniques – Data Carrier Identifiers (including Symbology Identifiers) for AIM modifier character details.

Appendix 3: Code ID Table

Symbology	Code ID
Code 128	j
GS1-128 (UCC/EAN-128)	j
EAN-8	d
EAN-13	d
UPC-E	c
UPC-A	c
Interleaved 2 of 5	e
ITF-6	e
ITF-14	e
Matrix 2 of 5	v
Code 39	b
Codabar	a
Code 93	i
Code 11	H
GS1 Databar(RSS)	R
GS1Composite Code(EAN•UCC Composite)	y
ISBN	B
Matrix 2 of 5(European Matrix 2 of 5)	v
Industrial 25	l
Standard 25	f
Plessey	n
MSI-Plessey	m
PDF417	r
QR Code	s
Aztec	z
Data Matrix	u
Maxicode	x
Chinese Sensible Code	h

Appendix 4: ASCII Table

Hex	Dec	Char
00	0	NUL (Null char.)
01	1	SOH (Start of Header)
02	2	STX (Start of Text)
03	3	ETX (End of Text)
04	4	EOT (End of Transmission)
05	5	ENQ (Enquiry)
06	6	ACK (Acknowledgment)
07	7	BEL (Bell)
08	8	BS (Backspace)
09	9	HT (Horizontal Tab)
0a	10	LF (Line Feed)
0b	11	VT (Vertical Tab)
0c	12	FF (Form Feed)
0d	13	CR (Carriage Return)
0e	14	SO (Shift Out)
0f	15	SI (Shift In)
10	16	DLE (Data Link Escape)
11	17	DC1 (XON) (Device Control 1)
12	18	DC2 (Device Control 2)
13	19	DC3 (XOFF) (Device Control 3)
14	20	DC4 (Device Control 4)
15	21	NAK (Negative Acknowledgemnt)
16	22	SYN (Synchronous Idle)
17	23	ETB (End of Trans. Block)
18	24	CAN (Cancel)
19	25	EM (End of Medium)
1a	26	SUB (Subsitute)
1b	27	ESC (Escape)
1c	28	FS (File Separator)
1d	29	GS (Group Separator)

1e	30	RS (Request to Send)
1f	31	US (Unit Separator)
20	32	SP (Space)
21	33	!(Exclamation Mark)
22	34	" (Double Quote)
23	35	#(Number Sign)
24	36	\$(Dollar Sign)
25	37	% (Percent)
26	38	& (Ampersand)
27	39	`(Single Quote)
28	40	((Right / Closing Parenthesis)
29	41)(Right / Closing Parenthesis)
2a	42	* (Asterisk)
2b	43	+ (Plus)
2c	44	, (Comma)
2d	45	- (Minus / Dash)
2e	46	. (Dot)
2f	47	/(Forward Slash)
30	48	0
31	49	1
32	50	2
33	51	3
34	52	4
35	53	5
36	54	6
37	55	7
38	56	8
39	57	9
3a	58	:(Colon)
3b	59	;(Semi-colon)
3c	60	< (Less Than)
3d	61	= (Equal Sign)
3e	62	> (Greater Than)
3f	63	? (Question Mark)
40	64	@ (AT Symbol)

41	65	A
42	66	B
43	67	C
44	68	D
45	69	E
46	70	F
47	71	G
48	72	H
49	73	I
4a	74	J
4b	75	K
4c	76	L
4d	77	M
4e	78	N
4f	79	O
50	80	P
51	81	Q
52	82	R
53	83	S
54	84	T
55	85	U
56	86	V
57	87	W
58	88	X
59	89	Y
5a	90	Z
5b	91	[(Left / Opening Bracket)
5c	92	\ (Back Slash)
5d	93] (Right / Closing Bracket)
5e	94	^ (Caret / Circumflex)
5f	95	_ (Underscore)
60	96	' (Grave Accent)
61	97	a
62	98	b
63	99	c

64	100	d
65	101	e
66	102	f
67	103	g
68	104	h
69	105	i
6a	106	j
6b	107	k
6c	108	l
6d	109	m
6e	110	n
6f	111	o
70	112	p
71	113	q
72	114	r
73	115	s
74	116	t
75	117	u
76	118	v
77	119	w
78	120	x
79	121	y
7a	122	z
7b	123	{ (Left/ Opening Brace)
7c	124	(Vertical Bar)
7d	125	} (Right/Closing Brace)
7e	126	~ (Tilde)
7f	127	DEL (Delete)

Appendix 5: Country Code Table

Country/Language	Code	Country/Language	Code
U.S.	0	Netherlands(Dutch)	14
Belgium	1	Norway	15
Brazil	2	Poland	16
Canada(French)	3	Portugal	17
Czechoslovakia	4	Romania	18
Denmark	5	Russia	19
Finland(Swedish)	6	Slovakia	21
France	7	Spain	22
Germany/Austria	8	Sweden	23
Greece	9	Switzerland(German)	24
Hungary	10	Turkey F	25
Israel(Hebrew)	11	Turkey Q	26
Italy	12	U.K	27
Latin-American	13	Japan	28

Appendix 6: ASCII Function Key Mapping Table

ASCII Function	ASCII Value (HEX)	No Function Key Mapping	Function Key Mapping
NUL (Null char.)	00	Null	Crtl+2
SOH (Start of Header)	01	Keypad Enter	Crtl+A
STX (Start of Text)	02	Caps Lock	Crtl+B
ETX (End of Text)	03	Null	Crtl+C
EOT (End of Transmission)	04	Null	Crtl+D
ENQ (Enquiry)	05	Null	Crtl+E
ACK (Acknowledgment)	06	Null	Crtl+F
BEL (Bell)	07	Enter	Crtl+G
BS (Backspace)	08	Left Arrow	Crtl+H
HT (Horizontal Tab)	09	Horizontal Tab	Crtl+I
LF (Line Feed)	0A	Down Arrow	Crtl+J
VT (Vertical Tab)	0B	Vertical Tab	Crtl+K
FF (Form Feed)	0C	Backspace	Crtl+L
CR (Carriage Return)	0D	Enter	Crtl+M
SO (Shift Out)	0E	Insert	Crtl+N
SI (Shift In)	0F	Esc	Crtl+O
DLE (Data Link Escape)	10	F11	Crtl+P
DC1 (XON) (Device Control 1)	11	Home	Crtl+Q
DC2 (Device Control 2)	12	Print Screen	Crtl+R
DC3 (XOFF) (Device Control 3)	13	Delete	Crtl+S
DC4 (Device Control 4)	14	tab+shift	Crtl+T
NAK (Negative Acknowledgemnt)	15	F12	Crtl+U
SYN (Synchronous Idle)	16	F1	Crtl+V
ETB (End of Trans. Block)	17	F2	Crtl+W
CAN (Cancel)	18	F3	Crtl+X
EM (End of Medium)	19	F4	Crtl+Y
SUB (Substitute)	1A	F5	Crtl+Z
ESC (Escape)	1B	F6	See the following table
FS (File Separator)	1C	F7	
GS (Group Separator)	1D	F8	
RS (Request to Send)	1E	F9	
US (Unit Separator)	1F	F10	

ASCII Function Key Mapping Table (Continued)

The function key mappings of the last five characters in the table above differ from one keyboard layout to another.

Country/ Keyboard Layout	Function Key Mapping				
	1B	1C	1D	1E	1F
United States	Ctrl+[Ctrl+\	Ctrl+]	Ctrl+6	Ctrl+-
Belgium	Ctrl+ [Ctrl+<	Ctrl+]	Ctrl+6	Ctrl+-
Scandinavia	Ctrl+8	Ctrl+<	Ctrl+9	Ctrl+6	Ctrl+-
France	Ctrl+^	Ctrl+8	Ctrl+\$	Ctrl+6	Ctrl+=
Germany		Ctrl+Ã	Ctrl++	Ctrl+6	Ctrl+-
Italy		Ctrl+\	Ctrl++	Ctrl+6	Ctrl+-
Switzerland		Ctrl+<	Ctrl+.	Ctrl+6	Ctrl+-
United Kingdom	Ctrl+ [Ctrl+ ¢	Ctrl+]	Ctrl+6	Ctrl+-
Denmark	Ctrl+8	Ctrl+\	Ctrl+9	Ctrl+6	Ctrl+-
Norway	Ctrl+8	Ctrl+\	Ctrl+9	Ctrl+6	Ctrl+-
Spain	Ctrl+ [Ctrl+\	Ctrl+]	Ctrl+6	Ctrl+-

Appendix 7: Symbology ID Number

Symbology	ID Number	Symbology	ID Number
Code 128	002	Standard 2 of 5	026
GS1-128 (UCC/EAN128)	003	Plessey	027
EAN-8	004	Code11	028
EAN-13	005	MSI/Plessey	029
UPC-E	006	Composite Code	030
UPC-A	007	GS1-Databar	031
Interleaved 2 of 5	008	PDF417	032
ITF-14	009	QR Code	033
ITF-6	010	Aztec Code	034
Matrix 2 of 5	011	Data Matrix	035
Code 39	013	Maxicode	036
Codabar	015	Chinese Sensible Code	039
Code 93	017		
ISBN	024		
Industrial 2 of 5	025		

Appendix 8: Parameter Programming Examples

The following examples show you how to program parameters by scanning programming barcodes.

a. Program the Decode Session Timeout

Example: Set the decode session timeout to 1500ms

1. Scan the **Enter Setup** barcode.
2. Scan the **Decode Session Timeout** barcode. (See the “**Decode Session Timeout**” section in Chapter 3)
3. Scan the numeric barcodes “1”, “5”, “0” and “0”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

b. Program the Timeout between Decodes (Same Barcode)

Example: Set the timeout between decodes (same barcode) to 1000ms

1. Scan the **Enter Setup** barcode.
2. Scan the **Timeout between Decodes (Same Barcode)** barcode. (See the “**Timeout between Decodes (Same Barcode)**” section in Chapter 3)
3. Scan the numeric barcodes “1”, “0”, “0” and “0”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

c. Program the Central Area

Example: Set the percentage of central area to 20%

1. Scan the **Enter Setup** barcode.
 2. Scan the **Specify Central Area** barcode. (See the “**Specify Central Area**” section in Chapter 4)
 3. Scan the numeric barcodes “2” and “0”.
 4. Scan the **Save** barcode.
 5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)
-

d. Program the Duration of Good Decode Beep (Type 1)

Example: Set the duration of good decode beep to 100ms

1. Scan the **Enter Setup** barcode.
2. Scan the **Custom** barcode. (See the “**Beep Duration**” section in Chapter 6)
3. Scan the numeric barcodes “1” , “0” and “0”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

e. Program the Frequency of Good Decode Beep (Type 1)

Example: Set the frequency of good decode beep to 3000Hz

1. Scan the **Enter Setup** barcode.
2. Scan the **Custom** barcode. (See the “**Beep Frequency**” section in Chapter 6)
3. Scan the numeric barcodes “3” , “0” , “0” and “0”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

f. Program the LED Notification Duration for Good Decode

Example: Set the LED notification duration to 2000ms

1. Scan the **Enter Setup** barcode.
 2. Scan the **Custom** barcode. (See the “**LED Notification Duration for Good Decode**” section in Chapter 6)
 3. Scan the numeric barcodes “2” , “0” , “0” and “0”.
 4. Scan the **Save** barcode.
 5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)
-

g. Program the Custom Prefix/Suffix

Example: Set the custom prefix to “CODE”

1. Check the hex values of “CODE” in the ASCII Table. (“CODE”: 43, 4F, 44, 45)
2. Scan the **Enter Setup** barcode.
3. Scan the **Set Custom Prefix** barcode. (See the “**Set Custom Prefix**” section in Chapter 7)
4. Scan the numeric barcodes “4”, “3”, “4”, “F”, “4”, “4”, “4” and “5”.
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

h. Program the Terminating Character Suffix

Example: Set the terminating character suffix to 0x0D

1. Scan the **Enter Setup** barcode.
2. Scan the **Set Terminating Character Suffix** barcode. (See the “**Set Terminating Character Suffix**” section in Chapter 7)
3. Scan the numeric barcodes “0” and “D”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

i. Program the Code ID

Example: Set the Code ID of PDF 417 to “p”

1. Check the hex value of “p” in the ASCII Table. (“p”: 70)
 2. Scan the **Enter Setup** barcode.
 3. Scan the **Modify PDF 417 Code ID** barcode. (See the “**Modify Code ID**” section in Chapter 7)
 4. Scan the numeric barcodes “7” and “0”.
 5. Scan the **Save** barcode.
 6. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)
-

j. Program the Length Range (Maximum/Minimum Lengths) for a Symbology

Note: If minimum length is set to be greater than maximum length, the engine only decodes barcodes with either the minimum or maximum length. If you only want to read barcodes with a specific length, set both minimum and maximum lengths to be that desired length.

Example: Set the engine to decode Code 128 barcodes containing between 8 and 12 characters

1. Scan the **Enter Setup** barcode.
2. Scan the **Set the Minimum Length** barcode. (See the “**Set Length Range for Code 128**” section in Chapter 8)
3. Scan the numeric barcode “8”.
4. Scan the **Save** barcode.
5. Scan the **Set the Maximum Length** barcode. (See the “**Set Length Range for Code 128**” section in Chapter 8)
6. Scan the numeric barcodes “1” and “2”.
7. Scan the **Save** barcode.
8. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

k. Program the Discrete Lengths for Interleaved 2 of 5

Example 1: Set the engine to decode Interleaved 2 of 5 barcodes containing either 12 or 24 characters

1. Scan the **Enter Setup** barcode.
2. Scan the **Enable the Discrete Lengths** barcode. (See the “Set Discrete Lengths for Interleaved 2 of 5” section in Chapter 8)
3. Scan the **Set the Discrete Length** barcode.
4. Scan the numeric barcodes “0”, “1” and “2”.
5. Scan the **Save** barcode.
6. Scan the **Set the Discrete Length** barcode.
7. Scan the numeric barcodes “0”, “2” and “4”.
8. Scan the **Save** barcode.
9. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

Example 2: Set the engine to decode Interleaved 2 of 5 barcodes containing between 12 and 24 characters

1. Scan the **Enter Setup** barcode.
2. Scan the **Enable the Discrete Lengths** barcode.”
3. Scan the **Set the Discrete Length** barcode.
4. Scan the numeric barcodes “0”, “1” and “2”.
5. Scan the numeric barcodes “0”, “2” and “4”.
6. Scan the **Save** barcode.
7. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

Appendix 9: F-Key Barcodes

When the HID-KBW feature is enabled, scanning one of the following barcodes will send the corresponding function key.

F1-F6



⏏

F1



⇅

F2



↑

F3



⏏

F4



→

F5



←

F6

F7-F12



F7



F8



F9



F10



F11



F12

Appendix 10: Digit Barcodes

0-9



A-F



A



B



C



D



E



F

Appendix 11: Save/Cancel Barcodes

After reading numeric barcode(s), you need to scan the **Save** barcode to save the data. If you scan the wrong digit(s), you can either scan the **Cancel** barcode and then start the configuration all over again, or scan the **Delete the Last Digit** barcode and then the correct digit, or scan the **Delete All digits** barcode and then the digits you want.

For instance, after reading the **Maximum Length** barcode and numeric barcodes “1”, “2” and “3”, you scan:

- ✧ **Delete the Last Digit:** The last digit “3” will be removed.
- ✧ **Delete All Digits:** All digits “123” will be removed.
- ✧ **Cancel:** The maximum length configuration will be cancelled. And the engine is still in the setup mode.



0000160

Save



0000170

Delete the Last Digit



0000180

Delete All Digits



0000190

Cancel



Headquarters / 总部

福建新大陆自动识别技术有限公司

地址：福建省福州市马尾区儒江西路 1 号新大陆科技园

邮编：350015

电话：+86 - (0) 591-83979222

传真：+86 - (0) 591-83979208

E-mail: marketing@nlscan.com

WEB: www.nlscan.com

Newland Europe BV/ 欧洲新大陆有限公司

Rolweg 25, 4104 AV Culemborg, The Netherlands

TEL: +31 (0) 345 87 00 33

FAX: +31 (0) 345 87 00 39

Email: sales@newland-id.com

WEB: www.newland-id.com

Tech Support: tech-support@newland-id.com

Newland North America Inc. / 北美新大陆有限公司

Address: 46559 Fremont Blvd., Fremont, CA 94538, USA

TEL: 510 490 3888

Fax: 510 490 3887

Email: info@newlandna.com

WEB: www.newlandna.com

Newland Taiwan Inc. / 台灣新大陸資訊科技股份有限公司

7F-6, No. 268, Liancheng Rd., Jhonghe Dist. 235, New Taipei City, Taiwan

新北市 235 中和區連城路 268 號 7 樓之 6 (遠東世紀廣場 J 棟)

TEL: +886 2 7731 5388

FAX: +886 2 7731 5389

Email: sales.tw@newland-id.com

WEB: www.newland-id.com.tw