

Verification Continuum™

VC Verification IP

USB

UVM User Guide

Version V-2023.09, September 2023



Copyright Notice and Proprietary Information

© 2023 Synopsys, Inc. All rights reserved. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at <http://www.synopsys.com/company/legal/trademarks-brands.html>. All other product or company names may be trademarks of their respective owners.

Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

www.synopsys.com

Contents

Preface	7
Web Resources	7
Customer Support	7
Synopsys Statement on Inclusivity and Diversity	7
Chapter 1	
Introduction	9
1.1 Product Overview	9
1.2 User Prerequisites	10
1.3 References	11
1.4 VIP Integration and Test Work Flow Chart	11
1.5 Product Features	12
1.5.1 VIP Features	12
1.5.2 USB Layers Feature and Component Port Support	12
1.5.3 Verification Features	16
1.6 UVM Features	16
Chapter 2	
Download and Installation	19
2.1 Hardware Requirements	19
2.2 Software Requirements	20
2.2.1 Platform/OS and Simulator Software	20
2.2.2 Synopsys Common Licensing (SCL) Software	20
2.2.3 Third Party Software	20
2.3 Setting Environment Variables	20
2.4 Downloading From SolvNetPlus and Installing	21
2.4.1 Downloading From Electronic Software Transfer (EST) System (Download Center)	21
2.4.2 Downloading Using FTP With a Web Browser	22
2.5 Adding VIP to Your Design Directory and Verifying Installation	23
2.5.1 Creating a Testbench Design Directory	23
2.5.2 Running Examples	24
2.6 Licensing	24
2.6.1 Simulation License Suspension	25
2.6.2 License Polling	25
2.7 Environment Variables	25
2.8 The dw_vip_setup Administrative Tool	25
2.8.1 Setting Environment Variables	26
2.8.2 The dw_vip_setup Command	26
2.9 Installing and Setting Up More Than One VIP Protocol	30
2.9.1 Running the Example With +incdir+	30

2.9.2 Getting Help on Example Run/make Scripts	31
2.9.3 Updating an Existing Model	32
Chapter 3	
Design Directory Maintenance	33
3.1 Design Directory	33
3.2 Usage Examples for dw_vip_setup Utility	34
3.2.1 Set Up a New VIP	34
3.2.2 Installing and Setting Up More than One VIP Protocol Suite	35
3.2.3 Updating an Existing Model	36
3.3 Include and Import Model Files into Your Testbench	36
3.3.1 UVM	36
3.4 Compile and Run Time Options	37
3.4.1 UVM	37
3.5 Removing VIP Models from a Design Directory	37
3.6 Installing a VIP Example	38
3.6.1 Running a VIP Example	38
Chapter 4	
Overview of the USB VIP	41
4.1 Introduction to UVM	41
4.2 USB VIP in an UVM Environment	42
4.2.1 Base Classes	42
4.2.2 UVM Components	43
4.2.3 USB VIP Objects	44
4.2.4 Interfaces and Modports	49
4.2.5 Constraints	50
4.2.6 Factories	52
4.2.7 Messages	53
4.2.8 Protocol Component SuperSpeed Link Callback, Factory, and Event Flows	54
4.2.9 Link Callback, Factory and UVM Event Flows for USB 2.0 VIP	67
4.2.10 Link Callback, Factory and UVM Event Flows for USB 3.1 VIP	77
4.2.11 SuperSpeed Packet Chronology	77
Chapter 5	
Verification Topologies	97
5.1 USB VIP Host and DUT Device Controller	97
5.2 USB VIP Device and DUT Host Controller	99
5.3 USB VIP Host and DUT Device PHY	100
5.4 USB VIP Host and DUT Device	101
5.5 USB VIP Device and DUT Host	102
5.6 USB VIP Device and DUT Host – Concurrent SS and 2.0 Traffic	103
5.7 USB VIP Device with Hub Emulation and DUT Host – Concurrent Serial Interface Traffic	104
Chapter 6	
Usage Notes	105
6.1 Setting Verbosity Levels	105
6.1.1 Setting Verbosity in the Testbench	105
6.1.2 Setting Verbosity During Run Time	105
6.2 SystemVerilog UVM Example Testbenches	108
6.3 Configuring VIP Using Configuration Creator	108

6.4 Protocol Feature	109
6.4.1 SuperSpeed Low Power Entry Support	109
6.4.2 Executing Aligned Transfers	112
6.4.3 SuperSpeed Serial LTSSM Flow (SS.Disabled to U0)	114
6.4.4 UTMI+ Support	116
6.4.5 USB 2.0 OTG Support	118
6.4.6 HSIC Overview	137
6.4.7 Using 2.0 Test Mode with UTMI	153
6.4.8 SuperSpeed InterChip Physical (SSIC) Usage	158
6.5 Implementing Functional Coverage	160
6.5.1 Default Functional Coverage	160
6.5.2 Covergroup Organization	161
6.5.3 Range Bins	162
6.5.4 Default Functional Coverage Class Hierarchy	162
6.5.5 Coverage Callback Classes	163
6.5.6 Using Functional Coverage	164
6.5.7 Using the High-Level Verification Plans	165
6.6 Using the Passive Monitor	165
6.6.1 VIP as Host Passive Monitor	165
6.6.2 VIP as Device Passive Monitor	165
Chapter 7	
Debug	167
7.1 Setting Up and Using Protocol Analyzer	167
7.1.1 Enabling the SVT USB VIP to Generate Data for Protocol Analyzer	167
7.1.2 Using Native Protocol Analyzer for Debugging	168
7.1.3 Performance Analyzer	169
7.2 Debug port	170
7.2.1 Enabling Debug Port	170
7.2.2 Invoking Debug Port Interface Signals	170
Chapter A	
Appendix A: Reporting Problems	171
A.1 Introduction	171
A.2 Debug Automation	171
A.3 Enabling and Specifying Debug Automation Features	172
A.4 Debug Automation Outputs	173
A.5 FSDB File Generation	174
A.5.1 VCS	174
A.5.2 Questa	174
A.5.3 Incisive	174
A.5.4 Creating a Waveform File	174
A.6 Initial Customer Information	175
A.6.1 Describing Your Issue	175
A.6.2 Describing Your Verification Environment	175
A.7 Sending Debug Information to Synopsys	175
A.8 Limitations	176



Preface

About This Manual

This manual contains installation, setup, and usage material for SystemVerilog UVM users of the Synopsys Discovery USB VIP, and is for design or verification engineers who want to verify USB operation using a UVM testbench written in SystemVerilog. Readers are assumed to be familiar with USB, Object Oriented Programming (OOP), SystemVerilog, and Universal Verification Methodology (UVM) techniques.

Web Resources

- ❖ Documentation through SolvNetPlus: <https://solvnetplus.synopsys.com> (Synopsys password required)
- ❖ Synopsys Common Licensing (SCL): <http://www.synopsys.com/keys>

Customer Support

To obtain support for your product, choose one of the following:

1. Go to <https://solvnetplus.synopsys.com/> and open a case.
 - ◆ Enter the information according to your environment and your issue.
 - ◆ For simulation issues, provide a UVM_FULL verbosity log file of the VIP instance and a VPD or FSDB dump file of the VIP interface.
2. Send an e-mail message to support_center@synopsys.com
 - ◆ Include the Product name, Sub Product name, and Product version for which you want to register the problem.
3. Telephone your local support center.
 - ◆ North America:
Call 1-800-245-8005 from 7 AM to 5:30 PM Pacific time, Monday through Friday.
 - ◆ All other countries:
<https://www.synopsys.com/support/global-support-centers.html>

Synopsys Statement on Inclusivity and Diversity

Synopsys is committed to creating an inclusive environment where every employee, customer, and partner feels welcomed. We are reviewing and removing exclusionary language from our products and supporting customer-facing collateral. Our effort also includes internal initiatives to remove biased language from our engineering and working environment, including terms that are embedded in our software and IPs. At the same time, we are working to ensure that our web content and software applications are usable to people of varying abilities. You may still find examples of non-inclusive language in our software or documentation

as our IPs implement industry-standard specifications that are currently under review to remove exclusionary language.

1

Introduction

The VC VIP for Verification IP supports verification of USB IP and SoC designs that include interfaces implementing the Universal Serial Bus Specification. This document describes the use of this VIP in testbenches that comply with the Universal Verification Methodology (UVM). This approach leverages advanced verification technologies and tools that provide:

- ❖ Protocol functionality and abstraction
- ❖ Constrained random verification
- ❖ Functional coverage
- ❖ Rapid creation of complex tests
- ❖ Proven testbench architecture that provides maximum reuse, scalability and modularity
- ❖ Proven verification approach and methodology
- ❖ Transaction-level, self-checking tests
- ❖ Object oriented interface that allows OOP techniques

This document assumes that you are familiar with USB, object oriented programming, SystemVerilog, and UVM.

This chapter gives a basic introduction, overview, and features of the USB UVM VIP.

The Introduction chapter discusses the following topics:

- ❖ [“Product Overview”](#)
- ❖ [“User Prerequisites”](#)
- ❖ [“References”](#)
- ❖ [“VIP Integration and Test Work Flow Chart”](#)
- ❖ [“Product Features”](#)
- ❖ [“UVM Features”](#)

1.1 Product Overview


The USB VIP is a suite of UVM-based verification components that are compatible for use with SystemVerilog-Compliant testbenches. The USB VIP suite simulates transfers, transactions, and packets through UVM agents as defined by the USB 3.1 and USB 2.0 specifications. The VIP defines one agent with three UVM components to implement the USB Specification.

The components are as follows:

- ❖ svt_usb_physical – Supports the physical layer of the USB protocol
- ❖ svt_usb_link – Supports the link layer of the USB protocol
- ❖ svt_usb_protocol – Supports the protocol layer of the USB protocol

Figure 1-1 shows the relationship of the three UVM components within the USB agent.

Figure 1-1 USB VIP UVM Agent Architecture



1.2 User Prerequisites

- ❖ Familiarize with USB, object oriented programming, SystemVerilog, and the current version of UVM.

1.3 References


For more information on USB, see the following documents:

- ❖ Class Reference for USB is available at:
`$DESIGNWARE_HOME/vip/svt/usb_svt/latest/doc/class_ref/usb_svt_uvm_class_reference/html/index.html`
- ❖ FAQ
`$DESIGNWARE_HOME/vip/svt/usb_svt/latest/doc/PDFs/usb_svt_faq.pdf`
- ❖ Getting Started Guide
`$DESIGNWARE_HOME/vip/svt/usb_svt/latest/doc/PDFs/usb_svt_uvm_getting_started.pdf`

1.4 VIP Integration and Test Work Flow Chart

The following flow chart represents the high level VIP Integration and Test Work Flow.

Figure 1-2 VIP Flow Chart



1.5 Product Features

1.5.1 VIP Features

USB VIP currently supports the following features:

- ❖ Enhanced SuperSpeed (ESS), SuperSpeed (SS), High-Speed (HS), Full-Speed (FS), Low-Speed (LS) and Embedded USB2
- ❖ Host, Device, PHY, Retimer, and Hub verification
- ❖ PHY interface support
 - ◆ UTMI, ULPI, HSIC, PIPE 3/4, SSIC, ESS Serial, SS Serial, 20 serial, Embedded USB2.0 Serial interfaces
- ❖ Power Management: Supports USB 3.2, USB 3.1 and USB 2.0 implementations
- ❖ USB 3.0/2.0 OTG support

1.5.2 USB Layers Feature and Component Port Support

1.5.2.1 Protocol Layer Features

The USB protocol layer manages the end-to-end flow of data between a device and its host. The VIP Protocol component accepts and processes testbench transfer requests according to the specification.

USB VIP supports the following protocol layer functions:

- ❖ Host emulation: Optional control to emulate Hub's downstream-facing hub port
- ❖ Device emulation: Optional control to emulate Hub's upstream-facing hub port
 - ◆ Emulates up to 128 devices with up to 32 endpoints each
- ❖ Transfers: Bulk, Bulk Stream, Control, ISOC, and Interrupt
- ❖ SOF and ITP packets: Generated automatically or under testbench control
- ❖ ESS LMP packets: Includes optional automatic generation of LMP capability, configuration or config response packets upon U0 entry
- ❖ Endpoint Halt control
 - ◆ Automatic endpoint halt upon receipt of STALL response.
 - ◆ Ability for VIP Host to attempt 'n' more transfers to a halted endpoint to verify persistence of DUT device halt status.
 - ◆ Support for testbench requested endpoint halt status entry and clearing of halt status
- ❖ USB 2.0 split traffic
- ❖ USB 2.0 LS on FS traffic
- ❖ Transaction scheduler: Transfers scheduling in (micro) frames/bus intervals

1.5.2.2 Protocol Component Ports

UVM Ports are the mechanism through which the Protocol Layer component connects to other components in the USB VIP sub-environment (`svt_usb_agent`) and/or to the testbench. The Protocol component contains various types of ports:

- ❖ Transfer Input ports. These are used by the sequencer to send sequences into the protocol layer. You cannot connect to them. They are only used by the sequencer. Consult UVM documentation on how to use sequence related classes.
- ❖ Observed ports (analysis ports). You take data from these ports and use them for either generating inputs into response (output ports), or for creating scoreboards and coverage checks.
- ❖ Response or Transfer Out ports. You use these ports to place data into the protocol layer.

The Protocol Layer component has the following UVM Port interfaces:

- ❖ `transfer_in_port` - Transfer input port used to supply stimulus transfers for the VIP as USB Host to execute. Used only by sequencers. You cannot connect to them.
- ❖ `transfer_out_port` - Transfer blocking_peek port used to give testbench access to transfers created by VIP as USB Device.
- ❖ `transfer_observed_port` - Transfer analysis port used to give testbench access to completed transfers.
- ❖ `transfer_response_port` - Transfer response input port used to allow testbench to supply transfer response details and control to VIP as USB Device.
- ❖ `usb_ss_packet_in_port` - Rx Packet data objects coming from the USB SS link layer arrive through this `get_peek` port.
- ❖ `usb_20_packet_in_port` - Rx Packet data objects coming from the USB 2.0 link layer arrive through this `get_peek` port.
- ❖ `protocol_service_in_port` - Protocol Layer service request data objects (`svt_usb_protocol_service`) to be acted upon by the Protocol Layer component are sent in through this port.
- ❖ `protocol_service_observed_port` - Protocol Layer service request (`svt_usb_protocol_service`) analysis port used to give testbench access to ITP (SS), LMP (SS), and LPM (2.0) service requests consumed (received).

1.5.2.3 Link Layer Features

The VIP Link Layer component emulates the link protocol data flow defined by the USB specifications, according to the bus speed appropriate protocol specification. USB VIP supports the following link layer functions:

- ❖ USB General Support
 - ◆ Host and Device support
 - ◆ Speed fallback from:
 - ◇ ESS Gen2 to Gen1
 - ◇ ESS to 2.0 speeds
 - ◆ Speed fall-forward from FS or HS to ESS
 - ◆ Speed fallback from SSP to SS
- ❖ USB 3.1 Support
 - ◆ LTSSM - Direct LTSSM state change support
 - ◆ ESS power management
 - ◆ ITP support
 - ◆ Link advertisements

- ◆ Link command and packet processing and response
- ❖ USB 2.0 Support
 - ◆ LPM
 - ◆ Suspend and Resume
 - ◆ USB2 power management

1.5.2.4 Link Component Ports

UVM Ports are the mechanism through which the Link Layer component connects to other components in the USB VIP sub-environment (svt_usb_agent) and/or to the testbench. The Link component contains various types of ports:

- ❖ Transfer Input ports. These are used by the sequencer to send sequences into the link layer. You cannot connect to them. They are only used by the sequencer. Consult UVM documentation on how to use sequence related classes.
- ❖ Observed ports (analysis ports). You take data from these ports and use them for either generating inputs into response (output ports), or for creating scoreboards and coverage checks.
- ❖ Response or Transfer Out ports. You use these ports to place data into the link layer.

The following list describes objects that move information through the Link component.

- ❖ usb_ss_packet_in_port - Super-speed Packet input port used to supply stimulus packets for the VIP to produce (transmit).
- ❖ usb_ss_packet_out_port - Super-speed Packet get_peek output port used to give upper-layer access to packets consumed (received).
- ❖ usb_ss_packet_observed_port - Super-speed Packet analysis port used to give testbench access to packets consumed (received).
- ❖ usb_20_packet_in_port - 2.0 Packet input port used to supply stimulus packets for the VIP to produce (transmit).
- ❖ usb_20_packet_out_port - 2.0 Packet get_peek output port used to give upper-layer access to packets consumed (received).
- ❖ usb_20_packet_observed_port - 2.0 Packet analysis port used to give testbench access to packets consumed (received).
- ❖ usb_ss_data_in_port - Rx Data objects coming from the USB super-speed physical layer arrive through this port.
- ❖ usb_20_data_in_port - Rx Data objects coming from the USB 2.0 physical layer arrive through this port.
- ❖ link_service_in_port - Link Layer service request data objects (svt_usb_link_service) to be acted upon by the Link Layer component are sent in through this port.

1.5.2.5 Physical Layer Features

USB VIP supports the following physical layer functions:

- ❖ ESS PIPE, Host, Device, PHY, OTG and Hub verification, and Serial
 - ◆ Data scrambling/descrambling
 - ◆ 8b/10b encoding/decoding for USB 3.0

- ◆ 128b/132b encoding/decoding for USB 3.1
- ◆ Rx data and clock recovery
- ◆ Rx error detection and polarity inversion
- ◆ Receiver detect
- ◆ Low frequency Periodic Signal transmission/detection
- ◆ Spread spectrum Clocking allowed on input clock
- ◆ 8/16/32 bit parallel interface
- ◆ PCLK generation (when configured as PHY)
- ◆ 10.0/5.0 Gb/s serial interface
- ❖ USB 2.0 UTMI/ULPI and Serial
 - ◆ 480Mb/s (HS), 12Mb/s (FS), or 1.5Mb/s (LS) serial interface
 - ◆ Bit stuffing/un-stuffing
 - ◆ NRZI encoding/decoding
 - ◆ Rx clock and data recovery
 - ◆ Rx error detection
 - ◆ Receiver detection
 - ◆ SYNC/EOP transmission/detection
 - ◆ Reset, Resume, Wakeup, and Suspend transmission
 - ◆ UTMI+ support
 - ◇ UTMI MAC and PHY support.
 - ◇ VIP configured as host and device can both act as MAC or PHY on the UTMI interface.
 - ◇ Reset, suspend and resume.

1.5.2.6 Physical Component Ports

UVM Ports are the mechanism through which the Physical Layer component connects to other components in the USB VIP sub-environment (svt_usb_agent) and/or to the testbench. The Physical component contains various types of ports:

- ❖ Transfer Input ports. These are used by the sequencer to send sequences into the physical layer. You cannot connect to them. They are only used by the sequencer. Consult UVM documentation on how to use sequence related classes.
- ❖ Observed ports (analysis ports). You take data from these ports and use them for either generating inputs into response (output ports), or for creating scoreboards and coverage checks.
- ❖ Response or Transfer Out ports. You use these ports to place data into the physical layer.

UVM Ports utilized for the USB SS data path are:

- ❖ usb_ss_link_data_in_port - Input port for USB SS data transactions to be sent by this component.
- ❖ usb_ss_link_data_observed_port - Analysis port for USB SS data transactions received by this component.
- ❖ usb_ss_physical_data_in_port - Input port for USB SS data transactions received by this component.

- ❖ `usb_ss_physical_data_out_port` - Output port for USB SS data transactions to be sent by this component.
- ❖ `usb_ss_physical_service_in_port` - Input port for USB SS service requests to this component.

UVM Ports utilized for the USB 2.0 data path are:

- ❖ `usb_20_link_data_in_port` - Input port for USB 2.0 data transactions to be sent by this component.
- ❖ `usb_20_link_data_observed_port` - Analysis port for USB 2.0 data transactions received by this component.
- ❖ `usb_20_physical_data_in_port` - Input port for USB 2.0 data transactions received by this component.
- ❖ `usb_20_physical_data_out_port` - Output port for USB 2.0 data transactions to be sent by this component.
- ❖ `usb_20_physical_service_in_port` - Input port for USB 2.0 service requests to this component.

1.5.3 Verification Features

USB VIP currently supports the following verification functions:

- ❖ Checks and Scoreboard
- ❖ Passive monitor
- ❖ Functional Coverage with Verification Planner
- ❖ Verdi and Protocol Analyzer Debug
- ❖ Sequence Libraries
- ❖ Debug Ports

1.6 UVM Features

USB VIP currently supports the following methodology functions:

The following is a summary of the supported UVM features:

- ❖ Top level USB agent that implements the following:
 - ◆ Configurable USB component stack that connects protocol, link, and physical components.
 - ◆ Support automatic end-of-test determination
- ❖ Callback support in all layers of the component stack
- ❖ Sequencers
- ❖ Random stimulus generators
- ❖ Factories
- ❖ Functional coverage for Link and Protocol layer
- ❖ Trace support in all layers of the component stack
- ❖ Digital simulation of analog signaling required for attachment and detachment detection
- ❖ Configuration object support
- ❖ Input through sequence item pull ports. The analysis ports are for output to the testbench for use in coverage, scoreboarding, and so forth.
 - ◆ USB transfers: BULK, CONTROL, ISOC, and Interrupt

- ◆ Packets (USB 2.0): TOKEN, DATA, HANDSHAKE, SPECIAL, NO_PID
- ◆ Packets (SS): TP and DP
- ◆ PHY requests: Drive Reset, Drive Resume/Suspend, Drive USB states (J, K, SE0, and SE1), High speed disconnect, Attach/detach (serial)
- ◆ Support for post port get actions using callbacks
- ◆ Support for post randomization callbacks after transfer, transaction, or packet randomization by the component
- ◆ Support for input transaction coverage through callbacks
- ◆ Service input ports:
 - ◇ Available on all components for receiving commands
- ◆ Error injection
 - ◇ Comprehensive built in errors, with constraints to control injection
 - ◇ Support for injecting multiple errors
 - ◇ Support for user override of errors and error constraints
 - ◇ Support for user provided error injection objects
- ❖ Output via TLMs
 - ◆ Performed in response to internal events
 - ◆ Generates transactions
 - ◆ Support for pre-port put actions via callback registered with the component
 - ◆ Output transaction coverage via callbacks
 - ◆ User provided objects supported by the `uvm_object_registry` and the `set_type_override` and `set_inst_override` methods.
 - ◆ An analysis port, for LPM, LMP, and ITP indication.
- ❖ Testbench scoreboard, done using callbacks.



2

Download and Installation

The Download and Installation chapter discusses the following topics:

- ❖ [Hardware Requirements](#)
- ❖ [Software Requirements](#)
- ❖ [Setting Environment Variables](#)
- ❖ [Downloading From SolvNetPlus and Installing](#)
- ❖ [Adding VIP to Your Design Directory and Verifying Installation](#)
- ❖ [Licensing](#)
- ❖ [Environment Variables](#)
- ❖ [The dw_vip_setup Administrative Tool](#)
- ❖ [Installing and Setting Up More Than One VIP Protocol](#)



If you encounter any problem in installing the USB VIP, see Customer Support.

2.1 Hardware Requirements

The USB VIP requires a Solaris or Linux workstation configured as follows:

[Table 2-1](#) describes the system requirements for the USB VIP product.

Table 2-1 System Requirements

Element	Minimum System Requirement
Platform/OS and VCS	See Platform/OS and Simulator Software
Disk Space	Approximately 400 MB available disk space for installation and basic use.
Memory	<ul style="list-style-type: none">For users of VCS or VCS MX, see VCS Installation Notes or VCS MX Installation Notes, which are accessible from the VC VIP for Installation Guide (search for “VC VIP for Installation Guide” on www.synopsys.com).For users of other simulators, see the documentation for your simulator.

**Note**

You must have access to www.designware.com to download the release image. You can sign up to receive updates for any VIP component through this web site.

2.2 Software Requirements

The USB VIP is qualified for use with certain versions of platforms and simulators. This section lists software that the USB VIP requires. This section consists of the following subsections:

- ❖ [Platform/OS and Simulator Software](#)
- ❖ [Synopsys Common Licensing \(SCL\) Software](#)
- ❖ [Third Party Software](#)

The Synopsys Discovery is qualified for use with certain versions of platforms and simulators. This section lists software that the requires.

2.2.1 Platform/OS and Simulator Software

To see which platform/OS and simulator versions are qualified for use with the USB VIP, check the support matrix for SVT-based VIP in the following document:

[VC VIP for USB Release Notes](#)

2.2.2 Synopsys Common Licensing (SCL) Software

The SCL software provides the licensing function for the Synopsys Discovery. Acquiring the SCL software is covered here in the installation instructions.

2.2.3 Third Party Software

- ❖ **Adobe Acrobat:** Synopsys Discovery documents are available in Acrobat PDF files. You can get Adobe Acrobat Reader for free from <http://www.adobe.com>.
- ❖ **HTML browser:** Synopsys Discovery USB VIP includes class reference documentation in HTML. The following browser/platform combinations are supported:
 - ◆ Microsoft Internet Explorer 6.0 or later (Windows)
 - ◆ Firefox 1.0 or later (Windows and Linux)
 - ◆ Netscape 7.x (Windows and Linux)

2.3 Setting Environment Variables

1. Set `DESIGNWARE_HOME` to the following absolute path where USB VIP is to be installed:


```
setenv DESIGNWARE_HOME <absolute_path_to_designware_home>
```
2. Ensure that your environment and `PATH` variables are set correctly, including:
 - ◆ `DESIGNWARE_HOME/bin` – The absolute path as described in the previous step.
 - ◆ `LM_LICENSE_FILE` – The absolute path to a file that contains the license keys for your third-party tools. Also, include the absolute path to the third party executable in your `PATH` variable.


```
% setenv LM_LICENSE_FILE <my_license_file|port@host>
```
 - ◆ `SNPSLMD_LICENSE_FILE` – The absolute path to a file that contains the license keys for Vera and Synopsys Common Licensing software or the `port@host` reference to this file.

```
% setenv SNPSLMD_LICENSE_FILE $LM_LICENSE_FILE  
<my_Synopsys_license_file|port@host>
```

- ◆ DW_LICENSE_FILE – The absolute path to a file that contains the license keys for VIP product software or the port@host reference to this file.

```
% setenv DW_LICENSE_FILE <my_VIP_license_file|port@host>
```

2.4 Downloading From SolvNetPlus and Installing

You can download the software from the download center using either HTTPS or FTP, or with a command-line FTP session. If you do not know your Synopsys SolvNetPlus password or you do not remember it, go to <http://solvnetplus.synopsys.com>.

You require the passive mode of FTP. The passive command toggles between the passive and active mode. If your FTP utility does not support the passive mode, use HTTP. For additional information, refer the following web page:

https://www.synopsys.com/apps/protected/support/EST-FTP_Accelerator_Help_Page.html

This section consists of the following subsections:

- ❖ [Downloading From Electronic Software Transfer \(EST\) System \(Download Center\)](#)
- ❖ [Downloading Using FTP With a Web Browser](#)



Attention

The Electronic Software Transfer (EST) system only displays products that your site is entitled to download. If the product you are looking for is not available, contact est-ext@synopsys.com

2.4.1 Downloading From Electronic Software Transfer (EST) System (Download Center)

- a. Point your web browser to <http://solvnetplus.synopsys.com>.
- b. Enter your Synopsys SolvNetPlus Username and Password.
- c. Click Sign In button.
- d. Make the following selections on SolvNetPlus to download the .run file of the VIP (See [Figure 1-1](#)).
 - i. Downloads tab
 - ii. Synopsys VIP Library product releases
 - iii. <release_version>
 - iv. Download Here button
 - v. Yes, I Agree to the Above Terms button
 - vi. Download .run file for the VIP

Figure 2-1 SolvNetPlus Selections for VIP Download

The figure illustrates the steps to download a VIP from the Synopsys SolvNetPlus website. It shows three screenshots of the website interface with red annotations highlighting key elements:

- Screenshot 1 (Left):** Shows the Synopsys SolvNetPlus homepage. The 'Downloads' link in the top navigation bar is highlighted. Below, the 'My Product Releases' section lists various products, with 'J-2014.06' highlighted.
- Screenshot 2 (Middle):** Shows the 'Download Details' for 'Synopsys VIP Library: J-2014.03'. The 'Download Here' button is highlighted.
- Screenshot 3 (Right):** Shows the 'Synopsys Electronic Software Transfer (EST)' page. The 'YES, I AGREE TO THE ABOVE TERMS' checkbox is highlighted, and the 'Download Here' button is highlighted.

A text box at the bottom left of the figure provides an example: "For example: Download vip_amba_svt_2.45a.run".

- e. Set the `DESIGNWARE_HOME` environment variable to absolute path of the location where you want to install the VIP.

```
% setenv DESIGNWARE_HOME <VIP_installation_absolute_path>
```

Execute the `.run` file by invoking its filename. The VIP is unpacked and all files and directories are installed under the path specified by the `DESIGNWARE_HOME` environment variable. The `.run` file can be executed from any directory. The important step is to set the `DESIGNWARE_HOME` environment variable before executing the `.run` file.



Note

You may download multiple files simultaneously.

2.4.2 Downloading Using FTP With a Web Browser

Follow Step a to Step e of Section 2.3.1 and then, perform the following steps:

- a. Click the Download via FTP link instead of the Download Here button.
- b. Click the Click Here To Download button.
- c. Select the file(s) that you want to download.
- d. Follow browser prompts to select a destination location.

**Note**

If you are unable to download the Verification IP using these instructions, see Customer Support.

2.5 Adding VIP to Your Design Directory and Verifying Installation

Integrating Synopsys Discovery into your testbench consists of the following tasks:

- ❖ [Creating a Testbench Design Directory](#)
- ❖ [Running Examples](#)

2.5.1 Creating a Testbench Design Directory

After installing the image, you need to set up a testbench design directory. A *design directory* contains a version of the Synopsys Discovery that is set up and ready for use in a testbench. A design directory gives you control over the version of Synopsys Discovery in your testbench because it is isolated from the DESIGNWARE_HOME installation.

You use the `dw_vip_setup` utility to create design directories. The `dw_vip_setup` utility allows you to perform the following tasks:

- ❖ Create the design directory (`design_dir`), which contains the transactors, support files (include files), and examples (if any)

Adds the specified version of USB VIP from DESIGNWARE_HOME to a design directory. If no version is specified, the latest version is added.

**Note**

If a version of VIP is already present in the specified design directory, then the new version files will overwrite the existing version.

To create a design directory and add an example, use the following command:

```
% $DESIGNWARE_HOME/bin/dw_vip_setup -path <design_dir> -e usb_svt/<example name> -svlog
```

Where `<example name>` are as follows:

- ❖ `tb_usb_svt_uvm_intermediate_sys`
- ❖ `tb_usb_svt_uvm_basic_sys`

To create a design directory and add the `usb_agent_svt` model, use the following command for UVM:

```
% $DESIGNWARE_HOME/bin/dw_vip_setup -path <design_dir> -a usb_agent_svt -svlog
```

**Note**

You must specify the `-svlog` option when adding the `usb_subenv_svt` model or an example. If `-svlog` is not used, VIP issues the following error message:

```
ERROR: VRO_CACHE_DIR is set to a directory that does not exist.
```

For a full description of `dw_vip_setup`, see [The dw_vip_setup Command](#). For more information on the design directory, see [Creating a Testbench Design Directory](#).

2.5.2 Running Examples

You can run an example to verify the following:

- ❖ The Synopsys Discovery is correctly installed
- ❖ The hardware, software, and license requirements are met

You can run examples using the Makefile or the shell script that is provided with the VIP. After the simulation completes, you can review the `./logs/compile.log` and `./logs/simulate.log` files or any errors. For more information on running examples, see the Running Examples tab on the HTML QuickStart documentation and the Readme file.



Note

Do not try to run the steps or examples from within the `DESIGNWARE_HOME` installation. Ensure that you have used the `dw_vip_setup` utility to copy the necessary files to your design directory as explained in [Creating a Testbench Design Directory](#).

2.6 Licensing

The USB VIP uses the SCL software to control its usage. You can find general SCL information from the following link:

<http://www.synopsys.com/keys>

The USB VIP uses a licensing mechanism that is enabled by the following license features:

- ❖ VIP-USB3-SVT

Only one license is consumed per simulation, no matter how many VIP models are instantiated in the design.

The licensing key must reside in files that are indicated by specific environment variables. For information about setting these licensing environment variables, see [Environment Variables](#).

The USB VIP can be enabled by the following license combinations. They are listed in the order of being checked. If one set is not available, the next set would be checked. If none are available, USB VIP will report an error.



Note

Licensing is required if the VIP component classes are instantiated in the design. This includes envs, agents, drivers, monitors, sequencers, and components in UVM and OVM. This includes groups, subenvs, and transactors in VMM.

Licensing is required if the VIP component classes are instantiated in the design. This includes envs, agents, drivers, monitors, sequencers, and components in UVM and OVM. This includes groups, subenvs, and transactors in VMM.

The USB VIP product is enabled by the following features defined in the order listed. After, a required feature or a set of features are successfully checked out, the VIP stops looking for other licenses.

- ❖ VIP-USB3-SVT
- ❖ VIP-PROTOCOL-SVT

If the VIP is configured to run in ESS mode, the following features are defined in sequential order:

- ❖ VIP-USB3-SVT + VIP-USB-31-OPT-SVT
- ❖ VIP-PROTOCOL-SVT

If define `SVT_USB_20_ENABLE` is enabled, then the following licenses are supported. When the define is enabled, the VIP fails for the corresponding speed selections of SS and ESS.

- ❖ VIP-USB2-SVT
- ❖ VIP-PROTOCOL-SVT

**Note**

“+” represents “AND” and all those features are required.

2.6.1 Simulation License Suspension

All VIP products support license suspension. The simulators that support license suspension allow a model to check-in its license token while a simulator is suspended and then checkout the license token when the simulation is resumed.

**Note**

This capability is simulator-specific; all simulators do not support license check-in during suspension.

2.6.2 License Polling

If you request a license and none are available, license polling allows your request to exist until a license becomes available instead of exiting immediately. To control license polling, use the `DW_WAIT_LICENSE` environment variable as follows:

- ❖ To enable license polling, set `DW_WAIT_LICENSE` to 1.
- ❖ To disable license polling, unset `DW_WAIT_LICENSE`. By default, license polling is disabled.

2.7 Environment Variables

The USB VIP verification models require the following environment variables and path settings:

- ❖ `DESIGNWARE_HOME`: The absolute path to where the VIP is installed.
- ❖ `SNPSLMD_LICENSE_FILE`: The absolute path to a file that contains the license keys for SCL software or the `port@host` reference to this file.
- ❖ `LM_LICENSE_FILE`: The absolute path to a file that contains the license keys for your third-party tools. Also, include the absolute path to the third party executable in your `PATH` variable.

2.8 The dw_vip_setup Administrative Tool

A *design directory* is where the USB VIP is set up for use in a testbench. A design directory is required for using VIP and, for this, the `dw_vip_setup` utility is provided.

The `dw_vip_setup` utility provides the following features:

- ❖ Creates the design directory (`design_dir`), which contains transactors, support files (include files), and examples (if any)
- ❖ Add a specific version of USB VIP from `DESIGNWARE_HOME` to a design directory.

The `dw_vip_setup` utility is as follows:

- ❖ Adds, removes, or updates USB VIP models in a design directory

- ❖ Adds example testbenches to a design directory, the USB VIP models they use (if necessary), and creates a script for simulating the testbench using any of the supported simulators
 - ❖ Restores (cleans) example testbench files to their original state
 - ❖ Reports information about your installation or design directory, including version information
 - ❖ Supports Protocol Analyzer (PA)
 - ❖ Supports the FSDB (File System Data Base) wave format
- The USB VIP provides the following models:

- ◆ `usb_agent_svt`
- ◆ `usb_link_svt`
- ◆ `usb_monitor_checker_svt`
- ◆ `usb_physical_svt`
- ◆ `usb_protocol_svt`
- ◆ `usb_ssic_physical_svt`
- ◆ `usb_subenv_svt`

**Note**

For UVM, set the value of the `UVM_PACKER_MAX_BYTES` 24000 on the command line as follows:

```
+define+UVM_PACKER_MAX_BYTES=24000
```

Otherwise, the USB VIP issues a fatal error.

For UVM, use the `UVM_DISABLE_AUTO_ITEM_RECORDING` macro to allow the USB VIP to use the UVM automatic transaction begin-end triggering and recording feature. Otherwise, the VIP issues a fatal error.

This section consists of the following subsections:

- ❖ [Setting Environment Variables](#)
- ❖ [The `dw_vip_setup` Command](#)

2.8.1 Setting Environment Variables

Before running `dw_vip_setup`, the `DESIGNWARE_HOME` environment must point to the location where the VIP is installed.

2.8.2 The `dw_vip_setup` Command

Invoke `dw_vip_setup` from the command prompt. The `dw_vip_setup` command checks the syntax of command-line arguments and makes sure that the requested input files exist. The syntax of the command is as follows:

```
% dw_vip_setup [-p[ath] directory] switch (model [-v[ersion] latest | version_no] ) ...
```

or

```
% dw_vip_setup [-p[ath] directory] switch -m[odel_list] filename
```

where

Table 2-2 dw_vip_setup Command

Command	Description
<code>[-p[ath] <i>directory</i>]</code>	The optional <code>-path</code> argument specifies the path to your design directory. When omitted, <code>dw_vip_setup</code> uses the current working directory.
<code>switch</code>	The switch argument defines <code>dw_vip_setup</code> operation. Table 2-3 lists the switches and their applicable sub-switches.

Table 2-3 Setup Program Switch Descriptions

Switch	Description
<code>-a[dd] (model [-v[ersion] version])...</code>	<p>Adds the specified model or models to the specified design directory or the current working directory. If you do not specify a version, the latest version is assumed. The model names are as follows:</p> <ul style="list-style-type: none">• <code>usb_agent_svt</code>• <code>usb_link_svt</code>• <code>usb_monitor_checker_svt</code>• <code>usb_physical_svt</code>• <code>usb_protocol_svt</code>• <code>usb_ssic_physical_svt</code>• <code>usb_subenv_svt</code> <p>The <code>-add</code> switch makes <code>dw_vip_setup</code> to build suite libraries from the same suite as the specified models, and to copy the other necessary files from <code>\$DESIGNWARE_HOME</code>.</p>
<code>-r[emove] model</code>	<p>Removes all versions of the specified model or models from the design. The <code>dw_vip_setup</code> command does not attempt to remove any include files used solely by the specified model or models. The model names are as follows:</p> <ul style="list-style-type: none">• <code>usb_agent_svt</code>• <code>usb_link_svt</code>• <code>usb_monitor_checker_svt</code>• <code>usb_physical_svt</code>• <code>usb_protocol_svt</code>• <code>usb_ssic_physical_svt</code>• <code>usb_subenv_svt</code>

Table 2-3 Setup Program Switch Descriptions (Continued)


Switch	Description
<code>-u[update] (model [-v[ersion] version])...</code>	<p>Updates to the specified model version for the specified model or models. The <code>dw_vip_setup</code> script updates to the latest models when you do not specify a version. The model names are as follows:</p> <ul style="list-style-type: none"> • <code>usb_agent_svt</code> • <code>usb_link_svt</code> • <code>usb_monitor_checker_svt</code> • <code>usb_physical_svt</code> • <code>usb_protocol_svt</code> • <code>usb_ssic_physical_svt</code> • <code>usb_subenv_svt</code> <p>The <code>-update</code> switch makes <code>dw_vip_setup</code> to build suite libraries from the same suite as the specified models, and to copy other necessary files from <code>\$DESIGNWARE_HOME</code>.</p>
<code>-e[example] {scenario model/scenario} [-v[ersion] version]</code>	<p>The <code>dw_vip_setup</code> script configures a testbench example for a single model or a system testbench for a group of models. The script creates a simulator-run program for all supported simulators.</p> <p>If you specify a scenario (or system) for example, testbench the models needed for the testbench are included automatically and do not need to be specified in the command.</p> <p> Note Use the <code>-info</code> switch to list all available system examples.</p>
<code>-ntb</code>	Not supported.
<code>-svtb</code>	Use this switch to set up models and example testbenches for SystemVerilog. The resulting design directory is streamlined and you can use it in SystemVerilog simulations.
<code>-c[lean] {scenario model/scenario}</code>	Cleans the specified scenario or testbench in either the design directory (as specified by the <code>-path</code> switch) or the current working directory. This switch deletes all files in the specified directory, then restores all Synopsys created files to their original contents.
<code>-i[nfo] design home</code>	<p>When you specify the <code>-info design</code> switch, <code>dw_vip_setup</code> prints a list of all models and libraries, installed in the specified design directory or the current working directory, and their respective versions. You can use the output from <code>-info design</code> to create a <code>model_list</code> file.</p> <p>When you specify the <code>-info home</code> switch, <code>dw_vip_setup</code> prints a list of all models, libraries, and examples, available in the currently-defined <code>\$DESIGNWARE_HOME</code> installation, and their respective versions.</p> <p>The command prints reports to STDOUT.</p>

Table 2-3 Setup Program Switch Descriptions (Continued)

Switch	Description
-h[elp]	Returns a list of valid <code>dw_vip_setup</code> switches and their correct syntax.
model	<p>The USB VIP models are as follows:</p> <ul style="list-style-type: none"> • <code>usb_agent_svt</code> • <code>usb_link_svt</code> • <code>usb_monitor_checker_svt</code> • <code>usb_physical_svt</code> • <code>usb_protocol_svt</code> • <code>usb_ssic_physical_svt</code> • <code>usb_subenv_svt</code> <p>The model argument defines the model or models that <code>dw_vip_setup</code> acts upon. This argument is not needed with the <code>-info</code> or <code>-help</code> switches. All switches that require the model argument may also use a model list.</p> <p>You may specify a version for each listed model using the <code>-version</code> option. If omitted, <code>dw_vip_setup</code> uses the latest version. The <code>-update</code> switch ignores the model-version information.</p>
-m[odel_list] <i>filename</i>	<p>The <code>-model_list</code> argument makes <code>dw_vip_setup</code> to use a user-specified file to define the list of models that the program acts on. The <code>model_list</code>, like the model argument, can contain the model-version information. Each line in the file contains the following:</p> <pre>model_name [-v version] -or- # Comments</pre>
-b/ridge	Updates the specified design directory to reference the current <code>DESIGNWARE_HOME</code> installation. All product versions contained in the design directory must also exist in the current <code>DESIGNWARE_HOME</code> installation.
-pa	<p>Enables the run scripts and Makefiles generated by <code>dw_vip_setup</code> to support PA. If this switch is enabled, and the testbench example produces FSDB files, PA will be launched and the FSDB files will be read at the end of the example execution.</p> <p>For run scripts, specify <code>-pa</code>.</p> <p>For Makefiles, specify <code>-pa = 1</code>.</p>
-waves	<p>Enables the run scripts and Makefiles generated by <code>dw_vip_setup</code> to support the <code>fsdb waves</code> option. To support this capability, the testbench example must generate an FSDB file when compiled with the WAVES Verilog macro set to <code>fsdb</code>, that is, <code>+define+WAVES=\"fsdb\"</code>. If a <code>.fsdb</code> file is generated by the example, the Verdi nWave viewer will be launched.</p> <p>For run scripts, specify <code>-waves fsdb</code>.</p> <p>For Makefiles, specify <code>WAVES=fsdb</code>.</p>
-doc	Creates a doc directory in the specified design directory which is populated with symbolic links to the <code>DESIGNWARE_HOME</code> installation for documents related to the given model or example being added or updated.

Table 2-3 Setup Program Switch Descriptions (Continued)

Switch	Description
-methodology <name>	When specified with -doc, only documents associated with the specified methodology name are added to the design directory. Valid methodology names include: OVM, RVM, UVM, VMM and VLOG.
-copy	When specified with -doc, documents are copied into the design directory, not linked.



The `dw_vip_setup` command treats all lines beginning with “#” as comments.

2.9 Installing and Setting Up More Than One VIP Protocol

All VIPs for a particular project must be set up in a single common directory once you execute the *.run file., you may have different projects. In this case, the projects can use their own VIP setup directory. However, all the VIPs used by that specific project must reside in a common directory.

The examples in this chapter refers to that directory as `design_dir`, but you can use any name. In this example, assume you will use the `usb_svt` and AXI VIP suites in the design. Your `$DESIGNWARE_HOME` contains both `usb_svt` and AXI VIPs. Primarily, install a `usb_svt` example in the `design_dir` directory. After the `usb_svt` example has been installed, the VIP suite must be set up in and located in the same `design_dir` directory as the `usb_svt` VIP. Use the following commands to perform the steps:

```
// First install the usb_svt intermediate UVM example:
% $DESIGNWARE_HOME/bin/dw_vip_setup -path design_dir -e
usb_svt/tb_usb_svt_uvm_intermediate_sys -svtb
// Add AXI to the same design_dir as the usb_svt:
% $DESIGNWARE_HOME/bin/dw_vip_setup -path design_dir -add axi_system_env_svt -svlog
```



By default, all of the VIPs use the latest installed version of SVT. Synopsys maintains backward compatibility with previous versions of SVT. As a result, you may mix and match models using previous versions of SVT.

2.9.1 Running the Example With +incdir+

In the current setup, you install the VIP under `DESIGNWARE_HOME` followed by creation of a design directory which contains the versioned VIP files.

With every newer version of the already installed VIP requires the design directory to be updated.

This results in:

- ❖ Consumption of additional disk space
- ❖ Increased complexity to apply patches

The new alternative approach of directly pulling in all the files from `DESIGNWARE_HOME` eliminates the need for design directory creation. VIP version control is now in the command line invocation. The following code snippet shows how to run the basic example from a script:

```
cd /examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
// To run the example using the generated run script with +incdir+
./run_usb_svt_uvm_basic_sys -verbose -incdir base_test vcsvlog
```

For example, the following compile log snippet shows the paths and defines set by the new flow to use VIP files right out of DESIGNWARE_HOME instead of design_dir.

```
vcs -l ./logs/compile.log -q -Mdir=./output/csdc
+define+DESIGNWARE_INCDIR= \
+define+SVT_LOADER_UTIL_ENABLE_DWHOME_INCDIRS \
+incdir+/vip/svt/usb_svt/sverilog/include \
-ntb_opts uvm -full64 -sverilog +define+UVM_PACKER_MAX_BYTES=16000
+define+UVM_PACKER_MAX_BYTES=1500000 \
+define+UVM_DISABLE_AUTO_ITEM_RECORDING -timescale=1ns/1ps +define+SVT_UVM_TECHNOLOGY
+define+SYNOPSIS_SV \
+incdir+<testbench_dir>/examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
. \
+incdir+<testbench_dir>/examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
../../env \
+incdir+<testbench_dir>/examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
../env \
+incdir+<testbench_dir>/examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
env \
+incdir+<testbench_dir>/examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
dut \
+incdir+<testbench_dir>/examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
hdl_interconnect \
+incdir+<testbench_dir>/examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
lib \
+incdir+<testbench_dir>/examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
tests \
-o ./output/simvcsvlog -f top_files -f hdl_files
```



Note

For VIPs with dependency, include the +incdir+ for each dependent VIP.

2.9.2 Getting Help on Example Run/make Scripts

You can get help on the generated make/run scripts in the following ways:

1. Invoke the run script with no switches, as in:

```
usage: run_usb_svt_uvm_basic_sys [-32] [-verbose] [-debug_opts] [-waves] [-clean] [-nobuild] [-buildonly] [-norun] [-pa] <scenario> <simulator>
```

where <scenario> is one of: test entry under tests directory, sans the ts. prefix and file extension

<simulator> is one of: vcsmxvlog mtivlog vcsvlog vcszsimvlog vcscvlog ncuvlog vcszebuvlog vcsmxpcvlog vcsvhdl vcsmxpipvlog ncmvlog vcspcvlog

- ◆ -32 forces 32-bit mode on 64-bit machines
- ◆ -incdir use DESIGNWARE_HOME include files instead of design directory
- ◆ -verbose enable verbose mode during compilation
- ◆ -debug_opts enable debug mode for VIP technologies that support this option
- ◆ -waves [fsdb|verdi|dve|dump] enables waves dump and optionally opens viewer (VCS only)
- ◆ -seed run simulation with specified seed value
- ◆ -clean clean simulator generated files

- ◆ `-nobuild` skip simulator compilation
- ◆ `-buildonly` exit after simulator build
- ◆ `-norun` only echo commands (do not execute)
- ◆ `-pa` invoke Verdi after execution

2. Invoke the make file with help switch as in:

Usage: `gmake USE_SIMULATOR=<simulator> [VERBOSE=1] [DEBUG_OPTS=1] [SEED=<value>]
[FORCE_32BIT=1] [WAVES=fsdb|verdi|dve|dump] [NOBUILD=1] [BUILDONLY=1] [PA=1] [<scenario>
...]`

Valid simulators are: `vcsmxvlog mtivlog vcsvlog vcszsimvlog vcsscvlog ncvlog
vcszebuvlog vcsmxpcvlog vcsvhdl vcsmxpipvlog ncmvlog vcspcvlog`

Valid scenarios are: test entry under tests directory, sans the `ts.` prefix and file extension



Note

You must have PA installed if you use the `-pa` or `PA=1` switches.

2.9.3 Updating an Existing Model

To add an update an existing model, perform the following steps:

1. Install the model to the same location as your other VIPs by setting the `$DESIGNWARE_HOME` environment variable.
2. Issue the following command using `design_dir` as the location for your project directory.

```
% $DESIGNWARE_HOME/bin/dw_vip_setup -path /tmp/design_dir  
-add <model-name>_svt -svlog
```

3. You can also update your `design_dir` by specifying the version number of the model.

```
% dw_vip_setup -path design_dir -add <model-name>_svt -v 3.50a model_vmt -v 3.50a
```


3

Design Directory Maintenance

This chapter leads you through design directory maintenance.

The Design Directory Maintenance chapter discusses the following topics:

- ❖ [Design Directory](#)
- ❖ [Usage Examples for dw_vip_setup Utility](#)
- ❖ [Include and Import Model Files into Your Testbench](#)
- ❖ [Compile and Run Time Options](#)
- ❖ [Removing VIP Models from a Design Directory](#)
- ❖ [Installing a VIP Example](#)

3.1 Design Directory


A *design directory* contains a version of the VIP that is set up and ready for use in a testbench. You use the `dw_vip_setup` utility to create design directories. For the full description of `dw_vip_setup`, see [The dw_vip_setup Command](#).

A design directory gives you control over the version of VIP in your testbench because it is isolated from the `DESIGNWARE_HOME` installation. When you want, you can use `dw_vip_setup` to update the VIP in your design directory. [Figure 3-1](#) shows this process and the contents of a design directory.



Note

If you move a design directory, the references in your testbenches to the include files will need to be revised to point to the new location. Also, any simulation scripts in the examples directory will need to be recreated.

Figure 3-1 Design Directory Created by dw_vip_setup**Table 3-1 Design Directory**

Directory	Description
examples	Each VIP includes example testbenches. The dw_vip_setup utility adds them in this directory, along with a script for simulation. If an example testbench is specified on the command line, this directory contains all files required for model, suite, and system testbenches.
include	Language-specific include files that contain critical information for Synopsys Discovery models. This directory is specified in simulator command lines.
src	Synopsys Discovery-specific include files (not used by all Synopsys Discovery). This directory may be specified in simulator command lines.
.dw_vip.cfg	A list of all Synopsys Discovery models being used in the testbench. This file is created and used by dw_vip_setup. When multiple different VIPs are added to the same design directory, the new model names are appended in this file.

**Note**

Do not modify this file because dw_vip_setup depends on the original content.

3.2 Usage Examples for dw_vip_setup Utility

This section provides some examples to help you run dw_vip_setup for some common tasks.

3.2.1 Set Up a New VIP

After you have installed the VIP, you must set up the VIP for project and testbench use. All VC VIP suites contain various components such as transceivers, masters, slaves, and monitors depending on the protocol. The setup process gathers together all the required component files you need to incorporate into your testbench and simulation runs.

You have the choice to set up all of them, or only specific ones. For example, the USB VIP contains the following components.

In UVM the USB VIP contains the following component:

- ❖ `usb_agent_svt`: This is the name used for the entire set of sub-models.
- ❖ `usb_protocol_svt`: Supports protocol layer of USB protocol
- ❖ `usb_link_svt`: Supports link layer of USB protocol
- ❖ `usb_physical_svt`: Supports physical layer of USB protocol
- ❖ `usb_ssic_physical_svt`: Supports SSIC physical layer of USB protocol

You can set up either an individual component, or the entire set of components within one protocol suite. Use the Synopsys provided tool called `dw_vip_setup` for these tasks. It resides in `$DESIGNWARE_HOME/bin`. To get help on `dw_vip_setup`, invoke the following:

```
% $DESIGNWARE_HOME/bin/dw_vip_setup --help
```

The following command adds an model `<model_svt>` to the directory `design_dir`.

```
$DESIGNWARE_HOME/bin/dw_vip_setup -path /tmp/design_dir -add svt_usb_agent_svt
```

This command sets up all the required files in `/tmp/design_dir`. The utility `dw_vip_setup` creates three directories under `design_dir` which contain all the necessary model files. Files for every VIP are included in these three directories.

- ❖ **examples.** Each VIP includes example testbenches. The `dw_vip_setup` utility adds them in this directory, along with a script for simulation. If an example testbench is specified on the command line, this directory contains all files required for model, suite, and example testbenches.
- ❖ **include.** Language-specific include files that contain critical information for Synopsys Discovery models. This directory `include/sverilog` is specified in simulator commands to locate model files.
- ❖ **src.** Synopsys-specific include files This directory `src/sverilog/vcs` must be included in the simulator command to locate model files.



Note

Some components are top level and will setup the entire suite. You have the choice to set up the entire suite, or just one component such as a monitor



Attention

There must be only one `design_dir` installation per simulation, regardless of the number of Synopsys Verification and Implementation IPs you have in your project. It is recommended not to create this directory in `$DESIGNWARE_HOME`.

3.2.2 Installing and Setting Up More than One VIP Protocol Suite

All VIPs for a particular project must be set up in a single common directory once you execute the `*.run` file. You may have different projects. In this case, the projects can use their own VIP setup directory. However, all the VIPs used by that specific project must reside in a common directory.

The examples in this chapter call that directory `design_dir`, but you can use any name. In this example, assume you have the AXI suite set up in the `design_dir` directory. In addition to the AXI VIP, you require the Ethernet and USB VIP suites.

First, follow the previous instructions on downloading and installing the Ethernet VIP and USB suites.

Once installed, the Ethernet and USB suites must be set up in and located in the same `design_dir` location as AMBA. Use the following commands:

```
// First install AXI.
%unix> $DESIGNWARE_HOME/bin/dw_vip_setup -path /tmp/design_dir
-add axi_system_env_svt -svlog

//Add Ethernet to the same design_dir as AXI.
%unix> $DESIGNWARE_HOME/bin/dw_vip_setup -path /tmp/design_dir
-add ethernet_system_env_svt -svlog

// Add USB to the same design_dir as AMBA and Ethernet
%unix> $DESIGNWARE_HOME/bin/dw_vip_setup -path /tmp/design_dir
-add usb_agent_svt (UVM and OVM) or usb_subenv_svt (VMM) -svlog
```

To specify other model names, consult the VIP documentation.



Note By default, all of the VIPs use the latest installed version of SVT. Synopsys maintains backward compatibility with previous versions of SVT. As a result, you may mix and match models using previous versions of SVT.

3.2.3 Updating an Existing Model

To add an update to an existing model, do the following:

1. Install the model to the same location as your other VIPs by setting the `$DESIGNWARE_HOME` environment variable.
2. Issue the following command using `design_dir` as the location for your project directory.

```
$DESIGNWARE_HOME/bin/dw_vip_setup -path /tmp/design_dir -add svt_usb_agent_svt
```

3. You can also update your `design_dir` by specifying the version number of the model.

```
$DESIGNWARE_HOME/bin/dw_vip_setup -path /tmp/design_dir -add svt_usb_agent_svt -v N-2017.12-2
```

3.3 Include and Import Model Files into Your Testbench

After you set up the models, you must include and import various files into your top testbench files to use the VIP. Including and importing model files into your testbench in UVM methodology is as follows:

3.3.1 UVM

Following is a code list of the includes and imports for USB:

```
/* Include USB VIP Interface */
`include "svt_usb_if.uvm.svi"

/* Include USB SVT UVM package */
`include "svt_usb.uvm.pkg"

/** Import UVM Package */
```

```
import uvm_pkg::*;
`include "uvm_macros.svh"

/** Import the SVT UVM Package */
import svt_uvm_pkg::*;

/** Import the USB UVM Package */
import svt_usb_uvm_pkg::*;
```

3.4 Compile and Run Time Options

Every Synopsys provided example has ASCII files containing compile and run time options. The examples for the model are located in:

```
$DESIGNWARE_HOME/vip/svt/usb_svt/latest/examples/sverilog/example_testbench
```

The files containing the options are:

- ❖ `sim_build_options` (also `vcs_build_options`)
- ❖ `sim_run_options` (also `vcs_run_options`)

3.4.1 UVM

These files contain both optional and required switches. For USB (UVM), following are the contents of each file, listing optional and required switches:

`vcs_build_options`

- ❖ Required: `+define+UVM_PACKER_MAX_BYTES=24000`
- ❖ Required: `+define+UVM_DISABLE_AUTO_ITEM_RECORDING`
- ❖ Optional: `-timescale=1ps`
- ❖ Optional: `+define+SVT_UVM_INCLUDE_USER_DEFINES`

`vcs_run_options`

- ❖ Required: `+UVM_TESTNAME=$scenario`



Note

`scenario` is the UVM test name you pass to VCS

3.5 Removing VIP Models from a Design Directory

This example shows how to remove all listed models in the design directory at `/d/test2/daily` using the model list in the file `del_list` in your home directory. The `dw_vip_setup` program command line is:

```
% $DESIGNWARE_HOME/bin/dw_vip_setup -p /d/test2 -remove usb_agent_svt
```

The models in the `del_list` file are removed, but object files and include files are not.

3.6 Installing a VIP Example

To install the VIP by extracting it from the .run file, perform the following steps:

1. Open a UNIX terminal and browse to the directory, where the .run file resides.
2. Change the permissions for the .run file to executable using the following command:
`vip_usb_svt_N-2017.12.run`
where, `vip_usb_svt_N-2017.12.run` is the name of the .run file you downloaded from SolvNetPlus.
3. Create a directory where you want to extract the VIP present in the .run file. This directory is named as `DESIGNWARE_HOME`. For example, `mkdir dw_home`
4. Set the `DESIGNWARE_HOME` environment variable to a path where you want to install the VIP. For this use the following command:

```
setenv DESIGNWARE_HOME <dw_home path>
```

For example,

```
setenv DESIGNWARE_HOME  
/<dw path>/dw_home
```

5. Execute the .run file by invoking its name and by specifying the directory. For this use the following command:

```
vip_usb_svt_N-2017.12.run --dw_home <path>
```

The command extracts the VIP from the .run file and creates the following directories:

- ◆ bin
- ◆ vip

3.6.1 Running a VIP Example

To run a VIP example, perform the following steps:

1. Create a directory in which you want to extract the VIP examples.
For example, `mkdir design_dir`
2. Set your `VCS_HOME` environment variable using the following command:
3. Set your `DISPLAY` environment variable using the following command:
`setenv DISPLAY <machine's $DISPLAY value>`
For example, `setenv DISPLAY amp3:119.0`
4. Go to the `design_dir` directory and extract the VIP examples using the following command:
`$DESIGNWARE_HOME /bin/dw_vip_setup -path <path of design_dir> -example <path of example> -svtb`
For example,
`$DESIGNWARE_HOME /bin/dw_vip_setup -path
/<path>/design_dir -example usb_svt/tb_usb_svt_uvm_basic_sys -svtb`
5. The examples are present in the examples directory. Go in that
For example,

```
cd examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
```

6. You can run test, using any one of the following method:

a. Using makefile

For example, to run the `ts.basic_ss_serial.sv`, use the following command:

```
gmake USE_SIMULATOR=vcsvlog basic_ss_serial WAVES=1
```



Note

Invoke `gmake --help` to view more options

b. Using the sim script

For example, to run the `ts.basic_ss_serial.sv`, use the following command:

```
./run_usb_svt_uvm_basic_sys basic_ss_serial vcsvlog
```



Note

Invoke `./run_usb_svt_uvm_basic_sys -help` to view more options.

4

Overview of the USB VIP

This chapter describes the data objects that support the higher structures that comprise the USB VIP. For more information on description of attributes and properties of the objects mentioned in this chapter, see the Refer to the Class Reference HTML. This chapter describes the HTML Class Reference at various abstraction level that are part of UVM testbench for USB VIP. Definitions of these class references includes description of attributes and properties of class objects

The Overview of the VIP chapter discusses the following topics:

- ❖ [Introduction to UVM](#)
- ❖ [USB VIP in an UVM Environment](#)

4.1 Introduction to UVM

UVM (Universal Verification Methodology) is high level abstract based upon System Verilog which follows Object Oriented approach.. It provides a blueprint for building testbenches using a constrained random verification. The resulting structure also supports directed testing.


The USB VIP for UVM described in this document provides class libraries that verify features of the USB protocol. The VIP provides a USB UVM agent that contains stacked components that are compatible for use with SystemVerilog-Compliant UVM based testbenches. Agent supports all functionality normally associated with active UVM components, including the creation of transactions by built-in sequencers, checking and reporting the protocol correctness, transaction logging, Symbol logging and functional coverage.

After instantiating the agents, you can select and combine these agents with different mode setups to create an environment that verifies USB features in the DUT.

4.2 USB VIP in an UVM Environment

Figure 4-1 shows how USB VIP is used in the UVM based Testbench. In the layered approach that is typical for UVM, the VIP (purple) fits into the lower levels, which allows you to focus on higher levels of abstraction.

Figure 4-1 USB VIP in Layered Testbench Architecture



4.2.1 Base Classes

In an object-oriented programming environment, a set of base classes form the foundation for the entire system. Base classes provide common functionality and structure. The SystemVerilog base classes are specifically designed for the UVM approach to verification. They provide common functionality and structure needed for simulation (such as reporting) and they support any sort of verification function.

The USB VIP classes are extended from these base classes, providing an actual implementation and demonstrating that UVM is not simply a set of guidelines and recommendations. So, instead of writing your own reporting routine, you can reuse the UVM report class. Inheritance, extension, and polymorphism facilitate customization opportunities.

Important UVM base classes used by the USB VIP include:

- ❖ `uvm_agent`
- ❖ `uvm_component`
- ❖ `uvm_object`
- ❖ `uvm_callback`
- ❖ `uvm_sequencer`

4.2.2 UVM Components

Objects derived from `uvm_component` are objects in a UVM compliant verification environment. The testbench and stack layers exchange transactions through `uvm_component` in three distinct ways:

❖ Sequencer Ports

- ◆ The sequencers and drivers are connected through TLM ports. Sequencers place transactions that they create in input ports.
- ◆ The sequencer includes an 'implementation' of a pull port which it 'exports' for connection so that `sequence_item_pull_ports` can connect to it. The USB components and drivers have `sequence_item_pull_ports` which are connected to the sequencer provided exports.

❖ Callbacks

- ◆ Before a component 'gets' something from a data source it does a 'get' callback. On the opposite side, before a component 'puts' something to a data sink, it does a 'put' callback.

For example, a 'get' operation can be:

- ❖ get data from a sequence item pull port
- ❖ get recognition of data off the bus
- ❖ get or peek from a lower level component

For example, a 'put' operation can be:

- ❖ get/peek export to a higher level component
- ❖ sequence execution that results in sequence items going to lower level components
- ◆ Callbacks are defined in a callback facade class (associated with each sequencer), and accessed by registering (with the associated component) an instance of a class extended from that facade class.
- ◆ Each `uvm_component` supports additional callbacks to access to data at internal dataflow points. Refer to the HTML documentation for a complete callback list.

❖ UVM Events

- ◆ Events are based on the `uvm_event` class. Some `uvm_component` signal "significant events" through UVM events and include transactions as `uvm_data` objects with these events. Testbenches can be configured to wait for `uvm_event` instances, making a call to the `uvm_component`'s UVM event service instance. Then you can retrieve data by making a call to the `get_trigger_data()` method on the UVM event.

UVM components associate coverage (cov) callbacks with ports, in addition to 'get' and 'put' callbacks. These callbacks connect functional coverage to these ports. Coverage callbacks are called after corresponding get and put methods if none of the methods set 'drop_it' to 1.

4.2.3 USB VIP Objects

The USB VIP defines several classes designed for a UVM environment. This section introduces the major USB VIP objects.

As mentioned earlier, the USB VIP classes extend base classes to handle specific needs of the protocol and provide predefined constraints. The predefined constraints can be used “as is” to produce a wide range of stimulus, or extended to create specific test conditions. For information about constraints, see [Constraints](#).

An object and its constraints are referred to as a factory object, or factory when used to control the production of, or randomization of a transaction data object. Sequencers which create sequences use factories to create streams of randomized objects. Sequencers are typically responsible for creating sequence items based on factories.

The remainder of this section describes the following USB VIP objects:

- ❖ [Configuration Objects](#)
- ❖ [Sequence Item Data Objects](#)
- ❖ [Status Objects](#)
- ❖ [Exception and Exception List Objects](#)
- ❖ [Callbacks](#)

4.2.3.1 Configuration Objects

The configuration objects specify attributes and support testbench capabilities, such as randomization and constraints. Configuration objects apply to all appropriate `uvm_components` and `uvm_objects` in the stack.

The configuration data objects are extended from the `svt_configuration` class, which is extended from the `uvm_sequence_item` base class. These objects implement all of the methods specified by UVM for the `uvm_sequence_item` class. The testbench can retrieve the current configuration of the USB agent through the `get_cfg()` method.

Configuration data objects convey the agent’s configuration. This includes:

- ❖ Static Configuration include those protocol and VIP specific parameters, such as bus width which are generally configured. Static settings are defined only for VIP initially before simulation is run. Data is sent to the `uvm_components` anytime prior to the start – either between the constructor call and the start or between a hard reset and the start.
- ❖ Dynamic information that defines VIP parameters, such as timeout values that can be changed at any time during simulation. The components use the updated values set by the user through testcases.

The user passes the configuration object to the agent. The agent then disburses it to the components. If the user wants to get the `cfg` object, they should access it through the agent. For anything that is “stack wide”, user actions should be aimed at the agent.

Configuration objects are controlled by direct access to their data properties or through randomization. Data properties that control monitoring levels, such as timeouts and visibility of messages, are normally not randomizable and must be set manually. Default randomization allows for a complete randomization of the configuration, including static as well as dynamic information.

You can use the method “function `int svt_usb_configuration::static_rand_mode(bit on_off)`” to turn static configuration parameter randomization on/off as a block.

In UVM the user sets up the configuration, and then provides it to the `config_db` for later access by the agent. This is done in the test or env ‘`build_phase`’ method, prior to the construction of the agent. The main agent

construction occurs during the `build_phase` when the agent retrieves the configuration and any other pertinent support information from the `config_db`.

After constructing the component, you can change the configuration through the `reconfigure()` method, which takes one parameter: the configuration object.

The USB VIP defines the following configuration classes:

- ❖ **Agent configuration** (*svt_usb_agent_configuration*): This class provides settings for the basic testbench capabilities: for example, whether tracing is enabled, or whether exceptions are enabled. These basic testbench capabilities are not randomized, and are controlled via basic 'enable' flags and more complex enumerated choices. The agent configuration is also extended from the basic usb configuration (*svt_usb_configuration*) which includes the basic configuration information for the protocol. It also contains the host, device, etc., configurations.
- ❖ **Device configuration** (*svt_usb_device_configuration*): This class provides device information for an individual USB device. This object contains information normally conveyed in the USB specified Device, Configuration, and Interface descriptors, collapsed into a single object for use by the protocol layer and the external testbench.
- ❖ **Host configuration** (*svt_usb_host_configuration*): The 'prot' component uses the information to support its breaking of transfers into individual transactions.
- ❖ **Endpoint configuration** (*svt_usb_endpoint_configuration*): This *uvm_data* class provides endpoint information for an individual USB endpoint. The information that this class provides can be categorized as being made up of endpoint descriptors and dynamic information.
- ❖ **Ustream configuration** (*svt_usb_ustream_resource_configuration*): This *uvm_data* class contains information regarding a 'USB SS stream resource'.

Note the following:

- ❖ Configuration data objects are extended from the *svt_configuration* class, which is extended from the *uvm_sequence_item* base class. These objects implement all of the methods specified for the *uvm_sequence_item* class.
- ❖ The testbench can retrieve the current configuration via the `get_cfg()` method.

For more information, see the Class Reference.

4.2.3.2 Sequence Item Data Objects

The transaction data objects are extended from the *svt_sequence_item* class, which is extended from the *uvm_sequence_item* base class. These objects implement all of the methods specified by UVM for the *uvm_sequence_item* class.

Pre-defined sequence and sequencer classes exist for different UVM sequence item objects. For example *svt_usb_data_sequencer* is a valid object type available to the testbench designer relative to the *svt_usb_data* class.

uvm_sequence_item data objects define a unit of bus protocol information that is passed across the bus. The attributes of data objects are public and are accessed directly for setting and getting values. Most sequence item attributes can be randomized. The sequence item data object can represent the desired activity to be simulated on the bus, or the actual bus activity that was monitored. A protocol may have several types of sequence item data objects, such as for different protocol layers.

uvm_sequence_time data objects store data content and protocol execution information for USB connection transactions in terms of bit-level and timing details of the transactions. USB transaction data objects are used to:

- ❖ Generate random scenario stimulus
- ❖ Report observed transactions from receiver uvm_components
- ❖ Generate random responses to stack requests
- ❖ Collect functional coverage statistics
- ❖ Support error injection

Class properties are public and accessed directly to set and read values. Sequence item data objects support randomization for varying stimulus and to provide valid ranges and reasonable constraints.

- ❖ *valid_ranges* constraints limit generated values to those acceptable to the components. These constraints ensure basic VIP operation and should never be disabled.
- ❖ *reasonable_** constraints, which can be disabled individually or as a block, limit the simulation by:
 - ◆ enforcing the protocol. These constraints are typically enabled unless errors are being injected into the simulation.
 - ◆ setting simulation boundaries. Disabling these constraints may slow the simulation and introduce system memory issues.

The VIP supports extending sequence item data classes for customizing randomization constraints. This allows you to disable some *reasonable_** constraints and replace them with constraints appropriate to your system. Individual *reasonable_** constraints map to independent fields, each of which can be disabled. The class provides the **reasonable_constraint_mode()** method to enable or disable blocks of *reasonable_** constraints.

The USB VIP defines the following classes:

- ❖ **Data** (*svt_usb_data*): These objects represent the information required to send one USB data byte. This class includes support for physical layer transformations.
- ❖ **Detected Object** (*svt_usb_detected_object*): This class represents objects detected by the class *svt_usb_object_detect*. When the *svt_usb_object_detect* class detects an object, it constructs the appropriate object and generates a corresponding notify with the new object as the data associated with the *uvm_event*.
- ❖ **Link Command** (*svt_usb_link_command*): This class represents a USB link command
- ❖ **Link Service** (*svt_usb_link_service*): These objects represent USB link service commands requested by the link service commands that are put into the link component.
- ❖ **Packet** (*svt_usb_packet*): These objects represent USB packet data units that flow between the USB Protocol layer and the USB Link layer. Objects represent either USB SS or USB 2.0 packets.
- ❖ **Physical Service** (*svt_usb_physical_service*): These objects represent USB physical service commands.
- ❖ **Protocol Service** (*svt_usb_protocol_service*): These objects represent protocol service commands that flow between the Protocol layer and the testbench. Commands that Protocol Service objects support include:

LMP Transactions – Link Management Packet (LMP) transactions manage USB links.

LPM Transactions – Link Power Management (LPM) transactions manage the USB 2.0 link power state. The Host Protocol component receives Protocol Service object containing power management transaction properties from the testbench.

SOF Commands – Start Of Frame (SOF) commands allow the testbench to control the automatic production of SOF packets by the host. Commands include turning SOF packets on and off, and setting and getting the current SOF frame number.

- ❖ **Symbol Set** (*svt_usb_symbol_set*): This class represents objects detected by *svt_usb_object_detect* that are represented by an array of symbols (*svt_usb_data*) represented in USB Specification as Ordered sets.
- ❖ **Transaction** (*svt_usb_transaction*): These objects represent USB transaction data units that the Protocol layer processes.

The testbench creates, randomizes, or sets transfer object attributes to define USB transfers. The testbench sends transfer objects to the VIP USB Protocol through the Transfer In port. The Protocol *uvm_component* controls USB bus activity using the list of transactions. Alternatively, the testbench can leave the list of data objects empty and the protocol *uvm_component* will create the transactions needed to implement the transfer.

The same transfer data object is used by the VIP USB Protocol layer to receive inbound transactions from packet input ports. The testbench receives these transactions through callbacks and *uvm_events* issued by the VIP USB Protocol. Remotely initiated transfers are also provided to the testbench through the transfer output ports

- ❖ **Transfer** (*svt_usb_transfer*): These objects represent USB transfer data units that flow between the USB Protocol layer and the testbench.

4.2.3.3 Status Objects

Status classes define status data descriptor objects. The configuration status data objects are extended from the *svt_sequence_item* class, which is extended from the *uvm_sequence_item* base class. These objects implement all of the methods specified by UVM for the *uvm_sequence_item* class. The testbench can retrieve the current status as the *shared_status* object is a public member of the agent. As a result, your testbench can access it directly.

The USB VIP defines the following status classes:

- ❖ **Component** (*svt_usb_status*): This class provides a common location for status information coming from the different components in the USB component stack. This status information comes in two forms – data and events (status objects use UVM events). The data members represent the current status as defined by the component implementing and updating the status information. The notifies are used to indicate a change in status, as defined by the component responsible for indicating the *uvm_event*.
- ❖ **Device** (*svt_usb_device_status*): This class contains status information regarding a USB device either being modeled by or communicating with the USB VIP.
- ❖ **Host** (*svt_usb_host_status*): This class contains status information regarding a USB host either being modeled by or communicating with the USB VIP.
- ❖ **Endpoint** (*svt_usb_endpoint_status*): This class contains information regarding a USB endpoint. In the USB protocol component there will be one 'sub-component' for each endpoint defined in the *svt_usb_configuration* object supplied to the USB VIP. This class makes available the endpoint specific status information.
- ❖ **Ustream Resource** (*svt_usb_ustream_resource_status*): This class contains information regarding a USB SS stream resource. In the USB protocol component there will be one sub-component for each instance of *svt_usb_ustream_resource_status* if the endpoint supports streams. That sub-component indicates the USB stream IDs it is assigned to support.

4.2.3.4 Exception and Exception List Objects

Exception objects represent injected errors or protocol variations. Each sequence data object has an exception list, which is an object that serves as an array of exception objects that may apply.

The USB VIP defines the following exception classes:

- ❖ **Data** (*svt_usb_data_exception, svt_usb_data_exception_list*): This class is the foundation exception descriptor for USB data transactions. The exceptions are errors that may be introduced into transactions, for the purpose of testing how the connected port of a DUT responds.
- ❖ **Link Command** (*svt_usb_link_command_exception, svt_usb_link_command_exception_list*): This class is the foundation exception descriptor for USB link command transaction. The exceptions are errors that may be introduced into transaction, for the purpose of testing how the connected port of a DUT responds.
- ❖ **Packet** (*svt_usb_packet_exception, svt_usb_packet_exception_list*): This class is the foundation exception descriptor for USB packet transaction. For a packet to be transmitted the class represents errors that are introduced into transactions, for the purpose of testing how a DUT responds. For a packet that is received the class represents the ERROR seen on the bus.
- ❖ **Symbol set** (*svt_usb_symbol_set_exception, svt_usb_symbol_set_exception_list*): This class is the foundation exception descriptor for USB symbol_set transaction. For a symbol_set to be transmitted the class represents errors that are introduced into transactions, for the purpose of testing how a DUT responds.
- ❖ **Transaction** (*svt_usb_transaction_exception, svt_usb_transaction_exception_list*): This class is the foundation exception descriptor for the USB transaction class. The exceptions are errors that may be introduced into transaction, for the purpose of testing how the DUT responds.
- ❖ **Transfer** (*svt_usb_transfer_exception, svt_usb_transfer_exception_list*): This class is the foundation exception descriptor for USB transaction class. The exceptions are errors that may be introduced into transaction, for the purpose of testing how the DUT responds.

4.2.3.5 Callbacks

Callbacks are an access mechanism that enable the insertion of user-defined code and allow access to objects for scoreboarding and functional coverage. Each uvm_component is associated with a class that contains a set of callback methods. These methods are called as part of the normal flow of procedural code. There are a few differences between callbacks and other methods that set them apart.

- ❖ The *svt_usb_protocol_callback* class is extended from the *svt_xactor_callbacks* base class, which is extended from the *uvm_callback* class. These objects implement all of the methods specified by UVM for the *uvm_callback* class. Callbacks are virtual methods with no code initially so they do not provide any functionality unless they are extended. The exception to this rule is that some of the callback methods for functional coverage already contain a default implementation of a coverage model.
- ❖ The callback class is accessible to users so the class can be extended and user code inserted, potentially including testbench-specific extensions of the default callback methods, and testbench-specific variables and/or methods used to control whatever behavior the testbench is using the callbacks to support.
- ❖ Callbacks are called within the sequential flow at places where external access would be useful. In addition, the arguments to the methods include references to relevant data objects. For example, just before a sequencer puts data object into an output port is a good place to sample for functional coverage since the object reflects the activity that just happened on the pins. A callback at this point with an argument referencing the sequence data object allows this exact scenario.

- ❖ There is no need to invoke callback methods for callbacks that are not extended. To avoid a loss of performance, callbacks are not executed by default. You add a callback in the following manner.

```
uvm_callbacks#(svt_usb_protocol)::add(my_agent.prot,my_20_dev_resp_cb);
```

USB VIP uses callbacks in four main applications:

- ❖ Access for functional coverage
- ❖ Access for scoreboarding
- ❖ Insertion of user-defined code
- ❖ Message processing

The VIP defines the following types of callbacks:

- ❖ **post-port get callbacks:** called after a transaction is pulled from the input port; provided with a handle to the transaction gotten from the port
- ❖ **pre-port put callbacks:** called prior to putting a transaction out on output port, provided with a handle to the transaction being put
- ❖ **traffic or dataflow event callbacks:** called in response to critical traffic or dataflow events, providing a mechanism for responding to the event or introducing errors into the event processing.

The following are the callback classes defined by the VIP:

- ❖ `svt_usb_link_callbacks`
- ❖ `svt_usb_physical_callbacks`
- ❖ `svt_usb_protocol_callbacks`

For more information, see Class Reference.

4.2.4 Interfaces and Modports

SystemVerilog models signal connections using interfaces and modports. Interfaces define the set of signals which make up a port connection. Modports define logical connections supported by the port.

USB VIP Physical components communicate with USB ports through modports. Modports provide a logical connection between components and the testbench. This connection is bound in after the interface is instantiated and other components are connected to its other modports.

USB VIP Physical components accept the necessary modports through their constructors. Components use modports for connecting to USB ports. Optional debug modports provide diagnostic information.

The following are the interfaces that the USB VIP includes:

- ❖ **PIPE Interface <3 :** This interface (*svt_usb_pipe3_if*) declares signals included in a USB PIPE Interface <3 connection as defined by the PIPE Interface <3 Specification. The PIPE Interface <3 interface declares clocking blocks that define clock synchronization and directionality of interface signals used by the USB VIP's Physical component, and declares modports that define logical port connections.
- ❖ **USB SS Serial Interface:** This interface (*svt_usb_ss_serial_if*) declares signals included in a USB SS Serial connection, as defined by the USB Specification. The USB SS Serial Interface declares clocking blocks that define clock synchronization and directionality of interface signals used by the USB VIP's Physical component, and declares modports that define logical port connections.

- ❖ **USB 2.0 Serial Interface:** This interface (*svt_usb_20_serial_if*) declares signals included in a USB 2.0 serial connection that support HS, FS, and LS communication, as defined by the USB Specification. The USB 2.0 Serial Interface declares 'clocking blocks' that define clock synchronization and directionality of interface signals used by the USB VIP's Physical component, and declares modports that define logical port connections.
- ❖ **USB Interface:** This interface (*svt_usb_if*) declares all of the signals that by the USB Specifications define as being included in a USB Tx/Rx connection. The USB Interface consists of the PIPE Interface <3 Interface, USB SS Serial Interface, and USB 2.0 Serial Interface as sub-interfaces.

**Attention**

In UVM the *svt_usb_if* interface comes from the *svt_usb_if.uvm.svi* (as opposed to *svt_usb_if.svi*) file. This ensures that you obtain the correct interface: one which does not have parameters.

Note that this is only for the top level interface.

- ❖ **USB On-The-Go (OTG) Interface:** This interface (*svt_usb_otg_if*) includes signals that support the modeling of the OTG functionality. It includes modport definitions needed to provide the logical connection for various interface connections (such as the MAC to PHY connection).

For more information, see the USB SVT - Interfaces Reference page in the HTML Class Reference.

4.2.5 Constraints

4.2.5.1 Description

USB VIP uses objects with constraints for transactions, configurations, and exceptions. Tests in a UVM flow are primarily defined by constraints. The constraints define the range of randomized values that are used to create each object during the simulation.


Classes that provide random attributes allow you to constrain the contents of the resulting object. When you call the *randomize()* method, which is a built-in method, all random attributes are randomized using all constraints that are enabled.

Constraint randomization is sometimes misunderstood and seen as a process whereby the simulation engine takes the control of class members away from the user. In fact, the opposite is true. Randomization is an additional way for the user to assign class members and there are several ways to control the process. The following techniques apply when working with randomization:

- ❖ Randomization only occurs when an object's *randomize()* method is called, and it is completely up to the test code when, or even if, this occurs.
- ❖ Constraints form a rule set to follow when randomization is performed. By controlling the constraints, the testbench has influence over the outcome. Direct control can be exerted by constraining a member to a single value. Constraints can also be enabled or disabled.
- ❖ Each rand member has a rand mode that can be turned ON or OFF, giving individual control of what is randomized.
- ❖ A user can assign a member to a value at any time. Randomization does not affect the other methods of assigning class members.

The following diagram shows the scope of the constraints that are part of all USB VIP.

Figure 4-2 Constraints: Valid Ranges, Reasonable, and User-Defined



- ❖ Valid range constraints:
 - ◆ Provided with USB VIP
 - ◆ Keep values within a range that the components can handle
 - ◆ Are not tied to protocol limits
 - ◆ On by default, and should not be turned off or modified
- ❖ Reasonable constraints:
 - ◆ Provided with USB VIP
 - ◆ Keep values within protocol limits (typically) to generate worthwhile traffic
 - ◆ In some cases, keep simulations to a reasonable length and size
 - ◆ Defined to be “reasonable” by Synopsys (user can override)
 - ◆ May result in conditions that are a subset of the protocol
 - ◆ On by default and can be turned off or modified (user should review these constraints)
- ❖ User-defined constraints:
 - ◆ Provide a way for you to define specific tests
 - ◆ Constraints that lie outside of the valid ranges are not included during randomization

All constraints that are enabled are included in the simulation. The constraint solver resolves any conflicts.

4.2.5.2 Implementation

The following two methods implement constraints:

- ❖ Add an extension of a pre-defined external constraint block.

Most VIP data classes include pre-defined, but empty, external constraint blocks. This mechanism allows a user to add constraints to any and all instances or uses of a class by adding an implementation to this constraint block anywhere in the test code outside of a structure.

Example:

```
svt_usb_transfer::test_constraints1 { payload_intended_byte_count <= 4096; }
```

The constraint ensures that no transfers larger than 4K bytes are produced by any transfer randomization in the testbench.

If adding constraints to any and all instances/usages of a class meets the needs of the test, this approach is very quick and easy to implement.

- ❖ Declare a class that extends the VIP's data class, add new constraint blocks to the extended class, and replace a specific VIP factory instance with an instance of the extended class (created by the testbench or testcase).

Example (this code might be in a testcase)

```
class my_transfer extends svt_usb_transfer;
    constraint my_constraint { payload_intended_byte_count <= 4096; }
endclass;
my_class my_randomized_transfer_response = new();

dev_agent.prot.randomized_usb_ss_transfer_response =
my_randomized_transfer_response;
```

A constraint is added to a class extension that is used only to replace the VIP USB Device agent's protocol layer transfer response factory. This constraint causes the VIP Device to always create transfers with 4K data bytes or less. Other instances/usages of the svt_usb_transfer data class will be unaffected by this constraint.

4.2.6 Factories

The object that is provided to a sequencer is referred to as a factory, or factory object. It is a blueprint for randomization and serves as the template for the generated objects. A sequencer uses the factory to create streams of randomized transactions. Also, USB VIP components create factory objects for output ports so user-defined extensions to a transaction class can be handled for scoreboarding.


In UVM factories for the user sequencers as well as for VIP components should all go through the uvm_object_registry. Use set_type_override and set_inst_override to establish factories. The sequences/sequencers/components will then 'create' objects based on these registered factories.

There are two situations that require factories:

- ❖ Provide a mechanism for creating a template containing user constraints. During randomization, to give the user control over constraints and other objects
The nomenclature for this is 'randomized object'; these variables are prefixed with the 'randomized_' string.
- ❖ Constructing an transaction that is loaded and handed to the user without any randomization.
These objects are designated by the term 'factory' as a suffix – usb_ss_packet_out_port_factory.

Figure 4-3 illustrates how a factory object works with a sequence and a USB VIP component.

Figure 4-3 Factories with USB VIP



When using USB VIP, the factory object is typically a sequence. In Figure 4-3, the code excerpt extends a USB VIP sequence item class and then establishes two instances to use as factory objects—one for the sequence and one for the component. Typically, extensions to a sequence class are user constraints that scope the randomization to the desired test conditions. Based on the factory object and the extended constraints, the sequence creates transactions and puts them into the input port of the component. The component generates the protocol activity, handles any response, and optionally passes scoreboard information through the output port to the scoreboard.

When a component creates an object to be output on an activity or output port, the `allocate()` method is used to ensure that the resulting object is of the extended type (the factory type) and not of the base type. Note that, for this type of object, the extended members are only initialized because the VIP does not process the functionality of the extra members. Handling any added members must be provided by the testbench.

In UVM, constructors come in entirely through `uvm_config_db` (that is, all 'randomized_' fields) and/or the factory override subsystem (i.e., all `randomized_` fields if not found via `config_db`, as well as all `_factory` fields in all situations).

4.2.7 Messages

Messages can be controlled individually or in groups. This section describes messages and how to use them.

The messages originate in two scopes:

- ❖ Methodology messages, which report base class conditions and errors
- ❖ Protocol-specific messages that report protocol conditions, events, and errors

Messages can have a number of attributes, such as type, severity, ID, and text. Here are some qualities of these attributes:

- ❖ **Type:** Messages are categorized into types.

- ❖ **Severity:** Severity is similar to the urgency of the message or how serious it is.
- ❖ **Text:** This is the text of the message. UVM supports and promotes identifying messages by string matching against a regular expression.

4.2.8 Protocol Component SuperSpeed Link Callback, Factory, and Event Flows

This section provides detailed information about the sequence and content of callbacks provided by the VIP.

4.2.8.1 Protocol SuperSpeed Callback Flow when the VIP is Acting as a Host

4.2.8.1.1 Non-isochronous Transfers

Sequence of operations:

1. VIP gets transfer from transfer_in input port.
2. VIP uses the *svt_usb_protocol::randomized_transfer_in_exception_list* randomization factory to assist in creating exceptions to be injected into USB transfers.
3. After pulling a USB transfer descriptor out of the input port, VIP calls *svt_usb_protocol_callbacks::post_transfer_in_port_get(svt_usb_protocol component, int port_id, svt_usb_transfer transfer, ref bit drop)*; and then acts on the descriptor.
4. VIP calls *svt_usb_protocol_callbacks::transfer_in_port_cov(svt_usb_protocol component, int port_id, svt_usb_transfer transfer)*; callback to allow the testbench to collect functional coverage information from a USB transfer received in the transfer_in input port.

After performing the previous steps, the component can modify and process the object as required.

Send Phase

In the send phase, the VIP protocol component layer performs the following actions:

1. VIP uses the *svt_usb_protocol::randomized_usb_ss_transfer_response* factory to create new USB transactions.
2. VIP can use the *svt_usb_protocol_callbacks::randomized_transaction(this, transfer, transaction_ix, rand_point)*; callback to modify the transaction created in the first step.
3. VIP uses the *svt_usb_protocol::randomized_usb_ss_transaction_exception_list* randomization factory to create exceptions to be injected into USB SS transactions that need to be sent.
4. VIP issues the *svt_usb_protocol_callbacks::pre_transaction((svt_usb_transfer transfer, int transaction_ix)* callback when a protocol processor thread is ready to begin a USB Transaction. This callback can be extended to collect functional coverage data, or to check the transaction against a scoreboard, and other such operations.
5. VIP uses *randomized_usb_ss_transfer_response* to create new USB SS packets.
6. VIP uses *randomized_usb_ss_packet* for creating packets for USB SuperSpeed transactions.
7. If *rand_point* = *PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY*, then VIP issues *randomized_packet_rx_pkt_pre_processing_delay(svt_usb_protocol component, svt_usb_packet packet)*; callback when a protocol processor thread randomizes a received SS packet in order to create a randomized *svt_usb_packet::rx_pkt_pre_processing_delay* value.

If *rand_point* != *PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY*, then VIP issues *svt_usb_protocol_callbacks::randomized_packet(svt_usb_protocol component, svt_usb_transfer transfer, int*

transaction_ix, int packet_ix, svt_usb_types::protocol_randomization_point_enum rand_point) callback when a protocol processor thread creates a new USB packet by randomizing the packet factory.

8. VIP uses the *randomized_usb_ss_tx_packet_exception_list* to create exceptions to be injected into outgoing USB SS packets.
9. VIP may extend the *svt_usb_protocol_callbacks::pre_tx_packet(transfer, transaction_ix, packet_ix)* callback to collect functional coverage data, or to check the packet against a scoreboard.
10. VIP calls *svt_usb_protocol_callbacks::pre_usb_ss_packet_out_port_put(my_pkt, curr_xact, curr_xact.get_packet_index(tx_pkt), curr_xfer, curr_xfer.tx_xact_ix, drop)* callback before putting a USB packet descriptor into the SS packet output port.
11. VIP issues *svt_usb_protocol_callbacks::usb_ss_packet_out_port_cov(svt_usb_packet)* callback to enable the testbench to collect functional coverage information from a USB packet about to be sent to the link layer through the USB SS packet output port.

Receive Phase

In the receive phase, the VIP protocol component layer performs the following actions:

1. VIP uses the *svt_usb_protocol::randomized_transfer_in_exception_list* randomization factory to create exceptions to be injected into USB transfers.
2. The VIP pulls a USB packet descriptor out of the USB SuperSpeed input port (link layer), calls *post_usb_ss_packet_in_port_get(svt_usb_protocol component, int port_id, svt_usb_packet packet, ref bit drop)*, and then acts on the descriptor.
3. The VIP then performs actions based on one of the following conditions:
 - ◆ No endpoint claims the packet
 - ◆ The packet is dropped

No endpoint claims the packet

VIP calls *unclaimed_ss_packet(svt_usb_protocol component, svt_usb_packet packet, ref bit drop)*; and then issues an error message stating that an unclaimed USB packet that came through the USB SuperSpeed Packet input port (from the link layer). This is called if the packet cannot be handled by the applicable protocol block.

If the packet is dropped

VIP calls *discarded_ss_packet(svt_usb_protocol component, svt_usb_packet packet)*; and then discards the USB packet descriptor that came through the USB SuperSpeed Packet input port (from the link layer). This is called if the packet cannot be handled by the applicable protocol block.

4. VIP uses *svt_usb_protocol::randomized_usb_ss_transfer_response* to create new USB SuperSpeed transactions. The transaction argument is a handle to the transaction whose variables are to be randomized. The *rand_point* argument defines the context of this randomization, and implies a specific set of variables that will be randomized.
5. After the protocol processor thread creates a new USB transaction (by randomizing the transaction factory), VIP issues *svt_usb_protocol_callbacks::randomized_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, svt_usb_types::protocol_randomization_point_enum rand_point)*.
6. VIP uses the *svt_usb_protocol::randomized_usb_ss_transaction_exception_list* randomization factory to create exceptions to be injected into the USB SuperSpeed transactions that are to be sent.

7. VIP issues *pre_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)* callback when a protocol processor thread is ready to begin a USB Transaction. This callback can be extended to collect functional coverage data, or to check the transaction against a scoreboard, or other such operations.
8. VIP then performs actions based on one of the following conditions:
 - ◆ The received packet is not TP_ERDY
 - ◆ The received packet is for IN endpoint processor and retry_pending IN transfer is set to zero
 - ◆ The received packet is for IN endpoint processor

If the received packet is not TP_ERDY

VIP uses *svt_usb_protocol::randomized_usb_ss_rx_packet_exception_list* randomization factory to create exceptions to be added to incoming USB SuperSpeed packets.

VIP issues *svt_usb_protocol_callbacks::pre_rx_packet(svt_usb_transfer transfer, int transaction_ix, int packet_ix)* callback when a protocol processor thread is ready to begin processing a USB Packet received as part of a USB transfer. This callback can be extended to collect functional coverage data, or to check the packet against a scoreboard, or other such operations.

If the received packet is for IN endpoint processor and retry_pending in transfer is set to zero

VIP issues *svt_usb_protocol_callbacks::transaction_ended(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)*; callback when a USB transaction is completed. This callback can be extended to collect functional coverage data, or to check the transaction against a scoreboard, or other such operations.

If the received packet is for IN endpoint processor

VIP issues *received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)*; callback when an error free data packet that is receiving data for a transfer has just been received. The transfer in progress is passed as the transfer argument, and the data packet (DP) is passed as the packet argument. This callback is intended to be used by a testbench to sample and/or check data received for a transaction on-the-fly, regardless of whether the transaction completes at this point or not. For example, this callback can still be made if an extra DP is received for a transaction that has already received a flow-control response.

VIP issues *svt_usb_protocol_callbacks::transfer_ended(svt_usb_protocol component, svt_usb_transfer transfer)* when a USB transfer is complete (when the *transfer.end_tr()* event is sent for that USB transfer). This callback can be extended to collect functional coverage data, or to check the transaction against a scoreboard, or other such operations.

For all other packets

VIP issues *svt_usb_protocol_callbacks::transfer_ended(svt_usb_protocol component, svt_usb_transfer transfer)* when a USB transfer is complete (when the *transfer.end_tr()* event is sent for that USB transfer). This callback can be extended to collect functional coverage data, or to check the transaction against a scoreboard, or other such operations.

4.2.8.1.2 Ping Transactions

Sequence of operations:

1. VIP gets the USB transfer descriptor from the *transfer_in* input port.
2. VIP uses *svt_usb_protocol::randomized_transfer_in_exception_list* randomization factory to create exceptions that will be injected into USB transfers.

3. After pulling the USB transfer descriptor from the `transfer_in` input port, VIP calls `svt_usb_protocol_callbacks::post_transfer_in_port_get(svt_usb_protocol component, int port_id, svt_usb_transfer transfer, ref bit drop);`
4. VIP issues `svt_usb_protocol_callbacks::transfer_in_port_cov(svt_usb_protocol component, int port_id, svt_usb_transfer transfer);` callback to allow the testbench to collect functional coverage information from a USB transfer received from the `transfer_in` input port.
5. VIP uses `svt_usb_protocol::usb_ss_transaction_factory` factory to create new USB SuperSpeed transactions.
6. VIP can use `svt_usb_protocol_callbacks::randomized_transaction(this, transfer, transaction_ix, rand_point)` to modify the transaction created in the previous step.
7. VIP creates exceptions using `svt_usb_protocol::randomized_usb_ss_transaction_exception_list` randomization factory. These exceptions are injected into USB SuperSpeed transactions that will be sent.

If `rand_point = PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY`, then VIP issues `randomized_packet_rx_pkt_pre_processing_delay(svt_usb_protocol component, svt_usb_packet packet);` callback when a protocol processor thread randomizes a received SS packet in order to create a randomized `svt_usb_packet::rx_pkt_pre_processing_delay` value.

If `rand_point != PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY`, then VIP issues `svt_usb_protocol_callbacks::randomized_packet(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, int packet_ix, svt_usb_types::protocol_randomization_point_enum rand_point)` callback when a protocol processor thread creates a new USB packet by randomizing the packet factory.

8. VIP issues `svt_usb_protocol_callbacks::pre_transaction((svt_usb_transfer transfer, int transaction_ix)` callback when a protocol processor thread is ready to begin a USB Transaction. This callback can be extended to collect functional coverage data, or to check the transaction against a scoreboard, or other such operations.
9. VIP uses the `randomized_usb_ss_packet` randomization factory to create packets for a USB SuperSpeed transaction.
10. After the protocol processor thread randomizes a received SuperSpeed packet (in order to create a randomized `svt_usb_packet::rx_pkt_pre_processing_delay` value), VIP issues `randomized_packet(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, int packet_ix, svt_usb_types::protocol_randomization_point_enum rand_point)` callback.
11. After a protocol processor thread creates a new USB packet (by randomizing the packet factory), VIP issues `randomized_packet(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, int packet_ix, svt_usb_types::protocol_randomization_point_enum rand_point)` callback.
12. VIP then creates exceptions using the `randomized_usb_ss_tx_packet_exception_list` randomization factory. These exceptions are injected into outgoing SS packets.
13. VIP can optionally extend the `svt_usb_protocol_callbacks::pre_tx_packet(transfer, transaction_ix, packet_ix)` callback to collect functional coverage data, check the packet against a scoreboard, or other such operations.
14. VIP calls `svt_usb_protocol_callbacks::pre_usb_ss_packet_out_port_put(my_pkt, curr_xact, curr_xact.get_packet_index(tx_pkt), curr_xfer, curr_xfer.tx_xact_ix, drop)` before putting a USB packet descriptor into the SS output port.

15. VIP then issues *svt_usb_protocol_callbacks::usb_ss_packet_out_port_cov(svt_usb_packet packet)* to enable the testbench to collect functional coverage information from a USB packet that is going to be sent to the link layer through the USB SS output port.

4.2.8.1.3 Ping Response Operation for OUT Transactions

Sequence of operations:

1. VIP uses *svt_usb_protocol::usb_ss_transaction_factory* to create new USB SS transactions.
2. VIP modifies the transaction created in the previous step using *svt_usb_protocol_callbacks::randomized_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, svt_usb_types::protocol_randomization_point_enum rand_point)* callback.
3. VIP creates a randomization factory using *svt_usb_protocol::randomized_usb_ss_transaction_exception_list*, which is then injected into outgoing USB SS packets.
4. VIP can then optionally extend the *svt_usb_protocol_callbacks::pre_rx_packet(transfer, transaction_ix, packet_ix)* callback to collect functional coverage data, check the packet against a scoreboard, or other such operations.
5. VIP then issues *svt_usb_protocol_callbacks::transaction_ended(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)* callback when a USB transaction is complete when the *transfer.end_tr()* event is sent for a particular USB transaction, the VIP can optionally extend this callback to collect functional coverage data, check the packet against a scoreboard, or other such operations.

4.2.8.1.4 Isochronous Transfers

Sequence of operations:

1. VIP gets transfer from *transfer_in* input port.
2. VIP uses the *svt_usb_protocol::randomized_transfer_in_exception_list* randomization factory to assist in creating exceptions to be injected into USB transfers.
3. After pulling a USB transfer descriptor out of the input port, VIP calls *svt_usb_protocol_callbacks::post_transfer_in_port_get(svt_usb_protocol component, int port_id, svt_usb_transfer transfer, ref bit drop)*; and then acts on the descriptor.
4. VIP calls *svt_usb_protocol_callbacks::transfer_in_port_cov(svt_usb_protocol component, int port_id, svt_usb_transfer transfer)*; callback to allow the testbench to collect functional coverage information from a USB transfer received in the *transfer_in* input port.

After performing the above steps, the component can modify and process the object as required.

Send Phase

In the send phase, the VIP protocol component layer performs the following actions:

1. VIP uses the *svt_usb_protocol::usb_ss_transaction_factory* factory to create new USB transactions.
2. VIP can use the *svt_usb_protocol_callbacks::randomized_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, svt_usb_types::protocol_randomization_point_enum rand_point)*; callback to modify the transaction created in the first step.
3. VIP uses the *svt_usb_protocol::randomized_usb_ss_transaction_exception_list* randomization factory to create exceptions to be injected into USB SS transactions that need to be sent.

4. VIP issues the *svt_usb_protocol_callbacks::pre_transaction((svt_usb_transfer transfer, int transaction_ix)* callback when a protocol processor thread is ready to begin a USB Transaction. This callback can be extended to collect functional coverage data, or to check the transaction against a scoreboard, and other such operations.
5. VIP uses *randomized_usb_ss_packet* to assist in creating packets for USB SuperSpeed transactions.

Receive Phase

Sequence of operations:

1. If *rand_point* = *PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY*, then VIP issues *randomized_packet_rx_pkt_pre_processing_delay(svt_usb_protocol component, svt_usb_packet packet);* callback when a protocol processor thread randomizes a received SS packet in order to create a randomized *svt_usb_packet::rx_pkt_pre_processing_delay* value.
If *rand_point* != *PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY*, then VIP issues *svt_usb_protocol_callbacks::randomized_packet(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, int packet_ix, svt_usb_types::protocol_randomization_point_enum rand_point)* callback when a protocol processor thread creates a new USB packet by randomizing the packet factory.
2. VIP uses *randomized_usb_ss_tx_packet_exception_list* randomization factory to create exceptions to be injected into outgoing USB SS packets.
3. VIP can then optionally extend the *svt_usb_protocol_callbacks::pre_tx_packet(transfer, transaction_ix, packet_ix)* callback to collect functional coverage data, check the packet against a scoreboard, or other such operations.
4. VIP calls *svt_usb_protocol_callbacks::pre_usb_ss_packet_out_port_put(svt_usb_protocol component, int port_id, svt_usb_packet packet, svt_usb_transaction transaction, int packet_ix, svt_usb_transfer transfer, int transaction_ix, ref bit drop)* before it puts a USB packet descriptor into the SS packet output port.
5. VIP issues *svt_usb_protocol_callbacks::usb_ss_packet_out_port_cov(svt_usb_packet packet)* callback to enable the testbench to collect functional coverage information from a USB packet that is about to be sent to the link layer through the USB SS packet output port.
6. VIP issues *svt_usb_protocol_callbacks::transaction_ended(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix);* callback when a USB transaction is complete (when the *transfer.end_tr()* event is sent for a particular USB transaction).

4.2.8.2 Protocol SuperSpeed Callback Flow when the VIP is Acting as a Device

High Level Sequence of Operations

1. VIP receives the packet from *packet_in_port*.
2. VIP retrieves packets from the link layer through the appropriate packet input port (see [Receive Phase](#)).
3. VIP locates device object for packet's *device_address* and determines if deferral is required based on the value of *USB_SEND_DEFERRED_PACKETS* protocol service.
4. If deferral is required, VIP does the following:
 - a. Creates a copy of the Rx packet (using the Rx packet's *allocate()* function), assigning the copy to *downstream_pkt*.
 - b. Sets *downstream_pkt.was_deferred* = 1.

- c. Randomizes the downstream packet using the `PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY` randomization point randomizing both `rx_pkt_pre_processing_delay` and `deferred_pkt_reflection_delay`.
 - d. Uses `downstream_pkt` as factory to create a copy assigning to `upstream_pkt`.
 - e. Places `upstream_pkt` in `deferred_pkt_queue` to be reflected back sequentially to the host. Before each individual packet is reflected back, the packet's `deferred_pkt_reflection_delay` time is inserted.
 - f. Places `downstream_pkt` in `rx_pkt_ppd_queue`.
 - g. After the deferral activity is complete, process each packet in the `rx_pkt_ppd_queue` sequentially. Each packet is delayed `rx_pkt_pre_processing_delay` amount of time before it is passed to the applicable protocol processor to create a new transfer or continue an existing transfer.
5. If deferral is not required, VIP does the following:
 - a. Sets `downstream_pkt` equal to Rx packet.
 - b. Randomizes the downstream packet using the `PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY` randomization point randomizing both `rx_pkt_pre_processing_delay` and `deferred_pkt_reflection_delay`.
 - c. After the deferral activity is complete, process each packet in the `rx_pkt_ppd_queue` sequentially. Each packet is delayed `rx_pkt_pre_processing_delay` amount of time before it is passed to the applicable protocol processor to create a new transfer or continue an existing transfer.
 6. Once the packet is routed to the appropriate endpoint, based on the endpoint direction, VIP processes the packet further (see [VIP Processing of Packets Received During IN Transfers](#) or [VIP processing packets received during OUT Transfers](#)).
 7. VIP sends the response to the host through the link layer packet output port.

Detailed Sequences

Receive Phase

1. VIP pulls a USB packet descriptor out of the SS packet input port (from the link layer) and calls `post_usb_ss_packet_in_port_get(svt_usb_protocol component, int port_id, svt_usb_packet packet, ref bit drop)`; before acting on the descriptor.
2. VIP calls `route_packet`.

VIP Processing of Packets Received During IN Transfers

For non-isochronous transfers, VIP completes the following sequence of operations:

1. VIP receives the packet and modifies the stream state when the device transitions to `move_data` state. If the received packet has `setup_bit = 1` and `transfer_stage` is not `SETUP_STAGE`, VIP performs the following actions:
 - a. Aborts transfer
 - b. Calls `route_packet`
 - c. Exits `receive_in_packet`

2. VIP prepares the transaction (if it is not yet ready).
3. VIP uses *randomized_usb_ss_rx_packet_exception_list* randomization factory to create fake exceptions to be added to incoming USB SS packets.
4. VIP checks if the received packet has the deferred bit set. If the deferred bit is set, VIP moves to idle stream state. If the deferred bit is not set, VIP issues *transaction_ended(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)* after the USB Endpoint Manager transaction is complete. VIP can optionally extend this callback to collect functional coverage data, check the transaction against a scoreboard, and other such operations.
If the transfer is not completed and the received packet is terminating with an ACK, VIP moves to idle stream state.

For isochronous transfers, VIP completes the following sequence of operations:

1. VIP prepares the transaction.
2. VIP uses *randomized_usb_ss_rx_packet_exception_list* randomization factory to create fake exceptions to be added to incoming USB SS packets.
3. If the received packet is neither a ping or a TP_ACK, VIP terminates the transfer.
4. If the received packet is a ping or a TP_ACK, VIP issues *post_ss_rx_pkt_xfer_update(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, int packet_ix)* callback immediately after a protocol processor thread completes processing a USB packet received and associated with a USB transfer. VIP can optionally extend this callback to collect functional coverage data, check the transaction against a scoreboard, and other such operations.
5. VIP then follows the process described in [VIP Processing Packets Sent During IN Transfers](#).

VIP processing packets received during OUT Transfers

For non-isochronous transfers, VIP completes the following sequence of operations:

1. VIP performs a check on the received packet:
 - ◆ If *transfer_stage* = *SETUP_STAGE*, and the received packet has setup bit set to 1 and deferred bit set to zero and if *received_packet.payload_presence* = *payload_present* and transfer has *setup_with_payload_absent* = 1, VIP performs the following actions:
 - i. VIP captures the information from the received setup packet and randomizes (or asks for the transfer) to operate on. When a packet is deferred, the payload is striped off. If the setup packet is deferred, the setup bytes are stripped off. So, if the first setup packet, which initiates the transfer is deferred, the device model does not have any valid setup bytes to randomize the transfer. So, when non-deferred setup packets are received after the deferred setup byte, VIP has to capture the correct setup bytes and re-randomize the transfer again.
 - ii. VIP generates the basic response information and then modifies the stream state when the device transitions to *move_data* state.
 - ◆ If received packet is *DATA_PACKET* and *setup_bit* is 1 and *xfer_stage* is not *SETUP_STAGE* in transfer (indicating that the received setup is not a part of the current transfer), VIP performs the following actions:
 - i. VIP calls *route_packet*.
 - ii. VIP prepares the transaction.
2. VIP uses *randomized_usb_ss_rx_packet_exception_list* randomization factory to create fake exceptions to be added to incoming SS packets.

3. VIP issues *pre_rx_packet(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, int packet_ix)* callback when a protocol processor thread is ready to start processing a USB packet to be transmitted as part of a USB transfer. VIP can optionally extend this callback to collect functional coverage data, check the packet against a scoreboard, or other such operations.
4. VIP uses *randomize_transaction* to determine if `EARLY_NAK_RESPONSE` or `EARLY_WAIT_FOR_ENDED_RESPONSE` is the response. VIP uses the randomization keys of `xact.early_response` to control the response types that are allowed.
5. VIP issues *received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)* callback when it receives an error-free data packet for a transfer. The transfer in progress is passed as the transfer argument, and the data packet is passed as the packet argument. The testbench uses this callback to sample data received for a transaction on-the-fly, regardless of whether the transaction completes at this point or not.
6. VIP calls *do_post_ss_rx_pkt_xfer_update_cb_exec*.

For isochronous transfers, VIP completes the following sequence of operations:

1. VIP prepares the transaction.
2. VIP uses *randomized_usb_ss_rx_packet_exception_list* randomization factory to create fake exceptions to be added to incoming SS packets.
3. If the received packet is `TP_PING`, then VIP calls *send_out_packet*. If the received packet is not a data packet, then VIP terminates the transfer.
4. VIP issues *transaction_ended(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)* callback immediately after a USB Endpoint Manager transaction is complete. VIP can optionally extend this callback to collect functional coverage data, check the packet against a scoreboard, or other such operations.
5. VIP issues *received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)* callback when it receives an error-free data packet for a transfer. The transfer in progress is passed as the transfer argument, and the data packet is passed as the packet argument. The testbench uses this callback to sample data received for a transaction on-the-fly, regardless of whether the transaction completes at this point or not.
6. VIP issues *post_ss_rx_pkt_xfer_update(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, int packet_ix)* callback when a protocol processor thread has completed processing a USB packet received and associated with a USB transfer. VIP can optionally extend this callback to collect functional coverage data, or modify the data in the packet so that it is reflected in the transfer.

VIP Processing Packets Sent During IN Transfers

For non-isochronous transfers, VIP completes the following sequence of operations:

1. VIP prepares the transaction.
2. VIP uses *randomized_usb_ss_transaction* randomization factory to create transactions for a USB SS transfer.
3. VIP issues *randomized_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, svt_usb_types::protocol_randomization_point_enum rand_point)* callback immediately after a protocol processor thread creates a new USB transaction by randomizing the transaction factory (*randomized_usb_transaction* object or array).
4. VIP prepares the response packet to be send to the host and then updates the variable after the IN endpoint transmits the packet to the host.

For isochronous transfers, VIP completes the following sequence of operations:

1. If the transaction is an SS Ping or Ping response, VIP calls *send_ping_response*.
2. If the transaction is not an SS Ping or Ping response, VIP performs the following operations:
 - a. VIP prepares the transaction.
 - b. VIP uses *randomized_usb_ss_transaction* randomization factory to create transactions for a USB SS transfer.
 - c. VIP issues *randomized_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, svt_usb_types::protocol_randomization_point_enum rand_point)* callback immediately after a protocol processor thread creates a new USB transaction by randomizing the transaction factory (*randomized_usb_transaction* object or array).
 - d. VIP prepares the next generated packet for the specified transaction and then creates packets for USB SS transactions.
 - e. If the packet is randomized with *PROTOCOL_RAND_SS_RX_PKT_PRE_PROCESSING_DELAY*, VIP issues *randomized_packet_rx_pkt_pre_processing_delay(svt_usb_protocol component, svt_usb_packet packet)* callback immediately after a protocol processor thread randomizes a received USB SS packet in order to create a randomized *svt_usb_packet::rx_pkt_pre_processing_delay* value.
 - f. VIP issues *randomized_packet(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, int packet_ix, svt_usb_types::protocol_randomization_point_enum rand_point)* callback immediately after the protocol processor thread creates a new USB transaction by randomizing the packet factory (*randomized_usb_packet* object or array).
 - g. If the transaction device response does not time out, VIP calls *send_ss_pkt_to_link* and issues *transaction_ended(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)* callback when a USB Endpoint Manager transaction is complete. VIP can optionally extend this callback to collect functional coverage data, check the transaction against a scoreboard, or other such operations.

VIP Processing Packets Sent during OUT Transfers

For non-isochronous transfers, VIP completes the following sequence of operations:

1. VIP uses *randomized_usb_ss_transaction* randomization factory to create transactions for a USB SS transfer.
2. VIP issues *randomized_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, svt_usb_types::protocol_randomization_point_enum rand_point)* callback immediately after a protocol processor thread creates a new USB transaction by randomizing the transaction factory (*randomized_usb_transaction* object or array).
3. VIP prepares the response packet to be sent to the host.
4. If the transfer completes successfully or if received packet *pp_bit=0* and *retyr_bit=0*, VIP moves to idle stream state.

For isochronous transfers, VIP checks if the transfer is an *isoc_ping* transfer, and then it sends a ping response.

4.2.8.3 Protocol SuperSpeed Endpoint Manager Flow

The SuperSpeed endpoint manager flow works parallel to the send and receive phase of host and device. This controls streamable and non-streamable endpoint states before during and after move_data states. For more information, see section 8.12 of the USB specification.

There are two different flows:

- ❖ Non-stream endpoint manager - This manages non-stream states.
- ❖ Stream endpoint manager - This manages stream states.

4.2.8.3.1 Non-stream Endpoint Manager Flow for Host and Device

Sequence of operations:

1. VIP prepares the transfer for the endpoint.
2. VIP randomizes the endpoint manager factory.

4.2.8.3.2 Stream Endpoint Manager Flow

[Figures 4-4](#) and [4-5](#) illustrate the stream endpoint manager flow for host and device respectively.

Figure 4-4 Host Stream Endpoint Manager Flow





Figure 4-5 Device Stream Endpoint Manager Flow

4.2.9 Link Callback, Factory and UVM Event Flows for USB 2.0 VIP

This section provides detailed information about the sequence and content of callbacks provided by the VIP.

USB 2.0 Service Command Handling

Table 4-2 lists the various USB 2.0 link service commands that are available.

Table 4-1 USB 2.0 Service Command Usage

Command	Host or Device	Usage
SVT_USB_20_PORT_RESET	Host only command	Causes the VIP to start driving protocol reset. Note: The VIP must be in a state other than POWERED_OFF or DISCONNECTED.
SVT_USB_20_SET_PORT_SUSPEND	Host and Device	Allows the VIP to move to the Suspend state (provided the command is issued when the VIP is in Idle state).
SVT_USB_20_CLEAR_PORT_SUSPEND	Host and Device	Allows the VIP to initiate Resume (provided the command is issued when the VIP is in Suspend state).
SVT_USB_20_PORT_START_LPM	Host and Device	Allows the VIP to transition to the L1 Suspend/Resume state machine, instead of the normal Suspend/Resume.
SVT_USB_20_PORT_INITIATE_SRP (NYI)	Host and Device	Allows the user to create SRP manually instead of the VIP doing it automatically based on timers.
SVT_USB_PACKET_ABORT	Host and Device	Kills the packet that is currently being processed. Note: The current implementation does not append an EOP to the packet that is being aborted.

4.2.9.1 When VIP is Acting as Host

4.2.9.1.1 Non-isochronous Transfers

Transfer Start Phase

A Host non-isochronous transfer begins with the Host VIP receiving a transfer object on the transfer input port.

Sequence of operations:

1. VIP gets transfer from transfer_in input port.
2. VIP uses the *svt_usb_protocol::randomized_transfer_in_exception_list* randomization factory to assist in creating exceptions to be injected into USB transfers. The *randomized_transfer_in_exception_list* is then randomized and added to the transfer's exception_list attribute. A new exception_list is created for the transfer if one did not exist.
3. After pulling a USB transfer descriptor out of the input port, VIP calls *svt_usb_protocol_callbacks::post_transfer_in_port_get(svt_usb_protocol component, int port_id, svt_usb_transfer transfer, ref bit drop)*; and then acts on the descriptor.

4. (Optional) This step occurs only if the drop bit from *post_transfer_in_port_get()* returns a false value. VIP calls *svt_usb_protocol_callbacks::transfer_in_port_cov(svt_usb_protocol component, int port_id, svt_usb_transfer transfer)*; to allow the testbench to collect functional coverage information from a USB transfer received in the transfer_in input port.

Transfer Processing Phase

The transfer may be completed as a single transaction, or it may require multiple transactions to complete the transfer. A loop is used to process the transfer until all of its transactions are completed (or until the transfer is aborted). The following loops are discussed here:

- ❖ Transfer loop for host non-isochronous
- ❖ Transaction loop for host non-isochronous (this is a subset of the entire transfer loop)

Transfer Loop for Host non-isochronous

Sequence of operations:

1. Create and prepare new transactions.

Each time the Transfer Loop is executed, a new transaction object is created that represents the next transaction needed to implement the transfer. For more information on the detailed callback and uvm_event sequences.

2. Process the transaction.

The transaction is processed according to the transaction loop described in [Transaction Loop for Host non-isochronous](#).

3. (Optional) Repeat the transfer loop if more transactions are required.

This step depends on the specific transfer. If there is more payload to send and the transfer is not aborted, then continue with the transfer loop.

4. If the transfer loop does not have to be repeated, VIP issues *transfer.end_tr()*, and then issues *svt_usb_protocol_callbacks::transfer_ended(svt_usb_protocol component, svt_usb_transfer transfer)*.

Transaction Loop for Host non-isochronous

The Transaction Loop occurs as a step within the Transfer Loop. The transaction may require sending or receiving multiple packets. The actual send or receive direction and the number of packets depends on the specific transaction type and traffic conditions. The description of the transaction loop is generic and does not attempt to detail the specific send and receive order, but rather the order of callbacks associated with a packet send or receive.

Sequence of operations:

1. Create and send packet.

The Host sends a TOKEN packet. For information on the callbacks. This callback flow applies even if the specific transaction requires the Host to send a DATA or a HANDSHAKE packet.

2. Get the received packet.

If the transaction requires the Host to receive a DATA or HANDSHAKE packet from the device, then the VIP uses the [Get Received Packet](#) callback flow.

- Host responds to the transaction based on the type of transaction.

If the transaction is a device IN DATA transaction

If the device DATA is a legal protocol response and has no packet exception errors, VIP does the following:

- VIP appends the payload to the data array.
- VIP issues `svt_usb_protocol_callbacks::received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)` when it receives an error free data packet that is receiving data for a transfer.

If (not INTR-CSPLIT) - VIP calls `transfer.payload.append_payload(packet.payload)`

If (last INTR-CSPLIT) - VIP calls `transfer.payload.append_payload(transaction.payload)`

If (last CSPLIT) - VIP calls the following:

- `transaction.status = svt_transaction::ACCEPT`
 - `transfer.end_tr()`
 - `svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)`
-

If the transaction is non-split, then VIP does the following:

- VIP randomizes the transaction object using `svt_usb_protocol::randomized_usb_20_transaction`. First the current transaction object is copied into the `randomized_usb_20_transaction` object. The `host_response` attribute is then randomized. And finally, the randomized factory object is copied back into the current transaction object.
 - VIP calls `svt_usb_protocol_callbacks::randomized_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, svt_usb_types::protocol_randomization_point_enum rand_point)`.
 - If `(transaction.host_response == HOST_NORMAL_RESPONSE)`, complete the flow listed in [“Prepare and Send Packet”](#) on page 68.
 - If the host response is ACK, with no injection errors, then VIP does the following:
 - `transaction.status = svt_transaction::ACCEPT`
 - `transfer.end_tr()`
 - `protocol_block.protocol.NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone());`
-

If the transaction is SPLIT IN and device responds with an ACK, VIP does the following:

- `transaction.status = svt_transaction::ACCEPT`
 - `transfer.end_tr()`
 - `svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)`
-

If the transaction exceeds the maximum allowed number of errors, VIP aborts the transfer.

Host Response to Device Handshake for OUT transactions

If the device HANDSHAKE is an ACK, does not have any packet exception errors, and if the transaction is either a Complete SPLIT or not a SPLIT, complete the following steps:

- Subtract the `transaction.payload.byte_count` value from the `transfer.payload_bytes_remaining` attribute.
 - Mark the transaction status as ACCEPT using `transaction.status = svt_transaction::ACCEPT`.
 - Trigger the transaction notify that the transaction has ENDED using `transfer.end_tr()`
 - Provide a copy of the ENDED transaction with the top protocol notification that the transaction has ENDED using `svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)`
-

If the device HANDSHAKE is a NYET, does not have any packet exception errors, and if the transaction is not a SPLIT, complete the following steps:

1. Subtract the *transaction.payload.byte_count* value from the *transfer.payload_bytes_remaining* attribute.
2. Mark the transaction status as ACCEPT using *transaction.status = svt_transaction::ACCEPT*.
3. Trigger the transaction notify that the transaction has ENDED using *transfer.end_tr()*.
4. Provide a copy of the ENDED transaction with the top protocol notification that the transaction has ENDED using *svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)*

If the transaction exceeds the maximum allowed number of errors, VIP aborts the transfer.

Host response to device handshake for SETUP transactions

If the device HANDSHAKE is an ACK, does not have any packet exception errors, and if the transaction is either a Complete SPLIT or not a SPLIT, complete the following steps:

1. Subtract the *transaction.payload.byte_count* value from the *transfer.payload_bytes_remaining* attribute.
2. Mark the transaction status as ACCEPT using *transaction.status = svt_transaction::ACCEPT*.
3. Trigger the transaction notify that the transaction has ENDED using *transfer.end_tr()*.
4. Provide a copy of the ENDED transaction with the top protocol notification that the transaction has ENDED using *svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)*.

If the transaction exceeds the maximum allowed number of errors, VIP aborts the transfer.

4. To repeat the transaction loop, go back to the flow at the top of the transaction loop. Otherwise, the transaction has already been marked ENDED and the callback to *transaction_ended* is made using *svt_usb_protocol_callbacks::transaction_ended(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)*. Isochronous Transfers

Transfer Start Phase

A host isochronous transfer begins when the Host VIP receives a transfer object on the transfer input port.

Sequence of operations:

1. VIP gets transfer from *transfer_in* input port.
2. VIP uses the *svt_usb_protocol::randomized_transfer_in_exception_list* randomization factory to assist in creating exceptions to be injected into USB transfers. The *randomized_transfer_in_exception_list* is then randomized and added to the transfer's *exception_list* attribute. A new *exception_list* is created for the transfer if one did not exist.
3. After pulling a USB transfer descriptor out of the input port, VIP calls *svt_usb_protocol_callbacks::post_transfer_in_port_get(svt_usb_protocol component, int port_id, svt_usb_transfer transfer, ref bit drop)*; and then acts on the descriptor.
4. (Optional) This step occurs only if the drop bit from *post_transfer_in_port_get()* returns a false value. VIP calls *svt_usb_protocol_callbacks::transfer_in_port_cov(svt_usb_protocol component, int port_id, svt_usb_transfer transfer)*; to allow the testbench to collect functional coverage information from a USB transfer received in the *transfer_in* input port.

Transfer Processing Phase

The transfer may be completed as a single transaction, or it may require multiple transactions to complete the transfer. A loop is used to process the transfer until all of its transactions are completed (or until the transfer is aborted). The following loops are discussed here:

- ❖ Transfer loop for host isochronous
- ❖ Transaction loop for host isochronous (this is a subset of the entire transfer loop)

Transfer Loop for Host Isochronous

Sequence of operations:

1. Create and prepare new transactions.
Each time the Transfer Loop is executed, a new transaction object is created that represents the next transaction needed to implement the transfer. For more information on the detailed callback and `uvm_event` sequences.
2. Process the transaction.
The transaction is processed according to the transaction loop described in [Transaction Loop for Host Isochronous](#).
3. (Optional) Repeat the transfer loop if more transactions are required.
This step depends on the specific transfer. If there is more payload to send and the transfer is not aborted, then continue with the transfer loop.
4. If the transfer loop does not have to be repeated, VIP issues `transfer.end_tr()`, and then issues `svt_usb_protocol_callbacks::transfer_ended(svt_usb_protocol component, svt_usb_transfer transfer)`.

Transaction Loop for Host Isochronous

The Transaction Loop occurs as a step within the Transfer Loop. The transaction may require sending or receiving multiple packets. The actual send or receive direction and the number of packets depends on the specific transaction type and traffic conditions. The description of the transaction loop is generic and does not attempt to detail the specific send and receive order, but rather the order of callbacks associated with a packet send or receive.

Sequence of operations:

1. Prepare and send packet.
The Host sends a TOKEN packet. For information on the callbacks. This callback flow applies even if the specific transaction requires the Host to send a DATA or a HANDSHAKE packet.
2. Get the received packet.
If the transaction requires the Host to receive a DATA or HANDSHAKE packet from the device, then the VIP uses the [Get Received Packet](#) callback flow.
3. Host responds to the transaction based on the type of transaction.

Host response to device isochronous IN DATA

If the device DATA is a legal protocol response and has no packet exception errors, VIP does the following:

1. VIP calls `transaction.payload.append_payload(packet.payload)`.
2. VIP issues `svt_usb_protocol_callbacks::received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)` when it receives an error free data packet that is receiving data for a transfer.
3. VIP calls `transfer.payload.append_payload(packet.payload)`.

If the transaction is non-SPLIT or last CSPLIT, VIP does the following:

- VIP calls `transaction.status = svt_transaction::ACCEPT`
 - VIP calls `transfer.end_tr()`
 - VIP calls `svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)`
-

If the transaction exceeds the maximum allowed number of errors, VIP aborts the transfer.

Host response to isochronous OUT transactions

If the transaction is not a SPLIT or is the last Start SPLIT, then VIP does the following:

1. Call *transaction.status = svt_transaction::ACCEPT*.
 2. Trigger the *uvm_event* that the transaction has ENDED using *transfer.end_tr()*.
 3. Provide a copy of the ENDED transaction with the top protocol *uvm_event* that the transaction has ENDED using *svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)*.
-

If the device handshake is a NYET and the transaction is not a SPLIT, then VIP does the following:

1. Subtract the *transaction.payload.byte_count* value from the *transfer.payload_bytes_remaining* attribute.
 2. Mark the transaction status as ACCEPT using *transaction.status = svt_transaction::ACCEPT*.
 3. Trigger the transaction notify that the transaction has ENDED using *transfer.end_tr()*.
 4. Provide a copy of the ENDED transaction with the top protocol *uvm_event* that the transaction has ENDED using *svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)*
-

4. To repeat the transaction loop, go back to the flow at the top of the transaction loop. Otherwise, the transaction has already been marked ENDED and the callback to *transaction_ended* is now made using *svt_usb_protocol_callbacks::transaction_ended (svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)*.

4.2.9.2 When the VIP Acts as a Device

4.2.9.2.1 Non-isochronous Transfers

Transfer Start Phase

A device non-isochronous transfer begins when the Device VIP receives a TOKEN packet object on the packet input port.

Sequence of operations:

1. VIP receives the TOKEN packet from the *svt_usb_protocol::packet_in_port* port. For more information about the callbacks and *uvm_events*.
2. VIP creates the new device VIP transfer object and allows you to modify or replace it. For more information about the callbacks and *uvm_events*.

Transfer Processing Phase

The transfer may be completed as a single transaction, or it may require multiple transactions to complete the transfer. A loop is used to process the transfer until all of its transactions are completed (or until the transfer is aborted).

The following loops are discussed here:

- ❖ Transfer loop for device non-isochronous
- ❖ Transaction loop for device non-isochronous (this is a subset of the entire transfer loop)

Transfer Loop for Device Non-isochronous

Sequence of operations:

1. Create and prepare new transactions.

Each time the Transfer Loop is executed, a new transaction object is created that represents the next transaction needed to implement the transfer. For more information on the detailed callback and `uvm_event` sequences.

2. Process the transaction.
3. The transaction is processed according to the transaction loop described in [Transaction Loop for Device Non-Isochronous](#).
4. (Optional) Repeat the transfer loop if more transactions are required.
This step depends on the specific transfer. If there is more payload to send and the transfer is not aborted, then continue with the transfer loop.
5. If the transfer loop does not have to be repeated, VIP issues `transfer.end_tr()`, and then issues `svt_usb_protocol_callbacks::transfer_ended(svt_usb_protocol component, svt_usb_transfer transfer)`.

Transaction Loop for Device Non-Isochronous

Sequence of operations:

1. If this is the first transaction of the transfer, mark the transfer as STARTED using `uvm_event begin_event` (`uvm_transaction`'s `begin_event` field)
2. If the transaction requires the Device to receive a TOKEN, DATA or HANDSHAKE packet from the Host, use the [Get Received Packet](#) callback flow.
If the transaction requires the Device to send either a DATA packet or a HANDSHAKE packet, use the callback flow.
3. Device responds to the transaction based on the type of transaction.

Device response if the transaction is not a SPLIT OUT or a SETUP transaction

Randomize the transaction for response using the [Randomize Transaction for Response](#) callback flow.

If you need to send a packet, use the [Prepare and Send Packet](#) callback flow.

If the device response is legal protocol and has no error exceptions, complete the following steps:

1. If the transaction is not a SETUP transaction, VIP calls `transaction.payload = received_packet.payload.copy()`.
2. VIP then calls the following:
 - `svt_usb_protocol_callbacks::received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)`
 - `transaction.status = svt_transaction::ACCEPT`
 - `t transfer.end_tr()`
 - `svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)`
3. If the transaction is not a SETUP transaction, VIP calls `transfer.payload.append_payload(transaction.payload)`

If the transaction has exceeded the maximum number of allowed errors, VIP aborts the transfer.

Device response if the transaction is a START SPLIT transaction

If the transaction is not an Interrupt, complete the following steps:

1. Randomize the transaction for response using the [Randomize Transaction for Response](#) callback flow.
2. If you need to send a packet, use the [Prepare and Send Packet](#) callback flow.
3. If the device response is legal protocol and has no error exceptions, move to Complete SPLIT

If the transaction has exceeded the maximum number of allowed errors, VIP aborts the transfer.

Device response if the transaction is a Complete SPLIT OUT or SETUP transaction

Randomize the transaction for response using the [Randomize Transaction for Response](#) callback flow.

If you need to send a packet, use the [Prepare and Send Packet](#) callback flow.

If the device response is legal protocol and has no error exceptions, complete the following steps:

1. If the transaction is not a SETUP transaction, VIP calls the following:
 - *transaction.payload = received_packet.payload.copy().*
 - *svt_usb_protocol_callbacks::received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)*
 - *transfer.payload.append_payload(transaction.payload)*
 - If the transaction is a SETUP transaction, VIP calls the following:
 - *svt_usb_protocol_callbacks::received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)*
2. VIP then calls the following:
 - *transaction.status = svt_transaction::ACCEPT*
 - *transfer.end_tr()*
 - *svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)*
3. If the transaction is not a SETUP transaction, VIP calls *transfer.payload.append_payload(transaction.payload).*

If the transaction has exceeded the maximum number of allowed errors, VIP aborts the transfer.

Device response if the transaction is a non-SPLIT IN transaction

Randomize the transaction for response using the [Randomize Transaction for Response](#) callback flow.

If you need to send a packet, use the [Prepare and Send Packet](#) callback flow.

If you need to receive a packet, use the [Get Received Packet](#) callback flow.

If the host handshake packet is legal protocol and has no error exceptions, VIP does the following:

1. *transaction.status = svt_transaction::ACCEPT*
2. *transfer.end_tr()*
3. *svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)*

If the transaction has exceeded the maximum number of allowed errors, VIP aborts the transfer.

Device response if the transaction is a Complete SPLIT IN (INTERRUPT) transaction

Randomize the transaction for response using the [Randomize Transaction for Response](#) callback flow.

If you need to send a packet, use the [Prepare and Send Packet](#) callback flow.

If this is the last CSPLIT and the Device DATA packet is legal protocol and error free, VIP does the following:

1. *transaction.status = svt_transaction::ACCEPT*
2. *transfer.end_tr()*
3. *svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)*

If the transaction has exceeded the maximum number of allowed errors, VIP aborts the transfer.

Device response if the transaction is a Complete SPLIT IN (BULK or CONTROL) transaction

Randomize the transaction for response using the [Randomize Transaction for Response](#) callback flow.

If you need to send a packet, use the [Prepare and Send Packet](#) callback flow.

If this is the last CSPLIT and the Device DATA packet is legal protocol and error free, VIP does the following:

1. *transaction.status = svt_transaction::ACCEPT*
 2. *transfer.end_tr()*
 3. *svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)*
-

If the transaction has exceeded the maximum number of allowed errors, VIP aborts the transfer.

4. To repeat the transaction loop, go back to the flow at the top of the transaction loop. Otherwise, the transaction has already been marked ENDED and the callback to *transaction_ended* is now made using *svt_usb_protocol_callbacks::transaction_ended (svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)*.

4.2.9.2.2 Isochronous Transfers

Transfer Start Phase

A device isochronous transfer begins when the Device VIP receives a TOKEN packet object on the packet input port.

Sequence of operations:

1. VIP receives the TOKEN packet from the *svt_usb_protocol::packet_in_port* port. For more information about the callbacks and *uvm_events*.
2. VIP creates the new device VIP transfer object and allows you to modify or replace it. For more information about the callbacks and *uvm_events*.

Transfer Processing Phase

The transfer may be completed as a single transaction, or it may require multiple transactions to complete the transfer. A loop is used to process the transfer until all of its transactions are completed (or until the transfer is aborted).

The following loops are discussed here:

- ❖ Transfer loop for device isochronous
- ❖ Transaction loop for device isochronous (this is a subset of the entire transfer loop)

Transfer Loop for Device Isochronous

Sequence of operations:

1. Create and prepare new transactions.
Each time the Transfer Loop is executed, a new transaction object is created that represents the next transaction needed to implement the transfer. For more information on the detailed callback and *uvm_event* sequences.
2. Process the transaction.
3. The transaction is processed according to the transaction loop described in [Transaction Loop for Device Non-Isochronous](#).
4. (Optional) Repeat the transfer loop if more transactions are required.

This step depends on the specific transfer. If there is more payload to send and the transfer is not aborted, then continue with the transfer loop.

5. If the transfer loop does not have to be repeated, VIP issues `-> uvm_event begin_event` (`uvm_transaction's begin_event` field)
6. , and then issues `svt_usb_protocol_callbacks::transfer_ended(svt_usb_protocol component, svt_usb_transfer transfer)`.

Transaction Loop for Device Isochronous

Sequence of operations:

1. If this is the first transaction of the transfer, mark the transfer as STARTED using `uvm_event begin_event` (`uvm_transaction's begin_event` field).
2. If the transaction requires the Device to receive a TOKEN, DATA or HANDSHAKE packet from the Host, use the [Get Received Packet](#) callback flow.
3. Randomize the `transaction.device_response`, and create and send the response packet (if needed) as follows:
 - a. Use `svt_usb_protocol::randomized_usb_20_transaction` to randomize the transaction object. Copy the current transaction object into the `randomized_usb_20_transaction` object. Then `randomized_usb_20_transaction.randomize()` is called. Only the `device_response` attribute is randomized. Finally, the randomized factory object is copied back into the current transaction object.
 - b. VIP calls `svt_usb_protocol_callbacks::randomized_transaction(svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix, svt_usb_types::protocol_randomization_point_enum rand_point)` after the transaction is randomized.
 - c. If the specific transaction requires the Device to send either a DATA or a HANDSHAKE packet, use the [Prepare and Send Packet](#) callback flow.
4. Device responds to the transaction based on the type of transaction.

Device response if the transaction is a HOST ISOC IN transaction

If the device response is legal protocol and has no error exceptions, subtract the `transaction.payload.byte_count` from the `transfer.payload_bytes_remaining` attribute.

If the transaction is either not a SPLIT or is the last complete SPLIT transaction, complete the following steps:

1. Mark the transaction status as ACCEPT using `transaction.status = svt_transaction::ACCEPT`.
2. Trigger the transaction notify that the transaction has ENDED using `transfer.end_tr()`.
3. Provide a copy of the ENDED transaction with the top protocol `uvm_event` that the transaction has ENDED using `svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)`

If the transaction has exceeded the maximum number of allowed errors, VIP aborts the transfer.

Device response if the transaction is a HOST ISOC OUT DATA transaction

If the Host DATA is a legal protocol and has no packet exception errors, VIP calls the following:

1. `transaction.payload.append_payload(packet.payload)`
2. `svt_usb_protocol_callbacks::received_data_packet(svt_usb_protocol component, svt_usb_transfer transfer, svt_usb_packet packet)`

If the transaction is non-SPLIT or last start SPLIT, VIP calls the following:

1. `transaction.status = svt_transaction::ACCEPT`
2. `transfer.end_tr()`
3. `svt_usb_protocol::NOTIFY_USB_TRANSACTION_ENDED.trigger(transaction.clone)`
4. `transfer.payload.append_payload(transaction.payload)`

If the transaction has exceeded the maximum number of allowed errors, VIP aborts the transfer.

5. To repeat the transaction loop, go back to the flow at the top of the transaction loop. Otherwise, the transaction has already been marked ENDED and the callback to `transaction_ended` is now made using `svt_usb_protocol_callbacks::transaction_ended (svt_usb_protocol component, svt_usb_transfer transfer, int transaction_ix)`.

4.2.10 Link Callback, Factory and UVM Event Flows for USB 3.1 VIP

This section explains the various link-layer flows through the use of flowcharts. Figures 4-5 to 4-15 illustrate the various SS link component flows.



Note

In the following flow charts, the abbreviation “cb” has been used to denote `svt_usb_link_callbacks`.

4.2.11 SuperSpeed Packet Chronology


This section describes the timing of packets on the bus. Possible outcomes of low-level packet exchange on the bus are represented by the events and status values of the packet data objects within the VIP.

4.2.11.1 Receiving LBAD

4.2.11.1.1 During DPP Tx

An LBAD link command is received during the transmission of a DPP payload. The super-speed transmitter continues producing the payload to completion.

Figure 4-6 Packet Chronology: Receiving LBAD During DPP Tx



At point “A” the following packet attributes are updated:

- ❖ status attribute is set to ACTIVE
- ❖ header_status is set to ACTIVE
- ❖ notify.indicate STARTED
- ❖ start_time is set to \$realtime

- ❖ packet_start_time is set to \$realtime

At point “B” the following packet attributes are updated:

- ❖ header_status is set to ACCEPT
- ❖ payload_status is set to ACTIVE
- ❖ packet_header_end_time is set to \$realtime

At point “C” the following packet attributes are updated:

- ❖ link_command_response is stored

At point “D” the following packet attributes are updated:

- ❖ status attribute is set to RETRY
- ❖ payload_status attribute is set to ACCEPT
- ❖ packet_end_time is set to \$realtime
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0


Table 4-2 Status Attribute Chronology: Receiving LBAD During DPP Tx

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “C”	at Point “D”
status	INITIAL	ACTIVE	ACTIVE	ACTIVE	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ACTIVE	ACCEPT
payload_presence	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT

4.2.11.1.2 During DPP Tx, EDB Result

An LBAD link command is received during the transmission of a DPP payload. The super-speed transmitter aborts production of the payload and ends the DPP with appropriate EDB framing.

Figure 4-7 Packet Chronology: Receiving LBAD During DPP Tx, EDB Result



At points “A” through “C” the events are identical to [Figure 4-6](#) at points “A” through “C”

At point “M” the following packet attributes are updated:

- ❖ status attribute is set to RETRY
- ❖ payload_status attribute is set to ACCEPT
- ❖ payload_presence is set to PAYLOAD_PRESENT_BUT_ABORTED
- ❖ packet_end_time is set to \$realtime
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0


Table 4-3 Status Attribute Chronology: Receiving LBAD During DPP Tx, EDB Result

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “C”	at Point “M”
status	INITIAL	ACTIVE	ACTIVE	ACTIVE	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ACTIVE	ACCEPT
payload_presence	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT_BUT_ABORTED

4.2.11.1.3 After DPP Tx Complete

An LBAD link command is received after the complete transmission of a DPP payload.

Figure 4-8 Packet Chronology: Receiving LBAD After DPP Tx Complete



At points “A” and “B” the events are identical to [Figure 4-6](#) at points “A” and “B”

At point “E” the following packet attributes are updated:

- ❖ status attribute is set to PARTIAL_ACCEPT
- ❖ payload_status is set to ACCEPT
- ❖ packet_end_time is set to \$realtime

At point “F” the following packet attributes are updated:

- ❖ link_command_response is stored
- ❖ status attribute is set to RETRY


- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-4 Status Attribute Chronology: Receiving LBAD After DPP Tx Complete

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “E”	at Point “F”
status	INITIAL	ACTIVE	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ACCEPT	ACCEPT
payload_presence	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT

4.2.11.1.4 After HP, No DPP

An LBAD link command is received after the complete transmission of Header Packet data; no payload is associated to the header (this could be a TP, ISOC, ITP or LMP packet).

Figure 4-9 Packet Chronology: Receiving LBAD After HP, No DPP

At point “A” the events are identical to [Figure 4-6](#) at point “A”

At point “B” the following packet attributes are updated:

- ❖ status is set to PARTIAL_ACCEPT
- ❖ header_status is set to ACCEPT
- ❖ packet_header_end_time is set to \$realtime
- ❖ packet_end_time is set to \$realtime

At point “G” the following packet attributes are updated:

- ❖ link_command_response is stored
- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0


- ❖ packet_end_time attribute is reset to 0

Table 4-5 Status Attribute Chronology: Receiving LBAD After HP, No DPP

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	INITIAL	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT
payload_status	DISABLED	DISABLED	DISABLED	DISABLED
payload_presence	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT

4.2.11.1.5 After Data Packet Retry

An LBAD link command is received command is after the complete transmission of replayed Data Packet; no payload is associated to the replay packet.

Figure 4-10 Packet Chronology: Receiving LBAD After Data Packet Retry

At point “A” the following packet attributes are updated:

- ❖ status attribute is set to ACTIVE
- ❖ header_status is set to ACTIVE
- ❖ payload_status is set to CANCELLED
- ❖ payload_presence is set to PAYLOAD_NOT_PRESENT
- ❖ packet_start_time is set to \$realtime

At point “B” the following packet attributes are updated:

- ❖ status is set to PARTIAL_ACCEPT
- ❖ header_status is set to ACCEPT
- ❖ packet_header_end_time is set to \$realtime
- ❖ packet_end_time is set to \$realtime

At point “G” the following packet attributes are updated:

- ❖ link_command_response is stored
- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0


- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-6 Status Attribute Chronology: Receiving LBAD After Data Packet Retry

	Prior to Point "A"	at Point "A"	at Point "B"	at Point "G"
status	RETRY	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	RETRY	ACTIVE	ACCEPT	ACCEPT
payload_status	(various possible)	CANCELLED	CANCELLED	CANCELLED
payload_presence	(various possible)	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT

4.2.11.1.6 After Non-Data Packet Retry

An LBAD link command is received command is after the complete transmission of replayed Data Packet; no payload is associated to the replay packet.

Figure 4-11 Packet Chronology: Receiving LBAD After Non-Data Packet Retry

At point "A" the following packet attributes are updated:

- ❖ status attribute is set to ACTIVE
- ❖ header_status is set to ACTIVE
- ❖ packet_start_time is set to \$realtime

At point "B" the following packet attributes are updated:

- ❖ status is set to PARTIAL_ACCEPT
- ❖ header_status is set to ACCEPT
- ❖ packet_header_end_time is set to \$realtime
- ❖ packet_end_time is set to \$realtime

At point "G" the following packet attributes are updated:

- ❖ link_command_response is stored
- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0

- ❖ packet_end_time attribute is reset to 0


Table 4-7 Status Attribute Chronology: Receiving LBAD After Non-Data Packet Retry

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	RETRY	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	RETRY	ACTIVE	ACCEPT	ACCEPT
payload_status	DISABLED	DISABLED	DISABLED	DISABLED
payload_presence	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT

4.2.11.2 Receiving TS1 Ordered Sets

4.2.11.2.1 During DPP Tx

A TS1 ordered set is received during the transmission of a DPP payload (due to the link partner entering recovery state). The super-speed transmitter continues producing the payload to completion. After recovery, the LGOOD advertisement indicates a header sequence number prior to the DPP in question (such that the DPP packet will be replayed).

Figure 4-12 Packet Chronology: Receiving TS1 ordered sets During DPP Tx

At points “A” and “B” the events are identical to [Figure 4-6](#) at points “A” and “B”

At point “C” the following packet attributes are updated:

- ❖ status is set to PARTIAL_ACCEPT
- ❖ payload_status is set to ACCEPT
- ❖ packet_end_time is set to \$realtime

At point “D” the following packet attributes are updated:


- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-8 Status Attribute Chronology: Receiving TS1 Ordered Sets During DPP Tx

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “C”	at Point “D”
status	INITIAL	ACTIVE	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ACCEPT	ACCEPT
payload_presence	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT

4.2.11.2.2 During DPP Tx, EDB Result

A TS1 ordered set is received during the transmission of a DPP payload (due to the link partner entering recovery state). The super-speed transmitter aborts production of the payload and ends the DPP with appropriate EDB framing. After recovery, the LGOOD advertisement indicates a header sequence number prior to the DPP in question (such that the DPP packet will be replayed).

Figure 4-13 Packet Chronology: Receiving TS1 Ordered Sets During DPP Tx, EDB Result

At points “A” and “B” the events are identical to [Figure 4-6](#) at points “A” and “B”

At point “C” the following packet attributes are updated:

- ❖ status is set to PARTIAL_ACCEPT
- ❖ payload_status is set to ABORTED
- ❖ payload_presence is set to PAYLOAD_PRESENT_BUT_ABORTED
- ❖ packet_end_time is set to \$realtime

At point “D” the following packet attributes are updated:


- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-9 Status Attribute Chronology: Receiving TS1 Ordered Sets During DPP Tx, EDB Result

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “C”	at Point “D”
status	INITIAL	ACTIVE	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ABORTED	ABORTED
payload_presence	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT	PAYLOAD_PRESENT_BUT_ABORTED	PAYLOAD_PRESENT_BUT_ABORTED

4.2.11.2.3 After DPP Tx Complete

A TS1 ordered set is received after the complete transmission of a DPP payload (due to the link partner entering recovery state). After recovery, the LGOOD advertisement indicates a header sequence number prior to the DPP in question (such that the DPP packet will be replayed).

Figure 4-14 Packet Chronology: Receiving TS1 Ordered Sets After DPP Tx Complete

At points “A” through “C” the events are identical to [Figure 4-8](#) at points “A” through “C”

At point “F” the following packet attributes are updated:

- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-10 Status Attribute Chronology: Receiving TS1 Ordered Sets After DPP Tx Complete


	Prior to Point “A”	at Point “A”	at Point “B”	at Point “C”	at Point “F”
status	INITIAL	ACTIVE	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ACCEPT	ACCEPT

Table 4-10 Status Attribute Chronology: Receiving TS1 Ordered Sets After DPP Tx Complete

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “C”	at Point “F”
payload_presence	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT

4.2.11.2.4 After HP, No DPP

A TS1 ordered set is received after the complete transmission of Header Packet data (due to the link partner entering recovery state). No payload is associated to the header (this could be a TP, ISOC, ITP or LMP packet). After recovery, the LGOOD advertisement indicates a header sequence number prior to the DPH in question (such that the DPH packet will be replayed).

Figure 4-15 Packet Chronology: Receiving TS1 Ordered Sets After HP, No DPP

At points “A” and “B” the events are identical to [Figure 4-9](#) at points “A” and “B”

At point “G” the following packet attributes are updated:


- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-11 Status Attribute Chronology: Receiving TS1 Ordered Sets After HP, No DPP

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	INITIAL	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT
payload_status	DISABLED	DISABLED	DISABLED	DISABLED
payload_presence	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT

4.2.11.2.5 After Data Packet Retry

A TS1 ordered set is received after the complete transmission of a replay Data Packet; no payload is associated to the replay packet. After recovery, the LGOOD advertisement indicates a header sequence number prior to the DPH in question (such that the DPH packet will be replayed).

Figure 4-16 Packet Chronology: Receiving TS1 Ordered Sets After Data Packet Retry

At points “A” and “B” the events are identical to [Figure 4-10](#) at points “A” and “B”

At point “G” the following packet attributes are updated:


- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-12 Status Attribute Chronology: Receiving TS1 Ordered Sets After Data Packet Retry

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	RETRY	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	RETRY	ACTIVE	ACCEPT	ACCEPT
payload_status	(various possible)	CANCELLED	CANCELLED	CANCELLED
payload_presence	(various possible)	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT

4.2.11.2.6 After Non-Data Packet Retry

A TS1 ordered set is received after the complete transmission of a replay packet (due to the link partner entering recovery state). No payload was previously associated with this header (this could be a TP, ISOC, ITP or LMP packet). After recovery, the LGOOD advertisement indicates a header sequence number prior to the DPH in question (such that the DPH packet will be replayed).

Figure 4-17 Packet Chronology: Receiving TS1 Ordered Sets After Data Packet Retry

At points “A” and “B” the events are identical to [Figure 4-9](#) at points “A” and “B”

At point “G” the following packet attributes are updated:

- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-13 Status Attribute Chronology: Receiving TS1 Ordered Sets After Data Packet Retry


	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	RETRY	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	RETRY	ACTIVE	ACCEPT	ACCEPT
payload_status	DISABLED	DISABLED	DISABLED	DISABLED
payload_presence	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT

4.2.11.3 Transmitting TS1 Ordered Sets

4.2.11.3.1 After HP Tx

The link layer can transition to recovery state after transmitting a Header Packet No payload is associated with this header (this could be a TP, ISOC, ITP or LMP packet).

Figure 4-18 Packet Chronology: Transmitting TS1 Ordered Sets After HP Tx



At points “A” and “B” the events are identical to [Figure 4-9](#) at points “A” and “B”

At point “P” the following packet attributes are updated:


- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0

Table 4-14 Status Attribute Chronology: Transmitting TS1 Ordered Sets After HP Tx

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	INITIAL	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT
payload_status	DISABLED	DISABLED	DISABLED	DISABLED
payload_presence	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT

4.2.11.3.2 After DPP Tx

The link layer can transition to recovery state after transmitting a Header Packet with DPP payload.

Figure 4-19 Packet Chronology: Transmitting TS1 Ordered Sets After DPP Tx

At points “A” through “E” the events are identical to [Figure 4-8](#) at points “A” through “E”

At point “N” the following packet attributes are updated:

- ❖ status attribute is set to RETRY
- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0


Table 4-15 Status Attribute Chronology: Transmitting TS1 Ordered Sets After DPP Tx

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “E”	at Point “F”
status	INITIAL	ACTIVE	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ACCEPT	ACCEPT
payload_presence	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT

4.2.11.3.3 After Data Packet Retry

The link layer can transition to recovery state after transmitting a replay Data Packet; no payload is associated to the replay packet.

Figure 4-20 Packet Chronology: Transmitting TS1 Ordered Sets After Data Packet Retry



Events at points “A” through “G” are identical to [Figure 4-10](#) events at points “A” through “G”


Table 4-16 Status Attribute Chronology: Transmitting TS1 Ordered Sets After Data Packet Retry

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	RETRY	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	RETRY	ACTIVE	ACCEPT	ACCEPT
payload_status	(various possible)	CANCELLED	CANCELLED	CANCELLED
payload_presence	(various possible)	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT	PAYLOAD_NOT_PRESENT

4.2.11.3.4 After Non-Data Packet Retry

The link layer can transition to recovery state after transmitting a replay Data Packet. No payload was previously associated with this header (this could be a TP, ISOC, ITP or LMP packet). After recovery, the LGOOD advertisement indicates a header sequence number prior to the DPH in question (such that the DPH packet will be replayed).

Figure 4-21 Packet Chronology: Transmitting TS1 Ordered Sets After Non-Data Packet Retry



At points “A” and “B” the events are identical to [Figure 4-9](#) at points “A” and “B”

At point “P” the following packet attributes are updated:

- ❖ status attribute is set to RETRY

- ❖ trace is stored for transmitted packet
- ❖ packet_start_time attribute is reset to 0
- ❖ packet_header_end_time attribute is reset to 0
- ❖ packet_end_time attribute is reset to 0


Table 4-17 Status Attribute Chronology: Transmitting TS1 Ordered Sets After Non-Data Packet Retry

	Prior to Point "A"	at Point "A"	at Point "B"	at Point "G"
status	RETRY	ACTIVE	PARTIAL_ACCEPT	RETRY
header_status	RETRY	ACTIVE	ACCEPT	ACCEPT
payload_status	DISABLED	DISABLED	DISABLED	DISABLED
payload_presence	PAYLOAD_NOT_PRE SENT	PAYLOAD_NOT_PRE SENT	PAYLOAD_NOT_PRE SENT	PAYLOAD_NOT_PRE SENT

4.2.11.4 Receiving LGOOD

4.2.11.4.1 During DPP Tx

An LGOOD link command is received (for the currently active packet) during the transmission of a DPP payload.

Figure 4-22 Packet Chronology: Receiving LGOOD During DPP Tx

At points "A" through "C" the events are identical to [Figure 4-6](#) at points "A" through "C"

At point "D" the following packet attributes are updated:


- ❖ status attribute is set to ACCEPT
- ❖ payload_status is set to ACCEPT
- ❖ packet_end_time is set to \$realtime
- ❖ end_time is set to \$realtime
- ❖ trace is stored for transmitted packet
- ❖ notify indicated uvm_event end_event (uvm_transaction's end_event field) on packet

Table 4-18 Status Attribute Chronology: Receiving LGOOD During DPP Tx

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “C”	at Point “D”
status	INITIAL	ACTIVE	ACTIVE	ACTIVE	ACCEPT
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ACTIVE	ACCEPT
payload_presence	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT

4.2.11.4.2 After DPP Tx Complete

An LGOOD link command is received after the complete transmission of a DPP payload.

Figure 4-23 Packet Chronology: Receiving LGOOD After DPP Tx Complete

At points “A” and “B” the events are identical to [Figure 4-6](#) at points “A” and “B”

At point “E” the following packet attributes are updated:

- ❖ status is set to PARTIAL_ACCEPT
- ❖ payload_status is set to ACCEPT
- ❖ packet_end_time is set to \$realtime

At point “F” the following packet attributes are updated:

- ❖ status attribute is set to ACCEPT
- ❖ end_time is set to \$realtime
- ❖ trace is stored for transmitted packet
- ❖ notify on uvm_event end_event (uvm_transaction’s end_event field) on packet

Table 4-19 Status Attribute Chronology: Receiving LGOOD After DPP Tx Complete


	Prior to Point “A”	at Point “A”	at Point “B”	at Point “E”	at Point “F”
status	INITIAL	ACTIVE	ACTIVE	PARTIAL_ ACCEPT	ACCEPT
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT	ACCEPT
payload_status	INITIAL	INITIAL	ACTIVE	ACCEPT	ACCEPT

Table 4-19 Status Attribute Chronology: Receiving LGOOD After DPP Tx Complete

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “E”	at Point “F”
payload_presence	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT	PAYLOAD_ PRESENT

4.2.11.4.3 After HP, No DPP

An LGOOD link command is received after the complete transmission of Header Packet data; no payload is associated to the header (this could be a TP, ISOC, ITP or LMP packet).

Figure 4-24 Receiving LGOOD After HP, No DPP

At points “A” and “B” the events are identical to [Figure 4-9](#) at points “A” and “B”

At point “G” the following packet attributes are updated:


- ❖ status attribute is set to ACCEPT
- ❖ end_time is set to \$realtime
- ❖ trace is stored for transmitted packet
- ❖ notify indicated uvm_event end_event (uvm_transaction’s end_event field) on packet

Table 4-20 Status Attribute Chronology: Receiving LGOOD After HP, No DPP

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	INITIAL	ACTIVE	PARTIAL_ACCEPT	ACCEPT
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT
payload_status	DISABLED	DISABLED	DISABLED	DISABLED
payload_presence	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT

4.2.11.4.4 After Data Packet Retry

An LGOOD link command is received after the complete transmission of replay Data Packet; no payload is associated to the replay packet.

Figure 4-25 Packet Chronology: Receiving LGOOD After Data Packet Retry

Events at points “A” and “B” are identical to [Figure 4-10](#) events at points “A” and “B”

At point “G” the following packet attributes are updated:


- ❖ status is set to ACCEPT
- ❖ end_time is set to \$realtime
- ❖ trace is stored for transmitted packet
- ❖ notify indicated uvm_event end_event (uvm_transaction’s end_event field) on packet

Table 4-21 Status Attribute Chronology: Receiving LGOOD After Data Packet Retry

	Prior to Point “A”	at Point “A”	at Point “B”	at Point “G”
status	INITIAL	ACTIVE	PARTIAL_ACCEPT	ACCEPT
header_status	INITIAL	ACTIVE	ACCEPT	ACCEPT
payload_status	(various possible)	DISABLED	DISABLED	DISABLED
payload_presence	(various possible)	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT

4.2.11.4.5 After Non-Data Packet Retry

An LGOOD link command is received after the complete transmission of replay Data Packet; no payload was previously associated with this header (this could be a TP, ISOC, ITP or LMP packet).

Figure 4-26 Packet Chronology: Receiving LGOOD After Non-Data Packet Retry

At point “A” and “B” the events are identical to [Figure 4-6](#) at points “A” and “B”

At point “G” the following packet attributes are updated:

- ❖ status is set to ACCEPT

- ❖ end_time is set to \$realtime
- ❖ trace is stored for transmitted packet
- ❖ notify indicated uvm_event end_event (uvm_transaction's end_event field) on packet

Table 4-22 Status Attribute Chronology: Receiving LGOOD After Non-Data Packet Retry

	Prior to Point "A"	at Point "A"	at Point "B"	at Point "G"
status	RETRY	ACTIVE	PARTIAL_ACCEPT	ACCEPT
header_status	RETRY	ACTIVE	ACCEPT	ACCEPT
payload_status	DISABLED	DISABLED	DISABLED	DISABLED
payload_presence	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT	PAYLOAD_ NOT_PRESENT

5

Verification Topologies


This chapter presents several agent testbench topologies. In addition to a brief description of the testbench topologies, each section lists configuration parameters required to instantiate the VIP agent. This chapter discusses the following topics:

- ❖ [USB VIP Host and DUT Device Controller](#)
- ❖ [USB VIP Device and DUT Host Controller](#)
- ❖ [USB VIP Host and DUT Device PHY](#)
- ❖ [USB VIP Host and DUT Device](#)
- ❖ [USB VIP Device and DUT Host](#)
- ❖ [USB VIP Device and DUT Host – Concurrent SS and 2.0 Traffic](#)
- ❖ [USB VIP Device with Hub Emulation and DUT Host – Concurrent Serial Interface Traffic](#)

5.1 USB VIP Host and DUT Device Controller

This topology consists of a VIP that tests a USB device controller. The VIP contains local protocol, link, and physical layers that emulates a USB host, along with a remote physical layer that emulates a USB device PHY. The VIP and the DUT connect through a PIPE3 interface.

In addition to a valid `cfg` object of type `svt_usb_agent_configuration`, the presence of a remote physical layer requires the end user to provide a handle to a valid `remote_cfg` object of type `svt_usb_configuration`.

Figure 5-1 USB VIP Host and DUT Device Controller

Implementation of this topology requires the setting of the following properties:

❖ **cfg object – representing the host vip**

```
svt_usb_types::component_type_enum component_type = svt_usb_types::HOST;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = MAC
usb_ss_signal_interface_enum usb_ss_signal_interface = USB_SS_TLM;
usb_capability_enum usb_capability = USB_SS_ONLY;
svt_usb_device_configuration remote_device_cfg[$];
svt_usb_endpoint_configuration endpoint_cfg[$];
int unsigned num_endpoints = 1;
int remote_device_cfg_size = 1;
```

❖ **remote_cfg – representing the remote phy's properties**


```
svt_usb_types::component_type_enum component_type = svt_usb_types::DEVICE;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = PHY;
usb_ss_signal_interface_enum usb_ss_signal_interface = PIPE_IF;
usb_capability_enum usb_capability = USB_SS_ONLY;
```

5.2 USB VIP Device and DUT Host Controller

This topology consists of a VIP that tests a USB host controller. The VIP contains local protocol, link, and physical layers that emulates a USB device, along with a remote physical layer that emulates a USB device PHY. The VIP and the DUT connect through a PIPE3 interface.

In addition to a valid `cfg` object of type `svt_usb_agent_configuration`, the presence of a remote physical layer requires the end user to provide a handle to a valid `remote_cfg` object of type `svt_usb_configuration`.

Figure 5-2 USB VIP Device and DUT Host Controller



Implementation of this topology requires the setting of the following properties:

- ❖ **cfg object (representing the device vip)**

```
svt_usb_types::component_type_enum component_type = svt_usb_types::DEVICE;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = MAC
usb_ss_signal_interface_enum usb_ss_signal_interface = USB_SS_TLM;
usb_capability_enum usb_capability = USB_SS_ONLY;
svt_usb_host_configuration remote_host_cfg;
svt_usb_device_configuration local_device_cfg[$];
```

- ❖ `remote_cfg` (representing the remote phy's properties)


```
svt_usb_types::component_type_enum component_type = svt_usb_types::HOST;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = PHY;
usb_ss_signal_interface_enum usb_ss_signal_interface = PIPE3_IF;
usb_capability_enum usb_capability = USB_SS_ONLY;
```

5.3 USB VIP Host and DUT Device PHY

This topology consists of two VIP instances and a USB Device PHY. The host VIP contains local protocol, link, and physical layers that connect to the DUT through serial interface. The device VIP contains local, link, and physical layers that connect to the local DUT through a PIPE3 interface.

Each VIP instance requires a valid `cfg` object of type `svt_usb_agent_configuration`.

Figure 5-3 USB3 VIP Host and DUT Device PHY



Implementation of this topology requires the setting of the following properties:

❖ **cfg object (representing the host vip)**

```
svt_usb_types::component_type_enum component_type = svt_usb_types::HOST;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = MAC
usb_capability_enum usb_capability = USB_SS_ONLY;
svt_usb_device_configuration remote_device_cfg[$] ;
svt_usb_endpoint_configuration endpoint_cfg[$];
int unsigned num_endpoints = 1;
int remote_device_cfg_size = 1; (size needs to be greater than or equal to 1)
```

❖ **cfg object (representing the device vip)**


```
svt_usb_types::component_type_enum component_type = svt_usb_types::DEVICE;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = MAC
usb_ss_signal_interface_enum usb_ss_signal_interface = USB_SS_SERIAL_IF;
usb_capability_enum usb_capability = USB_SS_ONLY;
svt_usb_device_configuration local_device_cfg[$] ;
svt_usb_endpoint_configuration endpoint_cfg[$];
int unsigned num_endpoints = 1;
int remote_device_cfg_size = 1; (size needs to be greater than or equal to 1)
```

5.4 USB VIP Host and DUT Device

This topology consists of a VIP that tests a USB device. The VIP contains local protocol, link, and physical layers that emulates a USB host. The VIP and the DUT connect through a serial interface.

The VIP instance requires a valid cfg object of type `svt_usb_agent_configuration`. This section provides configuration objects for SS and 2.0 serial interfaces.

Figure 5-4 USB3 VIP Host and DUT Device



Implementation of this topology requires the setting of the following properties:

❖ Simulating a SS (only) serial bus

```
svt_usb_types::component_type_enum component_type = svt_usb_types::HOST;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = MAC
usb_ss_signal_interface_enum usb_ss_signal_interface = USB_SS_SERIAL_IF;
usb_capability_enum usb_capability = USB_SS_ONLY;
svt_usb_device_configuration remote_device_cfg[$] ;
svt_usb_endpoint_configuration endpoint_cfg[$];
int unsigned num_endpoints = 1;
int remote_device_cfg_size = 1; (size needs to be greater than or equal to 1)
```

❖ Simulating a 2.0 (only) serial bus setting


```
svt_usb_types::component_type_enum component_type = svt_usb_types::HOST;
svt_usb_types::speed_enum speed = svt_usb_types::HS; (other speeds FS/LS)
component_subtype_enum component_subtype = MAC
usb_20_signal_interface_enum usb_20_signal_interface = USB_20_SERIAL_IF;
usb_capability_enum usb_capability = USB_20_ONLY;
svt_usb_device_configuration remote_device_cfg[$] ;
svt_usb_endpoint_configuration endpoint_cfg[$];
int unsigned num_endpoints = 1;
int remote_device_cfg_size = 1; (size needs to be greater than or equal to 1)
```

5.5 USB VIP Device and DUT Host

This topology consists of a VIP that tests a USB host. The VIP contains local protocol, link, and physical layers that emulates a USB device. The VIP and the DUT connect through a serial interface.

The VIP instance requires a valid cfg object of type `svt_usb_agent_configuration`. This section provides configuration objects for SS and 2.0 serial interfaces.

Figure 5-5 USB3 VIP Device and DUT Host



Implementation of this topology requires the setting of the following properties:

❖ Simulating a SS (only) serial bus

```
svt_usb_types::component_type_enum component_type = svt_usb_types::DEVICE;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = MAC
usb_ss_signal_interface_enum usb_ss_signal_interface = USB_SS_SERIAL_IF;
usb_capability_enum usb_capability = USB_SS_ONLY;
svt_usb_device_configuration remote_host_cfg;
svt_usb_device_configuration local_device_cfg[$];
```

❖ Simulating a 2.0 (only) serial bus


```
svt_usb_types::component_type_enum component_type = svt_usb_types::DEVICE;
svt_usb_types::speed_enum speed = svt_usb_types::HS; (other speeds FS/LS)
component_subtype_enum component_subtype = MAC
usb_20_signal_interface_enum usb_20_signal_interface = USB_20_SERIAL_IF;
usb_capability_enum usb_capability = USB_20_ONLY;
svt_usb_host_configuration remote_host_cfg ;
svt_usb_device_configuration local_device_cfg ;
int local_device_cfg_size = 1; (size needs to be greater than or equal to 1)
```

5.6 USB VIP Device and DUT Host – Concurrent SS and 2.0 Traffic

This topology consists of a VIP that tests a USB host. The VIP contains local protocol, link, and physical layers that emulates a USB device. The VIP and the DUT connect through a serial interface that provides concurrent SS and 2.0 traffic.

The VIP instance requires a valid `cfg` object of type `svt_usb_agent_configuration`.

Figure 5-6 USB3 VIP Device and DUT Host – Concurrent SS and 2.0 Traffic



Implementation of this topology requires the setting of the following properties:

❖ Simulating a SS and 2.0 serial bus

```
svt_usb_types::component_type_enum component_type = svt_usb_types::DEVICE;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = MAC
usb_ss_signal_interface_enum usb_ss_signal_interface = USB_SS_SERIAL_IF;
usb_20_signal_interface_enum usb_20_signal_interface = USB_20_SERIAL_IF;
usb_capability_enum usb_capability = USB_SS_CAPABLE;
svt_usb_device_configuration remote_host_cfg;
svt_usb_device_configuration local_device_cfg[$];
int local_device_cfg_size = 1; (size needs to be greater than or equal to 1)
```

5.7 USB VIP Device with Hub Emulation and DUT Host – Concurrent Serial Interface Traffic


This topology consists of a VIP that tests a USB host. The VIP contains local protocol, link, and physical layers that emulates a USB device with a hub. The VIP and the DUT connect through a serial interface that provides concurrent SS and 2.0 traffic.

The VIP instance requires a valid `cfg` object of type `svt_usb_agent_configuration`.



Note This is NOT a hub model that supports multiple ports. The hub emulation mode is to test a single downstream port communicating with multiple device addresses and configurations.

Figure 5-7 USB3 VIP Device with Hub Emulation and DUT Host – Concurrent Serial Interface Traffic



Implementation of this topology requires the setting of the following properties:

❖ **Simulating a SS and 20 serial bus between Host downstream and Hub's upstream port.**

```
svt_usb_types::component_type_enum component_type = svt_usb_types::DEVICE;
svt_usb_types::speed_enum speed = svt_usb_types::SS;
component_subtype_enum component_subtype = MAC
usb_ss_signal_interface_enum usb_ss_signal_interface = USB_SS_SERIAL_IF;
usb_20_signal_interface_enum usb_20_signal_interface = USB_20_SERIAL_IF;
usb_capability_enum usb_capability = USB_SS_CAPABLE;
svt_usb_device_configuration remote_host_cfg;
svt_usb_device_configuration local_device_cfg[$];
int local_device_cfg_size = 1; (size needs to be greater than or equal to 1)
bit hub_emulation_mode = 1'b1;
```


6

Usage Notes

This chapter presents UVM concepts and techniques for quickly achieving a basic constrained random testbench that incorporates the USB VIP. Code snippets illustrate these methods in practical use. The testbench shows typical USB VIP and SystemVerilog UVM usage, and highlights the concepts and techniques described. These techniques can be used with any of the VIP products. This chapter discusses the following topics:

- ❖ [Setting Verbosity Levels](#)
- ❖ [SystemVerilog UVM Example Testbenches](#)
- ❖ [Configuring VIP Using Configuration Creator](#)
- ❖ [Protocol Feature](#)
- ❖ [Implementing Functional Coverage](#)
- ❖ [Using the Passive Monitor](#)

6.1 Setting Verbosity Levels

You can set the VIP debug verbosity levels either in the testbench or as an option during run-time.

6.1.1 Setting Verbosity in the Testbench

To set the verbosity level in the testbench, use the UVM-specified log-levels in the code. The components are extended from `uvm_report_object`.

You can use the following `uvm_report_object` method to change the verbosity for the host (for example):

```
vip_usb_host.set_report_verbosity_level(<level>);
```

Where the following define all of the possible <levels>:

- ❖ `UVM_NONE` - Report is always printed, verbosity level setting can not disable it.
- ❖ `UVM_LOW` - Report is issued if configured verbosity is set to `UVM_LOW` or above.
- ❖ `UVM_MEDIUM` - Report is issued if configured verbosity is set to `UVM_MEDIUM` or above.
- ❖ `UVM_HIGH` - Report is issued if configured verbosity is set to `UVM_HIGH` or above.
- ❖ `UVM_FULL` - Report is issued if configured verbosity is set to `UVM_FULL` or above.

6.1.2 Setting Verbosity During Run Time

To set the verbosity level during run-time, you can use one of the following methods:

- ❖ “Method 1: To Enable the Specified Severity in the VIP, DUT, and Testbench”
- ❖ “Method 2: To Enable the Specified Severity to Specific Sub-Classes of VIP”

6.1.2.1 Method 1: To Enable the Specified Severity in the VIP, DUT, and Testbench

Use Example: VCS

```
vcs <other run time options> +UVM_VERBOSITY=UVM_HIGH
```

6.1.2.2 Method 2: To Enable the Specified Severity to Specific Sub-Classes of VIP



Note

Only applies to 'types' (for example, `svt_usb_physical`). [Table 6-1](#) lists the valid VIP sub-units that you can use.

The following instance verbosity is supported by UVM directly:

```
+uvm_set_verbosity=component_name,id,verbosity,phase_name,optional_time
```

Use Example: VCS

```
vcs <other run time options> -R
+vip_verbosity=svt_usb_link_ss_lcm:UVM_LOW,svt_usb_link_ss_ltssm_base:UVM_HIGH,
svt_usb_physical:UVM_HIGH,svt_usb_link_ss_tx:UVM_HIGH
```

The levels can be as follows:

```
`define SVT_FATAL_VERBOSITY    UVM_NONE
`define SVT_ERROR_VERBOSITY    UVM_NONE
`define SVT_WARNING_VERBOSITY  UVM_NONE
`define SVT_NORMAL_VERBOSITY   UVM_LOW
`define SVT_TRACE_VERBOSITY    UVM_MEDIUM
`define SVT_DEBUG_VERBOSITY    UVM_HIGH
`define SVT_VERBOSE_VERBOSITY  UVM_FULL
```

Table 6-1 Valid VIP Sub-Units

Layer	Sub-unit or Component
Entire agent	svt_usb_agent
Protocol Layer - SS:	<ul style="list-style-type: none"> svt_usb_protocol svt_usb_protocol_block svt_usb_protocol_device svt_usb_protocol_processor svt_usb_protocol_ss_host svt_usb_protocol_ss_host_non_isoc_ep_processor svt_usb_protocol_ss_host_isoc_ep_processor svt_usb_protocol_ss_device svt_usb_protocol_ss_device_non_isoc_ep_processor svt_usb_protocol_ss_device_isoc_ep_processor svt_usb_protocol_scheduler svt_usb_protocol_host_scheduler svt_usb_protocol_device_scheduler svt_usb_protocol_ss_host_isoc_ep_processor svt_usb_protocol_ss_device_isoc_ep_processor svt_usb_protocol_ss_lmp_processor svt_usb_protocol_ss_itp_processor
Protocol Layer - <protocol> 2.0	<ul style="list-style-type: none"> svt_usb_protocol_processor svt_usb_protocol_20_host_non_isoc_ep_processor svt_usb_protocol_20_host_isoc_ep_processor svt_usb_protocol_20_device_non_isoc_ep_processor svt_usb_protocol_20_device_isoc_ep_processor svt_usb_protocol_block svt_usb_protocol_20_host svt_usb_protocol_20_device svt_usb_protocol_20_lpm_processor svt_usb_protocol_20_sof_processor
Link layer-SS:	<ul style="list-style-type: none"> svt_usb_link_ss_tx svt_usb_link_ss_rx svt_usb_link_ss_ltssm_base svt_usb_link_ss_lcm
Link layer-<protocol> 2.0	<ul style="list-style-type: none"> svt_usb_link_20 svt_usb_link_20_device_a_sm svt_usb_link_20_device_b_sm svt_usb_link_20_timer
Physical Layer	svt_usb_physical

6.2 SystemVerilog UVM Example Testbenches

This section describes SystemVerilog UVM example testbenches that show general usage for various applications. A summary of the examples is listed in [Table 6-2](#).

Table 6-2 System Verilog Example Summary

Name	Source in design_dir/Description
Basic Example --Demonstrates how to implement a UVM testbench using USB VIP with SS Serial interface. This example consists of a top-level testbench, a Verilog hdl_interconnect, a UVM verification environment, a host and device agent components, one test file with an sequence, and two directed tests.	
tb_usb_svt_uvm_basic_sys	examples/sverilog/usb_svt/tb_usb_svt_uvm_basic_sys/
Intermediate Example --Builds on the Basic UVM Example by adding coverage and a scoreboard.	
tb_usb_svt_uvm_intermediate_sys	examples/tb_usb_svt_uvm_intermediate_syst

For more information, see section [“Downloading From SolvNetPlus and Installing”](#).

6.3 Configuring VIP Using Configuration Creator

To run Configuration Creator, type the following command in a shell:

```
$DESIGNWARE_HOME/bin/vipcc
```



Note

Configuration creator(vip_cc_<version_no>.run) should be installed separately.

If you have added \$DESIGNWARE_HOME/bin to your path, use the following command:

```
vipcc
```

For more information, see the Configuration Creator Getting Started Guide.

After Configuration Creator is downloaded and installed, product documentation resides at:

```
$DESIGNWARE_HOME/vip/tools/vipcc/latest/doc/
```

Once you finish implementing the configuration setting using Configuration Creator, the tool can generate a <configuration_name>.cfg file which you then load into the VIP. The file contains your configuration settings.

To load the *.cfg file into the VIP, use the load_prop_vals() method. The method definition is on the svt_data object. You should call it on the svt_usb_agent_configuration object instance. The following code snippet illustrates how to use the load_prop_vals() method to load a configuration file.

```
svt_usb_agent_configuration cfg = new();
if (cfg.load_prop_vals(filename)) begin
    $display("Successfully loaded svt_usb_agent_configuration using '%0s'.",
            filename);
    if (cfg.is_valid(0)) begin
        $display("svt_usb_agent_configuration loaded using '%0s' is valid.",
            filename);
    end else begin
        $display("ERROR: svt_usb_agent_configuration loaded using '%0s' is
            NOT valid.", filename);
    end
end else begin
    $display("ERROR: Failed attempting to load svt_usb_agent_configuration using
        '%0s'.", filename);
end
end
```

6.4 Protocol Feature

The following are the Protocol features:

- ❖ [SuperSpeed Low Power Entry Support](#)
- ❖ [Executing Aligned Transfers](#)
- ❖ [SuperSpeed Serial LTSSM Flow \(SS.Disabled to U0\)](#)
- ❖ [UTMI+ Support](#)
- ❖ [USB 2.0 OTG Support](#)
- ❖ [HSIC Overview](#)
- ❖ [Using 2.0 Test Mode with UTMI](#)
- ❖ [SuperSpeed InterChip Physical \(SSIC\) Usage](#)

6.4.1 SuperSpeed Low Power Entry Support

6.4.1.1 Overview

Link power management reduces power consumption when link partners are idle. The following Link Training and Status State Machine (LTSSM) operational states manages link power.

- ❖ U0 (link active): The fully operational link active state. Packets of any type may be communicated over links in the U0 state.
- ❖ U1 (link standby with fast exit): Power saving state characterized by fast transition to the U0 State.
- ❖ U2 (link standby with slower exit): Power saving state characterized by greater power savings at the cost of increased exit latency.
- ❖ U3 (suspend): Deep power saving state where portions of device power may be removed except as needed for limited functions.

After software configuration, the U1 and U2 link states are entered and exited through hardware autonomous control. The U3 link state is entered only under software control, typically after a software inactivity timeout expiry, and is exited either by software (host initiated exit) or hardware (remote wakeup). The U3 state is directly coupled to the device's suspend state.

The USB VIP provides support for both automatic and testbench-initiated low-power entry attempts.

6.4.1.2 Automatic Low-Power Entry Attempts

Automatic low-power entry from U0 to U1 is enabled by enabling the U1 inactivity timer. Automatic low-power entry from U0 to U2 is enabled by disabling the U1 inactivity timer and enabling the U2 inactivity timer instead. In each, when the designated amount of time elapses with no bus activity, the downstream port attempts to enter a low-power state by transmitting an LGO_U1 or LGO_U2 link command.

The USB protocol and VIP support the autonomous transition from U1 to U2 when the U2 inactivity timer is enabled for both the upstream and downstream ports. This scenario differs from transition attempts from U0 to U1 or from U0 to U2 in that the U1 transitions to U2 with no other traffic on the bus. Because this transition requires no handshaking, the U2 inactivity timeout values must be the same for both ports.

6.4.1.2.1 Controlling the U1 Inactivity Timer

Two configuration variables control the U1 inactivity timer: `u1_timeout` and `u1_timeout_factor`.

- ❖ `u1_timeout` specifies the U1 inactivity timer enabled status and the U1 inactivity timeout value.
Set `u1_timeout` to 0x00 to disable the U1 inactivity timer. This is the default value.
Set `u1_timeout` to 0xFF to disable the U1 inactivity timer and program the downstream port to reject U1 entry requests initiated by the connected upstream port.
Set `u1_timeout` between 0x01 and 0xFE to enable the U1 inactivity timer.
- ❖ `u1_timeout_factor` specifies the period by which the U1 inactivity timeout value is multiplied to determine the timeout period. The timeout value is

$$(\text{u1_timeout_factor}) \times (\text{u1_timeout}) \times (1 \mu\text{s})$$

`u1_timeout` is an 8-bit array that corresponds to `U1_TIMEOUT` and `PORT_U1_TIMEOUT` in the USB Specification. While the protocol specifies this 8-bit value is multiplied by 1 μs to determine the timeout value, the USB VIP uses the `u1_timeout_factor` as an additional multiplication factor to facilitate scaling while preserving the original timeout value.

6.4.1.2.2 Controlling the U2 Inactivity Timer

The U2 timeout value is represented by two variables: `initial_u2_inactivity_timeout` in the configuration, and `u2_inactivity_timeout` in the status object. The U2 inactivity timer can change dynamically because the Link Management Packet (LMP) can modify the timeout value.

Two configuration variables control the U2 inactivity timer: `u2_timeout` and `u2_timeout_factor`.

- ❖ `u2_timeout` specifies the U2 inactivity timer enabled status and the U2 inactivity timeout value.
Set `u2_timeout` to 0x00 to disable the U2 inactivity timer. This is the default value.
Set `u2_timeout` to 0xFF to disable the U2 inactivity timer and program the downstream port to reject U2 entry requests initiated by the connected upstream port
Set `u2_timeout` between 0x01 and 0xFE to enable the U2 inactivity timer.
- ❖ `u2_timeout_factor` specifies the period by which the U2 inactivity timeout value is multiplied to determine the timeout period. The timeout value is

$$(\text{u2_timeout_factor}) \times (\text{u2_timeout}) \times (256 \mu\text{s})$$

`u2_timeout` is an 8-bit array that corresponds to `U2_TIMEOUT` and `PORT_U2_TIMEOUT` in the USB Specification. While the protocol specifies this 8-bit value is multiplied by 256 μs to determine the timeout value, the USB VIP uses the `u2_timeout_factor` as an additional multiplication factor to facilitate scaling while preserving the original timeout value.

Because a testbench cannot modify the value of any status object variable, the VIP defines a Link Service Command that can modify the U2 inactivity timeout value. Because the link layer of the VIP does not interpret the contents of a U2 Inactivity Timeout LMP, updating the U2 timeout value in the VIP requires that a Link Service Command must accompany the timeout LMP.

When simulation starts, the `initial_u2_inactivity_timeout` value is copied to `u2_inactivity_timeout`. USB_SS_U2_TIMEOUT Link Service Commands perform subsequent U2 inactivity timeout value changes. The new timeout value is specified in by `u2_inactivity_timeout`.

6.4.1.3 Automatic Low-Power Entry for Upstream Ports

While the USB Specification defines automatic transition attempts from U0 to U1 or from U0 to U2 only for downstream ports, the VIP supports enabling U1 and U2 inactivity timers for upstream ports.

- ❖ Set `u1_inactivity_upstream_enabled` to enable U1 for upstream ports.
- ❖ Set `u2_inactivity_upstream_enabled` to enable U2 for upstream ports.

This feature is not supported by the USB Specification.

6.4.1.4 Testbench-Initiated Low-Power Entry Attempts

A testbench initiates low-power entry attempt through the following Link Service Commands:

- ❖ `USB_SS_ATTEMPT_U1_ENTRY`
- ❖ `USB_SS_ATTEMPT_U2_ENTRY`

You can configure these service commands to attempt immediate transmission of the LGO Link Command, or to wait for the required sending conditions.

- ❖ If you request immediate transmission of the LGO command when the required conditions are not satisfied, the VIP reports that low-power entry was not attempted and takes no further action.
- ❖ If you request postponing the transmission until conditions permit an LGO transmission, the request is active until the conditions are satisfied, after which the LGO Link Command is sent.

A port can have only one active low-power entry attempt.

Setting either of these Link Service Command variables to 1 causes the VIP to immediately send the LGO:

- ❖ `low_power_entry_ignore_pending_protocol`
- ❖ `low_power_entry_ignore_pending_link`

`USB_SS_CANCEL_LP_ENTRY_ATTEMPT` Link Service Command cancels active low-power entry attempts.

Link Service Commands attempting low-power entry require specific Link Layer and Protocol Layer conditions before an `LGO_U1` or `LGO_U2` is sent. These conditions ensure that there is no bus activity, pending packets, or link command transmissions. By default, these conditions are taken into account. You can configure Link Service Commands to ignore Protocol Layer or Link Layer conditions. The testbench must account for error conditions resulting from ignoring these conditions.

The following Link Service Command variable controls if the low-power entry is attempted immediately, or if it is “queued” until the required conditions are met before attempting low-power entry.

- ❖ `low_power_entry_wait_until_permitted`
If this variable is set to 1, the request is queued.

The following SystemVerilog code creates and submits a Link Service Command requesting a U1 entry attempt when the necessary Link Layer and Protocol Layer conditions are satisfied and to queue the request if the conditions are not satisfied:

```
svt_usb_link_service req;
    req = this.new_item("req");
    `svt_xvm_rand_send_with(req,
        {
            device_address == local::device_address;
            service_type == svt_usb_link_service::LINK_SS_PORT_COMMAND;
            link_ss_command_type ==
svt_usb_link_service::USB_SS_ATTEMPT_U1_ENTRY;
            low_power_entry_ignore_pending_protocol == 0;
            low_power_entry_ignore_pending_link == 0;
            low_power_entry_wait_until_permitted == 1;
            low_power_entry_ignore_advertisement == 0;
            prereq_ltssm_state == svt_usb_types::U0;
            prereq_ltssm_substate == svt_usb_types::NO_SUBSTATE;
            ltssm_state == svt_usb_types::U1;
            ltssm_substate == svt_usb_types::NO_SUBSTATE;
```

6.4.2 Executing Aligned Transfers

The USB specification defines transfers (IN or OUT) as 'aligned', when their total payload is equal to an integral multiple of the maximum packet size as configured in the particular endpoint configuration. The specification also allows two options for aligned transfers to end:

- ❖ End with a zero-length data packet (default behavior), or
- ❖ End without a zero-length when both host and device have such an expectation for particular transfers to certain endpoints

The following VIP attributes are key to executing an aligned transfer:

- ❖ Endpoint configuration may or may not allow aligned transfers without zero length DP
- ❖ Transfer class object attribute to execute a particular transfer with or without (assuming targeted endpoint configuration allows) zero length data packet

The usage of VIP with different combinations of the above attributes are described in the following sections.

6.4.2.1 VIP Acting as a Host

[Table 6-17](#) describes the VIP behavior when it is acting as a host.

Table 6-3 Behavior of VIP Acting as a Host for Different Endpoint Configurations and Transfers

Transfer	Endpoint Configuration	Endpoint Configuration
	<code>allow_aligned_transfers_without_zero_length=0</code>	<code>allow_aligned_transfers_without_zero_length=1</code>
<code>aligned_transfer_with_zero_length=0</code>	<p>VIP performs a check, and if <code>txfer::payload_intended_count</code> is aligned</p> <ul style="list-style-type: none"> OUT: VIP reports an error that endpoint configuration and transfer attributes are inconsistent. VIP then issues one or more OUT transactions to transmit <code>payload_count</code> bytes, and does not end with a 0-length data packet. IN: VIP reports an error that endpoint configuration and transfer attributes are inconsistent. VIP then continues to issue IN transactions until it receives all <code>payload_intended_count</code> or <code><max_packet_size></code> length payload is received (whichever occurs first), hence does not require a 0-length data packet. 	<p>VIP performs a check, and if <code>txfer::payload_intended_count</code> is aligned</p> <ul style="list-style-type: none"> OUT: VIP issues one or more OUT transactions to transmit <code>payload_count</code> bytes, and does not end with a 0-length data packet. IN: VIP continues to issue IN transactions until it receives all <code>payload_intended_count</code> or <code><max_packet_size></code> length payload is received (whichever occurs first), hence does not require a 0-length data packet.
	<p>VIP performs a check, and if <code>txfer::payload_intended_count</code> is not aligned, it reports the following constraint solver error:</p> <pre>txfer:: aligned_transfer_ends_with_zero_length must be set to 1 when payload is not aligned.</pre>	
<code>aligned_transfer_with_zero_length=1</code>	<ul style="list-style-type: none"> OUT: VIP issues one or more OUT transactions to transmit <code>payload_intended_byte_count</code> number of bytes, and always ends with a <code><max_packet_size></code> (0 or short) length data packet. IN: VIP continues to issue IN transactions until a <code><max_packet_size></code> (0 or short) length payload is received. 	

6.4.2.2 VIP Acting as a Device

[Table 6-18](#) describes the VIP behavior when it is acting as a host.

Table 6-4 Behavior of VIP Acting as a Device for Different Endpoint Configurations and Transfers

Transfer	Endpoint Configuration <code>allow_aligned_transfers_without_zero_length=0</code>	Endpoint Configuration <code>allow_aligned_transfers_without_zero_length=1</code>
	<code>aligned_transfer_with_zero_length=0</code>	<code>aligned_transfer_with_zero_length=1</code>
<code>aligned_transfer_with_zero_length=0</code>	<p>VIP performs a check, and if <code>txfer::payload_intended_count</code> is aligned</p> <ul style="list-style-type: none"> OUT: VIP reports an error that endpoint configuration and transfer attributes are inconsistent. VIP then continues to receive data packets until it receives all <code>payload_intended_count</code> or <code><max_packet_size></code> length payload is received (whichever occurs first), hence VIP does not require a 0-length data packet to end transfer. IN: VIP reports an error that endpoint configuration and transfer attributes are inconsistent. VIP then continues to provide data packets to IN transactions until it transmits all of <code>payload_intended_count</code>, and does not transmit a 0-length data packet. <p>VIP performs a check, and if <code>txfer::payload_intended_count</code> is not aligned, it reports the following constraint solver error:</p> <pre>txfer:: aligned_transfer_ends_with_zero_length must be set to 1 when payload is not aligned.</pre>	<p>VIP performs a check, and if <code>txfer::payload_intended_count</code> is aligned</p> <ul style="list-style-type: none"> OUT: VIP continues to receive data packets until it receives all <code>payload_intended_count</code> or <code><max_packet_size></code> length payload is received (whichever occurs first), hence VIP does not require a 0-length data packet to end transfer. IN: VIP continues to provide data packets to IN transactions until it transmits all of <code>payload_intended_count</code>, and does not transmit a 0-length data packet.
<code>aligned_transfer_with_zero_length=1</code>	<ul style="list-style-type: none"> OUT: VIP continues to receive data packets until a data packet with <code><max_packet_size></code> (0 or short) length payload is received. IN: VIP continues to provide data packets to IN transactions until it transmits all of <code>payload_intended_count</code> and always ends with a <code>< max_packet_size></code> (0 or short) length data packet. 	

6.4.3 SuperSpeed Serial LTSSM Flow (SS.Disabled to U0)

This section describes VIP's usage for starting with SS.Disabled and progressing to U0 link state, with SuperSpeed serial interface. VIP's timers that are directly relevant in this usage, are stated in 'italics'.

Whenever VIP's operation or usage is different for down-stream facing port or up-stream facing port configuration, VIP's operating mode is explicitly mentioned. Otherwise, VIP operation is the same for either facing port.

LTSSM state is SS.Disabled

VIP's initial LTSSM state is SS.Disabled (based on VIP's configuration parameter, `usb_ss_initial_ltssm_state = svt_usb_types::SS_DISABLED`)

If VIP's interface is a down-stream facing port (when VIP is configured as Host), VIP does the following:

1. Drives `vbus` output signal to 1,
2. Drives `vip_rx_termination` output to 0, and
3. Waits for a Link Service command (Directed or PowerOn Reset) to change state to Rx.Detect.Reset

If VIP's interface is an up-stream facing port (when VIP is configured as Device), VIP does the following:

1. After detecting vbus input=1, VIP drives vip_rx_termination output to 1, and
2. Transitions to Rx.Detect.Reset state.

LTSSM state is Rx.Detect.Reset

If it is not a warm reset, then VIP immediately proceeds to Rx.Detect.Active state.

LTSSM state is Rx.Detect.Active

VIP initiates detection of far-end receiver termination by driving sstxp=1 and sstxm=0, and VIP keeps track of number of attempts to detect receiver termination.

After *receiver_detect_time* duration, VIP stops driving sstxp or sstxm and checks the value of the dut_ss_termination input signal. VIP then checks for the following conditions and then performs the corresponding actions.

IF...	THEN...
dut_ss_termination == 1	VIP reports that far-end termination is present and proceeds to Polling.LFPS.
(number of attempts == rx_detect_termination_detect_count)	VIP transitions to SS.disabled

If none of the above conditions are true, VIP transitions to Rx.Detect.Quiet, and waits for rx_detect_quiet_timeout duration and then reverts to initiating detection of far-end receiver termination.



Note

- VIP's interface is constructed such that a sampled value of 1 is seen on the dut_ss_termination signal by default, unless the signal is specifically driven to 0.
- If VBUS input signal of VIP (configured as upstream facing port) is 0, far-end receiver detection is not successful.

LTSSM state is Polling.LFPS

After *p2_to_p0_transition_time* duration, VIP's PHY transitions from P2 to P0 power state. VIP starts LFPS transmission based on following parameters:

- ❖ polling_lfps_burst_time
- ❖ polling_lfps_repeat_time
- ❖ tx_lfps_duty_cycle
- ❖ tx_lfps_period

VIP expects to receive LFPS pulses that are in following range:

- ❖ Received LFPS burst time must be \geq polling_lfps_burst_min and \leq polling_lfps_burst_max
- ❖ Received LFPS repeat time must be \geq polling_lfps_repeat_min and \leq polling_lfps_repeat_max
- ❖ Received LFPS period must be \geq tperiod_min and \leq tperiod_max

As valid LFPS pulses are received, VIP keeps track of number of valid Polling.LFPS pulses received.

When received count == *polling_lfps_received_count*, VIP transmits *polling_lfps_sent_after_received_count* more pulses, and proceeds to Polling.RxEQ state.

Until received count is not equal to *polling_lfps_received_count*, VIP continues to drive LFPS pulses until the *polling_lfps_timeout* expires, and then transitions to SS.disabled state.

LTSSM state is Polling.RxEQ

If *ltssm_skip_polling_rxeq* ==1 then VIP immediately proceeds to Polling.Active state. If *ltssm_skip_polling_rxeq* !=1, then VIP drives *polling_rxeq_tseq_count* number of TSEQ symbols and proceeds to Polling.Active state.

LTSSM state is Polling.Active

VIP transitions to Polling.Configuration state after receiving *polling_active_received_ts_count* number of consecutive and identical TS1 or TS2 ordered sets. VIP transmits TS1 symbols until either VIP receives *polling_active_received_ts_count* number of consecutive and identical TS1 or TS2 symbols or *polling_active_timeout* timer expires, whichever happens first.

If expected number of TS1s or TS2s are not received before *polling_active_timeout* expires, VIP transitions to SS.disabled state.

LTSSM state is Polling.Configuration

VIP transitions to Polling.Idle state when both the following conditions are met:

- ❖ *polling_configuration_received_ts2_count* number of consecutive and identical TS2 ordered sets are received.
- ❖ *polling_configuration_sent_ts2_count* number of TS2 ordered sets are sent after receiving the first of the *polling_configuration_received_ts2_count* consecutive and identical TS2 ordered sets

If the expected number of TS2s are not received before *polling_configuration_timeout* expires, VIP transitions to SS.disabled state.

LTSSM state is Polling.Idle

VIP transitions to U0 when both the following conditions are met:

- ❖ *polling_idle_received_idle_count* consecutive Idle Symbols are received.
- ❖ *polling_idle_sent_idle_count* Idle Symbols are sent after receiving one Idle Symbol

If expected number of IDLEs are not received before *polling_idle_timeout* expires, VIP transitions to SS.disabled state.

6.4.4 UTMI+ Support

This section provides information on USB VIP support for UTMI+.

6.4.4.1 Port Interface

The USB VIP supports the complete UTMI+ signal set. The signals can be found in the interfaces:

- ❖ *svt_usb_utmi_dut_mac_if*
- ❖ *svt_usb_utmi_dut_phy_if*

The host and peripheral devices connected via the UTMI protocol are required to be operating on the same clock. That is, one clock domain for transceivers. When the VIP is acting as a PHY, it is capable of generating the clock for the DUT, as with any real world PHY.

Synopsys has added a pin called "Vip_Speed" in addition to the pins specified by the protocol. This pin relays the speed information as specified by the svt_usb_configuration object. The pin should only be used for internal testbench uses.

For detailed information on the interfaces, consult the HTML on-line documentation at:

[\\$DESIGNWARE_HOME/vip/svt/usb_svt/latest/doc/usb_svt_uvm_class_reference/html/index.html](#)

6.4.4.2 Configuring the UTMI+ Interface

Table 6-19 lists all the available configuration parameters you can use to set UTMI behavior.

Table 6-5 Configuration Parameters to Control the UTMI Interface

Parameter	Legal values	Description
usb_20_signal_interface	Enum: UTMI_IF	Determines the interface to be used by the VIP
utmi_data_width	Integer: 8 or 16	This parameter determines the width of the UTMI+ interface. It is speed dependent: <ul style="list-style-type: none">• HS/FS -- 8-bit interface• HS/FS -- 16-bit interface• FS Only -- 8-bit interface• LS Only -- 8-bit interface. <p>This attribute is dependent on the speed attribute.</p>
speed	Enum: svt_usb_types::HS, svt_usb_types::FS svt_usb_types::LS	This attribute is used to control the UTMI+ interface speed. NOTE: For the VIP to support HS_FS functionality speed must be set to HS.
component_subtype	ENUM MAC PHY	Represents the behavior of the VIP relative to the signal interface.

6.4.4.3 Error Injection

The VIP in the UTMI+ mode supports all protocol, link and physical exceptions that are supported at the USB 2.0 serial interface.

The VIP supports control over RxError by doing the following:

- ❖ Injecting bit errors in the local PHY transmission (using callbacks) so that that the error is translated into an abort1 or abort2 type error on the remote PHY side.
- ❖ Injecting BUFFER_UNDERRUN (type of packet exception) error into the packet objects (using callbacks).

6.4.4.4 Attach / Detach

Attach/Detach is supported through service calls to the PHY model.

6.4.4.5 L1, L2 (Suspend), Resume, Remote wake-up

The UTMI+ protocol supports entry into either the L1 (LPM) sleep state or the L2 suspend state. Exit from either state can be accomplished through resume signaling initiated by the host on the bus, or by remote wake-up signaling initiated by the device/peripheral on the bus.

6.4.4.6 UTMI+ Messages

The UTMI+ interface will issue error and warning messages under the following conditions:

- ❖ Error
 - ◆ When `xcvrselect` is set to a value of 2'b11, which requests a feature of UTMI+ level 3 that is not supported.
 - ◆ A device tries to attach using the UTMI+ interface with an active high speed transceiver. The device is not attached.
- ❖ Notes
 - ◆ Transceiver reset completed. Current state of the reset pin is 1'b0.
 - ◆ Attach command called when `OpMode` does not equal 2'b01 (non-driving mode). Waiting for `Opmode` to return to 2'b01.
 - ◆ Attach requested when reset is being driven. Command ignored.
 - ◆ Data bus width is changed to 16 (or 8) (the most recently sample value of `databus16_8` at the transceiver reset).

6.4.5 USB 2.0 OTG Support

This section provides information about how the USB VIP supports different functionalities necessary when testing an On-The-Go (OTG) DUT.

This section discusses the following topics:

- ❖ [OTG Interface Signals](#)
- ❖ [Session Request Protocol](#)
- ❖ [Attach Detection Protocol](#)

6.4.5.1 OTG Interface Signals

The VIP USB OTG interface (`svt_usb_otg_if`) includes the following different types of signals

6.4.5.1.1 Link Level Signals

The VIP uses the OTG signals defined by the UTMI+ specification as the basis for modeling OTG behavior across a link-level interface. These signals support device configuration, ID, and modeling of SRP signaling.

When this OTG interface is used in conjunction with modeling a USB 2.0 or SS serial-level signal interface, these signals reflect the link-level status within the VIP. When modeling a USB 2.0 link-level signal interface, these signals are used as the actual OTG signal interface.

**Note**

Because the UTMI+ specification is based on OTG 1.3, not all signals within this interface may be active when modeling OTG 2.0 behavior (for example, `VBUS` pulsing is no longer supported under OTG 2.0, therefore the `chrgvbus` and `dischrgvbus` signals will be inactive).

Table 6-21 lists and describes the OTG link interface signals.

Table 6-6 OTG Link Interface Signals

Signal	Direction	Polarity	Default	Size	Description and Values
VbusValid	Output	High	Tri-state	1	VBUS Valid signal <ul style="list-style-type: none"> 1'b0: VBUS voltage < VBUS Valid threshold 1'b1: VBUS voltage >= VBUS Valid threshold
AValid	Output	High	Tri-state	1	Session for A peripheral is Valid signal (DUT is A-device and device VIP is B-device) <ul style="list-style-type: none"> 1'b0: VBUS voltage < VBUS A-device Session Valid threshold 1'b1: VBUS voltage >= VBUS A-device Session Valid threshold
BValid	Output	High	Tri-state	1	Session for B peripheral is Valid signal (DUT is B-device and device VIP is A-device) <ul style="list-style-type: none"> 1'b0: VBUS voltage < VBUS B-device Session Valid threshold 1'b1: VBUS voltage >= VBUS B-device Session Valid threshold
SessEnd	Output	High	Tri-state	1	Session End signal <ul style="list-style-type: none"> 1'b0: VBUS voltage >= VBUS Session End threshold 1'b1: VBUS voltage is not above VBUS Session End threshold
DrvVbus	Input	High	-	1	VBUS Drive signal <ul style="list-style-type: none"> 1'b0: VBUS is not driven to 5V 1'b1: VBUS is driven to 5V
ChrgVbus	Input	High	-	1	VBUS Charging signal <ul style="list-style-type: none"> 1'b0: VBUS is not charged up to A session valid voltage 1'b1: VBUS is charged up to A session valid voltage
DischrgVbus	Input	High	-	1	VBUS Discharging signal <ul style="list-style-type: none"> 1'b0: B-device is not discharging the VBUS 1'b1: B-device is discharging the VBUS
IdDig	Output	-	1	1	ID Status signal (drives the ID of the DUT); VIP asserts iddig when testbench issues start command <ul style="list-style-type: none"> 1'b0: Mini-A plug is connected 1'b1: Mini-B plug is connected
HostDisconnect	Output	High	1	1	Indicates if a peripheral is connected. Valid only if ddpulldown and dmpulldown are 1'b1 <ul style="list-style-type: none"> 1'b1: - No peripheral is connected 1'b0: - A peripheral is connected

Table 6-6 OTG Link Interface Signals

Signal	Direction	Polarity	Default	Size	Description and Values
IdPullup	Input	-	-	1	Enables pull-up resistor on the ID line and sampling of the signal level <ul style="list-style-type: none"> 1'b0: Disables sampling of the ID line 1'b1: Enables sampling of the ID line
DpPulldown	Input	-	-	1	Enables pull-down resistor on the DP line <ul style="list-style-type: none"> 1'b0: Pull-down resistor is not connected to DP 1'b1: Pull-down resistor is connected to DP
DmPulldown	Input	-	-	1	Enables pull-down resistor on the DM line <ul style="list-style-type: none"> 1'b0: Pull-down resistor is not connected to DM 1'b1: Pull-down resistor is connected to DM

6.4.5.1.2 Serial Interface Signals

The OTG interface (svt_usb_otg_if) includes VIP-defined signals to support modeling OTG behavior across a serial-level interface. These signals provide the ability to model OTG functionality not clearly defined under existing specifications and/or analog functionality outside the normal scope of digital simulation (such as ADP probing and sensing).

When this OTG interface is used in conjunction with modeling any USB 2.0 or SS signal interface, these signals model and/or reflect the analog state of a serial interface that exists between the VIP and the DUT, regardless of whether or not that interface is real or virtual.

ADP Interface Signals

[Table 6-22](#) lists and describes the signals that support the modeling of ADP behavior.

These VIP-defined abstract signals model the following fundamental ADP behavior:

- ❖ Whether or not a device is attached to the bus, and
- ❖ Whether or not that device is performing ADP probing.

Table 6-7 OTG ADP Serial Interface Signals

Signal	Direction	Polarity	Default	Size	Description and Values
vip_attached	Output	High	1	1	VIP is attached <ul style="list-style-type: none"> 1'b0: VIP is not attached 1'b1: VIP is attached
vip_adp_prb	Output	High	0	1	VIP ADP probe is active <ul style="list-style-type: none"> 1'b0: VIP is not performing an ADP probe 1'b1: VIP is performing an ADP probe
dut_attached	Input	High	–	1	DUT is attached <ul style="list-style-type: none"> 1'b0: DUT is not attached 1'b1: DUT is attached
dut_adp_prb	Input	High	–	1	DUT ADP probe is active <ul style="list-style-type: none"> 1'b0: DUT is not performing an ADP probe 1'b1: DUT is performing an ADP probe

SRP Interface Signals

Table 6-23 lists and describes the signals that support the modeling of ADP behavior. These VIP-defined signals model whether or not a device is detecting a VBUS voltage above the valid OTG session level (VOTG_SESS_VLD).

Table 6-8 OTG SRP Serial Interface Signals

Signal	Direction	Polarity	Default	Size	Description and Values
vip_sess_vld	Output	High	0	1	VIP VBUS level detector - VOTG_SESS_VLD <ul style="list-style-type: none">1'b0: VIP detected/driven VBUS <= VOTG_SESS_VLD1'b1: VIP detected/driven VBUS > VOTG_SESS_VLD
dut_sess_vld	Input	High	0	1	DUT VBUS level detector - VOTG_SESS_VLD <ul style="list-style-type: none">1'b0: DUT detected/driven VBUS <= VOTG_SESS_VLD1'b1: DUT detected/driven VBUS > VOTG_SESS_VLD

6.4.5.2 Session Request Protocol

Session Request Protocol (SRP) is a mechanism used to conserve power. SRP allows an A-device to turn off VBUS when the bus is not in use. It also allows a B-device to request the A-device turn VBUS back on and start a session. A session, defined as the period of time VBUS is powered, ends once VBUS is turned off.


At the link-level, there are two parts to the SRP flow:

- ❖ Generating and responding to the SRP request, and
- ❖ Controlling the SRP response

The OTG Host and OTG peripheral VIP generate and respond to an SRP request if the `srp_supported` attribute is set in the `svt_usb_configuration` object.

6.4.5.2.1 SRP Protocol Flow When the VIP is Configured as an A-Device

Figure 6-14 explains the SRP process flow when the VIP is configured as an A-device.

Figure 6-1 SRP Protocol Flow when the VIP is Configured as an A-Device


[Table 6-24](#) expands on the abbreviated messages that are used in [Figures 6-14](#) and [6-15](#).

Table 6-9 Legend Explaining the Abbreviated Messages

Abbreviated Messages Used in Figure 6-14	Actual Messages Issued by VIP
N: waiting for end of session	Waiting for the end of a session by monitoring VBUS and data lines.
N: detected start of SRP	A-device detected start of SRP since D+ went high
N: SRP completed successfully	SRP completed successfully since D+ pull-up resistor remained ON for a period within the range specified by TB_DATA_PLS
N: device is now connected	tdcnn timer expired. Device is now connected.
Abbreviated Message Used in Figure 6-15	Actual Message Issued by VIP
N: signaling SRP	B-device signaling SRP by generating data line pulsing.

SRP Protocol Flow When the VIP is Configured as a B-Device

[Figure 6-15](#) explains the SRP process flow when the VIP is configured as a B-device. The abbreviated messages listed in [Figure 6-15](#) are expanded in detail in [Table 6-24](#).

Figure 6-2 SRP Protocol Flow when the VIP is Configured as a B-Device

6.4.5.2.2 Role Swapping Using the HNP Protocol

Host Negotiation Protocol (HNP) is the protocol by which an OTG Host relinquishes the role of USB Host to an OTG Peripheral that is requesting the role. To do this the OTG Host suspends the bus, and then signaling during suspend and resume determines which device has the role of USB Host when the bus comes out of suspend.

At the start of a session, the A-device defaults to having the role of host. During a session, the role of host can be transferred back and forth between the A-device and the B-device any number of times, using HNP.

The acting USB Host may suspend the bus at any time when there is no traffic. HNP is applicable only if an acting OTG Host has detected an acting OTG Peripheral's request to assume the role of USB Host prior to the suspend. The initiation of the role swap first initiated by the OTG device.



Role swapping is possible only when an OTG Host is directly connected to an OTG device and only if `hnp_capable` and `hnp_supported` attributes are set in their respective configurations.

6.4.5.2.3 Initializing and Storing Configurations for OTG Roles

To successfully support role swapping, the VIP agent must store the configuration data objects for the initial OTG role as well as the swapped OTG role.

The initial configuration is first stored when the VIP agent is constructed. The swapped configuration is stored through the `set_otg_cfg` function bit.

In the testbench (if `hnp_enable` is set to 1), a role swap is then initiated by the testbench through the `attempt_otg_role_swap` task.

The agent also notifies the testbench whether the role swap was successful or not through one of the following `uvm_events`:

- ❖ `NOTIFY_OTG_ROLE_SWAP_SUCCEEDED` or
- ❖ `NOTIFY_OTG_ROLE_SWAP_FAILED`

After successful role swap, the VIP agent and the component stack is reconfigured using the `reconfigure()` command. When `svt_usb_agent::reconfigure()` is called by the role-swap process, the stored `initial_cfg` or `swapped_cfg` configuration is used as the argument to the `reconfigure()` method. This means that the initial and swapped configurations are retained across role swaps. Changes to the active configuration by using the `svt_usb_agent::reconfigure()` method directly by the user (testbench) are not retained by the agent in the `initial_cfg` or `swapped_cfg` configurations. If a role swap occurs, the configuration used for the new role is the most recent configuration applied by the `set_otg_cfg()` method for that role.

If the testbench wishes to cause the VIP to start operating in a different configuration when the role is swapped, it must call `svt_usb_agent::set_otg_cfg()` for the inactive role while the current active role is in effect.

6.4.5.2.4 Role Swapping Process Overview

This section provides a brief overview of the sequence of events:

1. Testbench creates two `svt_usb_agent_configuration` instances, one each representing the configuration for the initial OTG role (`initial_cfg`) and the swapped OTG role (`swapped_cfg`).
2. Testbench constructs (using the `new()` method) the VIP agent using the `initial_cfg` configuration data object that represents its initial role (based on `component_type` value).
3. Testbench stores the `swapped_cfg` configuration data object using `set_otg_cfg()`.
4. If the VIP agent initially has the OTG Peripheral role, the testbench requests a role swap by calling the `attempt_otg_role_swap()` command.
 - ◆ If the role swap succeeds, the agent reconfigures the component stack (and itself) using the `swapped_cfg` configuration data object (which represents the configuration of the VIP while in the OTG Host role), and notifies the Testbench through the `NOTIFY_OTG_ROLE_SWAP_SUCCEEDED` `uvm_event`.
 - ◆ If the role swap fails the agent does not change anything, but notifies the testbench through the `NOTIFY_OTG_ROLE_SWAP_FAILED` `uvm_event`.

5. If VIP agent initially has the OTG Host role, and the DUT OTG Device initiates a role swap attempt, the agent notifies the testbench that a role swap attempt has started.
 - ◆ If the role swap succeeds, the agent reconfigures the component stack (and itself) using the `swapped_cfg` configuration data object (which represents the configuration of the VIP while in the OTG Peripheral role), and notifies the testbench through the `NOTIFY_OTG_ROLE_SWAP_SUCCEEDED uvm_event`.
 - ◆ If the role swap fails the agent does not change anything, but notifies the testbench through the `NOTIFY_OTG_ROLE_SWAP_FAILED uvm_event`.
6. When a successful role swap back to the initial OTG role occurs, (after step 4 or 5), the agent reconfigures the component stack (and itself) using the `initial_cfg` configuration data object.

6.4.5.2.5 HNP Polling

HNP polling is a mechanism that allows the OTG device currently acting as a Host to determine when the other attached OTG device wants to take the host role. When an OTG host is connected to an OTG device, it polls the device regularly to determine whether it requires a role-swap.

When doing HNP polling, the VIP configured as an A-device executes the `GetStatus()` control transfers directed at a control endpoint in the OTG device. However, this kind of polling is not really required because the VIP does not modify its behavior based on the information content of the transfers.

Alternate methods can be used to model the possible outcomes of polling. If required, the testbench can implement or detect such polling and synchronize the usage of the alternate mechanisms accordingly.

HNP Polling When the VIP is Configured as an OTG Host

When the VIP is acting as OTG Host, the testbench must create and send appropriate control transfers to enable and accomplish HNP Polling. These include the control transfers that implement the `GetDescriptor()`, `SetFeature()`, and `GetStatus()` commands used in HNP polling.

- ❖ When `GetDescriptor()` is used to access the DUT's OTG descriptor, the value returned for the "HNP Support" attribute (`bmAttributes` bit D1), should be saved, and the VIP should be dynamically reconfigured to set the equivalent `hnp_supported` bit in the `remote_device_cfg` that represents the DUT's configuration to the VIP as Host.
- ❖ When `SetFeature()` is used to set the `b_hnp_enable` bit successfully, the testbench can then call the `attempt_otg_role_swap()` method, which will enable the HNP procedure.
- ❖ When `GetStatus()` is used to interrogate the value of the DUT's "Host request flag" status bit, if the flag is set a protocol service data object should be created by the testbench and sent to the VIP to initiate a role swap attempt.
- ❖ It is also up to the testbench to control the timing of the `GetStatus()` control transfers to adhere to the timing requirements specified for HNP Polling.

HNP Polling When the VIP is Configured as an OTG Device

When the VIP is acting as OTG Peripheral, the testbench must interpret and respond to the following control transfers involved in HNP Polling:

- ❖ The value of the `b_hnp_supported` bit in the VIP's device configuration does not automatically result in the proper bit being set in the values returned for the `GetDescriptor()` control transfer. It is up to the testbench to interpret the control transfer, and control the return value based on the value of the `b_hnp_supported` bit in the VIP's device configuration.

- ❖ When a SetFeature() control transfer is received who's intent is to set the b_hnp_enable bit in the VIP, the corresponding bit in the VIP's device status is not automatically set. It is up to the testbench to interpret the control transfer and then call the agent's attempt_otg_role_swap() method to enable the HNP process.
- ❖ If the VIP is configured with b_hnp_supported = 1 and an attempt_otg_role_swap() method call is made, it will cause (in the case of a 2.0 connection) the host_request_flag in the VIP's shared device status to become set. However, this does not automatically result in the proper bit being set in the value returned for the GetStatus() control transfer. It is the responsibility of the testbench to interpret the control transfer, and control the return value based on the value of the host_request_flag in the VIP's shared device status.

6.4.5.2.6 HNP Sequence of Events When VIP is Configured as an A-Device

Figure 6-16 explains the HNP flow when the VIP is configured as an A-device. Figure 6-17 explains the role reversion sequence of events when the A-device reverts back to acting as a host.

Figure 6-3 HNP Flow When VIP is Configured as an A-Device





Figure 6-4 Reverse HNP Flow when the VIP A-Device Reverts Back to Acting as a Host

Table 6-26 expands on the abbreviated messages that are used in Figures 6-16 and 6-17.

Table 6-10 Legend Explaining the Abbreviated Messages Used in Figures 6-16 and 6-17

Abbreviated Messages Used in Figure 6-16	Actual Messages Issued by VIP
N: Moving to XCVR_STATE_BUSY	Active low PHY suspend (SuspendM = 0). Moving to state XCVR_STATE_BUSY.
N: attempt_otg_role_swap() completed with success	attempt_otg_role_swap() completed with usb_otg_b_hnp_success 1
N: Disable pull-down register	Disable pull-down resistor on DP (DpPullDown = 0)
N: A Peripheral HNP succeeded	A-PERIPHERAL HNP succeeded
Abbreviated Message Used in Figure 6-17	Actual Message Issued by VIP
N: Enable FS transceiver	Enable FS transceiver (XcvtSelect = 01)
N: Enable terminations	Enable terminations (TermSelect = 1)

Table 6-10 Legend Explaining the Abbreviated Messages Used in [Figures 6-16](#) and [6-17](#)

Abbreviated Messages Used in Figure 6-16	Actual Messages Issued by VIP
N: Disable terminations	Disable terminations (TermSelect = 0)
N: Reverse HNP Complete	Reverse HNP Complete on A-Device

6.4.5.2.7 HNP Sequence of Events When VIP is Configured as a B-Device

[Figure 6-18](#) explains the HNP flow when the VIP is configured as a B-device.


Figure 6-5 HNP Flow When VIP is Configured as a B-Device


Figure 6-6 Reverse HNP Flow When the VIP B-Device Reverts Back to Acting as a Device

Table 6-27 expands on the abbreviated messages that are used in Figures 6-18 and 6-19.

Table 6-11 Legend Explaining the Abbreviated Messages Used in Figures 6-18 and 6-19

Abbreviated Messages Used in Figure 6-18	Actual Messages Issued by VIP
N: twtrev_timer expired	N: twtrev_timer expired
N: Enable FS transceiver	N: Enable FS transceiver (XcvrSelect = 01)
N: Enable terminations	N: Enable terminations (TermSelect = 1)
N: tb_fs_bdis_timer has expired	N: tb_fs_bdis_timer has expired
N: Disable terminations	N: Disable terminations (TermSelect = 0)
N: HNP initiated	N: HNP initiated
N: Enable pull-down resistor on DP	N: Enable pull-down resistor on DP (DpPullDown =1)
N: B-HOST HNP succeeded	N: B-HOST HNP succeeded
Additional Abbreviated Messages Used in Figure 6-19	Actual Messages Issued by VIP
N: Moving to XCVR_STATE_BUSY	N: Active low PHY suspend (SuspendM = 0). Moving to state XCVR_STATE_BUSY
N: twtrev_timer has expired	N: main() - twtrev_timer has expired.linestate=se0
N: tb_fs_bdis_timer has expired	N: main() - tb_fs_bdis_timer has expired
N: ta_bidl_adis_timer has expired	N: main() - ta_bidl_adis_timer has expired
N: B-DEVICE HNP succeeded	N: B-DEVICE HNP succeeded

6.4.5.3 Attach Detection Protocol

Attach Detection Protocol (ADP) is the mechanism used to determine whether or not a remote device has been attached or detached when VBUS is not present.

ADP involves the following primary functions:

- ❖ ADP probing (performed by either an A-device or B-device). It is used to detect a change in the attachment state of a remote device.
- ❖ ADP sensing (performed only by B-device). It is used to detect whether or not a remote A-device is performing ADP probing

6.4.5.3.1 ADP Probing

The VIP performs ADP probing when the following conditions are met:


- ❖ The adp_supported configuration property is set
- ❖ VBUS is below the valid OTG level (at simulation startup or following a session end)
- ❖ ADP probing has not been disabled (through an ADP_PROBING_OFF physical service request)
- ❖ ADP sensing is not active (this only applies to a B-Device)

ADP Probing When VIP is Configured as an A-Device

When VIP is configured as an A-device, it only supports ADP probing. The ADP probing sequence is as follows:

1. At power on, the VIP performs an initial ADP probe if VBUS is not present.
2. After power on, the VIP starts ADP probing when the VBUS falls below the valid OTG session level (for example, when the VBUS is switched off). VIP continues ADP probing until it detects an ADP change, or if the VBUS rises above the valid OTG session level.
3. VIP issues an ADP change whenever it detects an attachment difference between two consecutive ADP probes.


[Figure 6-20](#) illustrates a simple ADP Probing process for VIP as an A-device or an Embedded Host using a waveform.

Figure 6-7 ADP Probing Flow when VIP is Configured as an A-Device or Embedded Host**ADP Probing When VIP is Configured as a B-Device**

When VIP is configured as a B-device, the ADP probing sequence is as follows:

1. At power on if VBUS is not present, the VIP performs an initial ADP probe before starting an SRP request.
2. After power on, the VIP starts ADP probing when the VBUS falls below the valid OTG session level (for example, when the VBUS is switched off), and if ADP sensing is not active. VIP continues ADP probing until the VBUS rises above the valid OTG session level.
3. VIP issues an ADP change whenever it detects an attachment difference between two consecutive ADP probes.

Figure 6-21 explains the ADP control when VIP is configured as a B-device.

Figure 6-8 ADP Probing and Sensing Flow when the VIP is Configured as a B-Device

6.4.5.3.2 ADP Sensing

The VIP performs ADP sensing when the following conditions are met:

- ❖ The `adp_supported` configuration property is set
- ❖ The VIP is configured as a peripheral (B-Device)
- ❖ VBUS has just fallen below the valid OTG level (following a session end)
- ❖ ADP sensing has not been disabled (through an `ADP_SENSING_OFF` physical service request)
- ❖ While the VIP continues to detecting ADP probing by the host

ADP Sensing When VIP is Configured as a B-Device

1. After power on, VIP starts ADP sensing when the VBUS falls below the OTG session valid level.
2. VIP continues ADP sensing until the VBUS rises above the OTG session valid level, or if VIP detects a lack of ADP probing by the A-device. If VIP detects a lack of probing by the A-device, it issues an ADP change.

For more information on the ADP control flow when VIP is acting as a B-device, see [Figure 6-21](#).

6.4.5.3.3 ADP UVM Events

VIP issues the following `uvm_events` to indicate the success or failure of an ADP probing or sensing operation:

- ❖ `NOTIFY_ADPRB_INITIATED` - Issued at the start of a VIP ADP probe
- ❖ `NOTIFY_ADPRB_COMPLETED` - Issued at the end of a VIP ADP probe
- ❖ `NOTIFY_ADPSNS_INITIATED` - Issued when VIP ADP sensing starts
- ❖ `NOTIFY_ADPSNS_COMPLETED` - Issued when VIP ADP sensing ends
- ❖ `NOTIFY_PHYSICAL_ADPCCHANGE` - Issued following detection of an ADP change. Issue during a VIP ADP probing or VIP ADP sensing event.
 - ◆ VIP ADP probe - Issued at the end of a VIP ADP probe event if a change in bus state was detected (a change in the `physical_adp_probe_state`). This `uvm_event` is issued just before an ADP probe is completed.
 - ◆ VIP ADP sensing - Issued during a VIP ADP sensing event whenever DUT ADP probing is not detected within the expected window of time (and is denoted by a change in the `physical_adp_change_detected` value).
- ❖ `NOTIFY_PHYSICAL_VBUS_CHANGE` - General `uvm_event` issued whenever a change on VBUS (driven or received) is detected.
- ❖ `NOTIFY_PHYSICAL_USB_20_LINESTATE_CHANGE` - General `uvm_event` issued whenever a change in received linestate is detected.

6.4.5.3.4 ADP User Control

The VIP provides physical service commands that can be used to control the VIP's modeling of ADP probing and sensing. These commands allow you to override the automatic default behavior of the VIP.

Use the following commands to enable and disable ADP probing:

- ❖ `ADP_PROBING_ON` - The `ADP_PROBING_ON` command enables ADP probing by the VIP. This command re-enables the VIP's default ADP probing behavior.
- ❖ `ADP_PROBING_OFF` - The `ADP_PROBING_OFF` command disables ADP probing by the VIP. This command disables the VIP's default ADP probing behavior. Once issued, this command permanently disables all VIP ADP probing until it is manually re-enabled (using the `ADP_PROBING_ON` command).

Use the following commands to enable and disable ADP sensing:

- ❖ `ADP_SENSING_ON` - The `ADP_SENSING_ON` command enables ADP sensing by the VIP. This command re-enables the VIP's default ADP sensing behavior.

- ❖ **ADP_SENSING_OFF** - The **ADP_SENSING_OFF** command disables ADP sensing by the VIP. This command disables the VIP's default ADP sensing behavior. Once issued, this command permanently disables all VIP ADP sensing until it is manually re-enabled (using the **ADP_SENSING_ON** command).

By default, both ADP probing and sensing are enabled.

6.4.6 HSIC Overview

The this section covers HSIC Support.

6.4.6.1 Supported HSIC Features

The model supports the following HSIC features:

- ❖ HS bus traffic
- ❖ Reset/Suspend/Resume/Remote Wakeup
- ❖ HSIC Discovery process
- ❖ Reception and transmission of inverted packet data
- ❖ Modeling of the powered off state.

6.4.6.2 Unsupported HSIC Features

When a HSIC interface is selected, some standard USB 2.0 features become unavailable. Following is a list of VIP features that are not supported when using a HSIC interface:

- ❖ Disconnect (can neither drive nor detect disconnection)
- ❖ Attach/Detach (can neither attach nor detach)

6.4.6.3 Configuration Parameters

You control much of the HSIC interface through various configuration members. The members also define the available feature set. The following table shows the most important HSCI configuration members. For a listing of the valid and reasonable constraints on the configuration members, consult the online HTML documentation..

Table 6-12 HSIC Configuration Parameters

Configuration Parameter	Purpose
usb_20_signal_interface	Selects the USB 2.0 interface type
usb_20_hsic_strobe_period	Width of a strobe period.
usb_20_hsic_auto_enabled_delay	Delay from host Power On to Enabled state (set negative to request manual initiation of the process).
usb_20_hsic_auto_connect_delay	Delay from peripheral IDLE detect to Connect (set negative to request manual initiation of the process).
usb_20_hsic_connect_time	Length of time CONNECT is driven during Connect signaling.
usb_20_hsic_connect_idle_time	Length of time IDLE is driven at the end of Connect signaling.
"usb_20_hsic_bus_keeper_time	Length of time peripheral checks for Bus Keepers to maintain IDLE following an IDLE driven at the end of signaling.

Table 6-12 HSIC Configuration Parameters (Continued)

Configuration Parameter	Purpose
usb_20_hsic_idle_drive_time	Length of time IDLE is driven after signaling (except during Connect signaling).
usb_20_hsic_strobe_data_rx_skew	Defines the maximum expected skew between Strobe and Data during detection of bus state transitions.
usb_20_hsic_strobe_data_tx_skew	Defines the skew between Strobe and Data during the driving of bus state transitions.
usb_20_hsic_fast_eop_to_idle_disable	Disables fastest transition from driving EOP to driving IDLE.
usb_20_hsic_bus_keeper_on_count	Number of half-strobe periods from IDLE detect to Bus Keepers being enabled.
usb_20_hsic_bus_keeper_off_count	Number of half-strobe periods from non-IDLE detect to Bus Keepers being disabled.
usb_20_hsic_tx_inversion_enable	Enables transmission of inverted packet data.
usb_20_hsic_dut_is_legacy_device	Used to identify when the DUT is a legacy device. A legacy device is allowed to transmit inverted packet data.

6.4.6.4 Transactions

The HSIC interface uses data transactions to model the flow of data exchanged across the HSIC interface, and uses service transactions to provide test bench and inter-layer control of the transactor's operation.

6.4.6.4.1 Data Transactions

There are no HSIC-specific data transaction requirements; the HSIC interface uses the current set of USB SVT transactions associated with the standard USB 2.0 HS data path.

6.4.6.4.2 Physical Service Transactions

The following HSIC-specific physical service commands are intended for test bench use to manually initiate a HSIC operation.

- ❖ **DRIVE_HSIc_ENABLED** - Request to a host to "present" the IDLE bus state indicating the HSIC Enabled On state.
- ❖ **DRIVE_HSIc_CONNECT** - Request to a peripheral to drive Connect signaling.

The following general use USB 2.0 physical service commands are also supported when configured for a HSIC interface:

- ❖ **VBUS_OFF** - When configured for HSIC, moves the VIP into the powered off state.
- ❖ **VBUS_ON** - When configured for HSIC, moves the VIP into the powered on state.

The following general use USB 2.0 physical service commands are not supported when configured for a HSIC interface:

- ❖ **ATTACH_DEVICE** - No support for attach/detach.
- ❖ **DETACH_DEVICE** - No support for attach/detach.
- ❖ **REMOTE_ATTACH_DEVICE** - Only supported for remote link interfaces.

- ❖ REMOTE_DETACH_DEVICE - Only supported for remote link interfaces.
- ❖ REMOTE_VBUS_OFF - Only supported for remote link interfaces.
- ❖ REMOTE_VBUS_ON - Only supported for remote link interfaces.
- ❖ ADP_PROBING_OFF - No support for OTG.
- ❖ ADP_PROBING_ON - No support for OTG.
- ❖ ADP_SENSING_OFF - No support for OTG.
- ❖ ADP_SENSING_ON - No support for OTG.

6.4.6.5 Exceptions

The HSIC interface uses USB SVT transaction exceptions to inject/report data-based flow and/or content errors and uses USB SVT error checks to report on protocol-related failures involving timing and/or signaling.

6.4.6.5.1 Protocol Errors

Outside of the HSIC Discovery process, the HSIC interface uses the current set of USB 2.0 protocol checks (i.e. reset timing, inter-packet delays).

Specific to HSIC Discovery process and to HSIC operation, the HSIC interface adds some new layer-specific protocol checks (using standard USB SVT error checks based on the `svt_err_check` class).

6.4.6.5.2 Physical Level Protocol Checks

The HSIC interface adds the following physical-level HSIC protocol checks:

- ❖ `usb_20_hsic_connect_check` - Identifies Connect signaling issues detected by the VIP when configured as a HSIC host. This check, performed by the VIP when configured as a host, verifies that a DUT peripheral signals CONNECT only after enabled, and that it drives CONNECT for the proper length of time.
- ❖ `usb_20_hsic_bus_keeper_check` - Identifies Bus Keeper timing issues detected by the VIP when configured as a HSIC peripheral. This check attempts to verify that after a non-IDLE to IDLE transition, a DUT host's Bus Keepers get enabled within the proper amount of time, and that they continue to hold the bus in IDLE once it is no longer being driven IDLE. This check is only attempted following the success of the post-signaling IDLE drive check (`usb_20_hsic_drive_idle_check`).
- ❖ `usb_20_hsic_drive_idle_check` - Identifies end-of-signaling drive IDLE timing issues detected by the VIP when the receiving HSIC device. This check attempts to verify that after a non-IDLE to IDLE transition, a DUT drives IDLE for the proper amount of time.
- ❖ `usb_20_hsic_data_inversion_check` - Identifies when inverted packet data is detected by the VIP when configured to support HSIC. This check is used to flag the reception of inverted packet data from a non-legacy device.

6.4.6.6 HSIC Interface

The HSIC signal interface, as with other supported signal interfaces, resides as an instance within the top-level SVT USB interface (`svt_usb_if.svi`). The `usb_20_hsic_if` interface includes all of the signals that make up the supported USB signal connections for a HSIC interface. It includes any clocking blocks and modports necessary to provide logical connections for the transactors interacting via the supported signal connections. This also includes modports which provide debug access to the different transactors.

6.4.6.7 HSIC Signal Interface

Defined within the `svt_usb_20_hsic_if.svi` file, the HSIC interface is a simple two signal serial interface consisting of the data and strobe signals. Additionally, this interface includes an input clock signal, `clk`; this input clock is used by the VIP to derive its transmit clock and to support clock/data recovery. See the following table.

Table 6-13 HSIC Signals

Signal Name	Direction	Polarity	Default	Size	Description/Values
data	In/Out	High	0	1	Bi-directional DDR data signal. During data communication, this signal is used to communicate data. Outside of data communication, this signal is used in combination with the strobe signal to control state.
strobe	In/Out	High	0	1	Bi-directional data strobe signal. During data communication, this signal is used as the clock for data. Outside of data communication, this signal is used in combination with the data signal to control state.
clk	Input	High	0	1	Input clock from the testbench. Requires a stable clock running at 4 times the desired VIP transmission rate (8x the desired strobe-period rate). This clock is used to derive the VIP transmit clock and to support clock recovery during reception.

6.4.6.8 Callbacks

There are no HSIC-specific callback requirements; the HSIC interface uses the current set of callbacks associated with the standard USB 2.0 data path.

6.4.6.9 Notifications

The HSIC interface adds the following HSIC-specific shared status notifications:

Table 6-14

Notification	Use
NOTIFY_USB_20_HSIC_ENABLED_ASSERTED	A HSIC host, moving from the Powered On state to the Enabled On state, has started asserting IDLE on the bus.
NOTIFY_USB_20_HSIC_ENABLED_DETECTED	A HSIC peripheral, in the Powered On state, has detected assertion of IDLE on the bus.
NOTIFY_USB_20_HSIC_CONNECT_INITIATED	A HSIC peripheral, moving from the Powered On state to the Connect state, has started driving the CONNECT portion of Connect signaling.
NOTIFY_USB_20_HSIC_CONNECT_DRIVE_IDLE	A HSIC peripheral, moving from the Powered On state to the Connect state, has started driving the IDLE portion of Connect signaling.
NOTIFY_USB_20_HSIC_CONNECT_COMPLETED	A HSIC peripheral, in the Connect state, has completed driving Connect signaling.
NOTIFY_USB_20_HSIC_CONNECT_DETECTED	A HSIC host, in the Enabled state, has detected Connect signaling.

Table 6-14

Notification	Use
NOTIFY_USB_20_HSIC_INVERTED_SYNC_DETECTED	A HSIC device, while in an idle state, has detected reception of an inverted SYNC.
NOTIFY_USB_20_HSIC_INVERTED_SYNC_TRANSMIT	A HSIC device, in the process of transmitting an inverted packet, has started transmission of that packet's inverted SYNC.

6.4.6.10 Factories

There are no HSIC-specific factory requirements; the HSIC interface uses the current set of factories associated with the standard USB 2.0 data path.

6.4.6.11 Shared Status

The HSIC interface adds the following HSIC-specific shared status properties:

- ❖ `usb_20_hsic_enabled` - Identifies when the HSIC device is in the Enabled state. When a host, set to 1 once it starts asserting IDLE on the bus after Power On. When a peripheral, set to 1 once it detects IDLE on the bus after Power On.
- ❖ `usb_20_hsic_connected` - Identifies when the HSIC device is in the Connected state. When a peripheral, set to 1 once it completes asserting CONNECT on the bus after Enabled. When a host, set to 1 once it detects valid Connect signaling on the bus after Enabled.


6.4.6.12 Usage

Following is a discussion of the HSIC-specific usage scenarios and how users may control and/or interact with them. The HSIC-specific usage scenarios are:

- ❖ Discovery Process - The HSIC protocol for establishing a HSIC connection.
- ❖ Bus Keepers - The HSIC host feature used to maintain IDLE on the bus.
- ❖ Data Inversion - Support for enabling transmission and reception of inverted data.
- ❖ "Data EOP Signaling - Support for configuring the end-of-data signaling pattern.
- ❖ Modeling Power Off - Support for modeling power off entry and exit.
- ❖ Controlling Skew - Support for configuring skew between Strobe and Data signals.

6.4.6.12.1 Discovery Process

Discovery is the HSIC power up and connection sequence used to establish communication between two HSIC devices. [Figure 6-22](#) illustrates the basic flow of the Discovery process. Included in the figure are annotations used in the following sections to help describe how the VIP operates during the Discovery process.

Figure 6-9 Discovery Process with VIP Set Values

6.4.6.12.2 VIP as Host

Using [Figure 6-22](#) as a reference, this section describes how the VIP operates as a HSIC host during the Discovery process.

T1 - Powered Off state

Description	This state models a HSIC host in the "Power state is OFF" state.
Entry	The VIP enters this state under one of the following conditions: <ul style="list-style-type: none"> The VIP has not yet been started. The VIP has been reset (via reset() after being started). The VIP has received a request to power down (via physical service command VBUS_OFF after being started).
Action	In this state, the VIP's HSIC interface provides weak pull-downs to prevent the Strobe and Data signals from floating.
Exit	Based on its entry into this state, the VIP exits this state under one of the following conditions: <ul style="list-style-type: none"> An un-started VIP will move to the T0 when it is started (via start()). A reset VIP will move to the T0 when it is restarted (via start()). A started VIP will move to the T0 when it receives a request to power up (via physical service command VBUS_ON).

T0 - Power On, HSIC not Enabled state

Description	This state models a HSIC host in the "Power state is ON, but HSIC is not enabled" state.
-------------	--



T0 - Power On, HSIC not Enabled state

Entry	From state T-1.
Action	In this state, the requirement for the host to "assert Bus Keepers on both Strobe and Data to provide a logic '0' state" is provided by the interface's weak pull-downs.
Exit	<p>The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF).</p> <p>The VIP moves to T1 based on the value of <code>usb_20_hsic_auto_enabled_delay</code>:</p> <ul style="list-style-type: none">• If <code>usb_20_hsic_auto_enabled_delay</code> is non-negative, the VIP moves to T1 after implementing the delay specified by the value.• If <code>usb_20_hsic_auto_enabled_delay</code> is negative, the VIP will not move to T1 until it receives a <code>DRIVE_HSIC_ENABLED</code> physical service command.


T1 - Power On, HSIC Enabled state

Description	This state models a HSIC host in the "Power state is ON, HSIC is enabled" state.
Entry	From state T0.
Action	The VIP issues the <code>NOTIFY_USB_20_HSIC_ENABLED_ASSERTED</code> notification, asserts its Bus Keepers to provide an IDLE bus state and then starts to monitor the Strobe and Data lines for the CONNECT bus state.
Exit	<p>The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF).</p> <p>The VIP moves to T2 when it detects the bus transition to the CONNECT bus state.</p>

T2 - Power On, HSIC Enabled, Peripheral signals Connect state

Description	This state models a HSIC host in the "Power state is ON, HSIC is enabled, and Peripheral signals a CONNECT" state following the detection of CONNECT.
Entry	From state T1.
Action	The VIP starts measuring the period CONNECT that is on the bus.
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves to T3 when it detects the bus transition out of the CONNECT bus state.

T3 - Power On, HSIC Enabled, Peripheral signals Connect state

Description	This state models a HSIC host in the "Power state is ON, HSIC is enabled, and Peripheral signals a CONNECT" state following the detection of end of CONNECT.
Entry	From state T2.
Action	<p>The VIP stops measuring the period CONNECT that is on the bus.</p> <ul style="list-style-type: none"> • If it detected assertion of the CONNECT bus state for the required minimum period of time (as controlled by the configuration property <code>usb_20_hsic_connect_time_min</code>), the VIP issues the <code>NOTIFY_USB_20_HSIC_CONNECT_DETECTED</code> notification. • If it detected assertion of the CONNECT for less than the minimum requirement, the VIP will issue a <code>usb_20_hsic_connect_check</code> failure and remain in T3 until the VIP is either restarted or powered down. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  Note The VIP starts operating as a standard USB 2.0 device. It begins using standard USB 2.0 configuration timers and state. </div>
Exit	<p>The VIP moves to T-1 if it receives a request to power down (via physical service command <code>VBUS_OFF</code>). Based on whether or not the detected CONNECT was valid:</p> <ul style="list-style-type: none"> • If valid, the VIP moves to T5 after implementing the delay specified by the <code>tattdb</code>. • If not valid, the VIP will remain in T3 until the VIP is either restarted or powered down.

T4 - Power On, HSIC Enabled, Peripheral signals Connect state

Description	This state models the point at which a HSIC peripheral stops driving IDLE following the end of driving CONNECT.
Entry	none
Action	none
Exit	n/a




T5 - Host drive HSIC RESET state

Description	This state models a HSIC host in processes of driving RESET.
Entry	From state T3.
Action	The VIP drives RESET on the bus.
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves to T6 after implementing the delay specified by the tdrst.

T6 - HSIC IDLE

Description	This state models a HSIC host driving the IDLE state following driving RESET.
Entry	From state T5.
Action	The VIP drives IDLE on the bus.
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves to T7 after implementing the delay specified by the usb_20_hsic_idle_drive_time.

T7 - HSIC IDLE

Description	This state models a HSIC host in the idle state following driving post-RESET IDLE. The host Bus Keepers maintain IDLE on the bus.
Entry	From state T6.
Action	The VIP stops driving the bus. <div> Note The VIP is ready to start exchanging data across the bus (as illustrated at T8).</div>
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves to T8 if packet transmission or reception is started.

T8 - HSIC transfer

Description	This state models the transfer of data across the bus.
Entry	From state T7
Action	The VIP is transmitting or receiving packet data.
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves back to T7 when packet transmission/reception has completed.

6.4.6.12.3 VIP as Peripheral

Using [Figure 6-22](#) as a reference, this section describes how the VIP operates as a HSIC peripheral during the Discovery process.

T-1 - Powered Off state

Description	This state models a HSIC peripheral in the "Power state is OFF" state.
Entry	The VIP enters this state under one of the following conditions: <ul style="list-style-type: none"> • The VIP has not yet been started. • The VIP has been reset (via reset() after being started). • The VIP has received a request to power down (via physical service command VBUS_OFF after being started).
Action	In this state, the VIP's HSIC interface provides weak pull-downs to prevent the Strobe and Data signals from floating.
Exit	Based on its entry into this state, the VIP exits this state under one of the following conditions: <ul style="list-style-type: none"> • An un-started VIP will move to the T0 when it is started (via start()). • A reset VIP will move to the T0 when it is restarted (via start()). • A started VIP will move to the T0 when it receives a request to power up (via physical service command VBUS_ON).

T0 - Power On, HSIC not Enabled state

Description	This state models a HSIC peripheral in the "Power state is ON, but HSIC is not enabled" state.
Entry	From state T-1.
Action	In this state, the VIP starts to monitor the Strobe and Data lines for an IDLE bus state.
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves to T1 when it detects the bus transition to the IDLE bus state.



T1 - Power On, HSIC Enabled state

Description	This state models a HSIC peripheral in the "Power state is ON, HSIC is enabled" state.
Entry	From state T0.
Action	The VIP issues the NOTIFY_USB_20_HSIC_ENABLED_DETECTED notification.
Exit	<p>The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF).The VIP moves to T2 based on the value of usb_20_hsic_auto_connect_delay:</p> <ul style="list-style-type: none">• If usb_20_hsic_auto_connect_delay is non-negative, the VIP moves to T2 after implementing the delay specified by the value.• If usb_20_hsic_auto_connect_delay is negative, the VIP will not move to T2 until it receives a DRIVE_HSIC_CONNECT physical service command.

T2 - Power On, HSIC Enabled, Peripheral signals Connect state

Description	This state models a HSIC peripheral in the "Power state is ON, HSIC is enabled, and Peripheral signals a CONNECT" state and starting to drive CONNECT.
Entry	From state T1.
Action	The VIP issues the NOTIFY_USB_20_HSIC_CONNECT_INITIATED notification and drives CONNECT on the bus.
Exit	<p>The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF).</p> <p>The VIP moves to T3 after implementing the delay specified by the usb_20_hsic_connect_time.</p>

T3 - Power On, HSIC Enabled, Peripheral signals Connect state

Description	This state models a HSIC peripheral in the "Power state is ON, HSIC is enabled, and Peripheral signals a CONNECT" state and starting to drive IDLE.
Entry	From state T2.
Action	The VIP issues the NOTIFY_USB_20_HSIC_CONNECT_DRIVE_IDLE notification and starts to drive IDLE on the bus.

T3 - Power On, HSIC Enabled, Peripheral signals Connect state

Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves to T4 after implementing the delay specified by the <code>usb_20_hsic_connect_idle_time</code> .
------	---

T4 - Power On, HSIC Enabled, Peripheral signals Connect state

Description	This state models the point at which a HSIC peripheral stops driving IDLE following the end of driving CONNECT.
Entry	From state T3.
Action	<p>The VIP issues the <code>NOTIFY_USB_20_HSIC_CONNECT_COMPLETED</code> notification and stops driving the bus.</p> <p>The VIP starts to monitor the Strobe and Data lines for a RESET bus state.</p> <div data-bbox="584 856 672 900" data-label="Image"></div> <p>Note At this point, the VIP starts operating as a standard USB 2.0 device. It begins using standard USB 2.0 configuration timers and state.</p>
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves to T5 when it detects the bus transition to the RESET bus state.

T5 - Host drive HSIC RESET state


Description	This state models a HSIC host in processes of driving RESET.
Entry	From state T4.
Action	The VIP starts to monitor the Strobe and Data lines for the end of RESET.
Exit	<p>The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF).</p> <p>The VIP moves to T6 when it detects the bus transition to the IDLE bus state.</p>

T6 - HSIC IDLE

Description	This state models a HSIC peripheral driving the IDLE state following driving RESET.
-------------	---



T6 - HSIC IDLE

Entry	From state T6.
Action	The VIP starts to monitor the Strobe and Data lines for the end of IDLE.
	 Note The VIP is ready to start exchanging data across the bus (as illustrated at T8).
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves to T8 if packet transmission or reception is started.

T7 - HSIC IDLE

Description	This state models a HSIC host in the idle state following driving post-RESET IDLE.
Entry	none
Action	none
Exit	n/a

T8 - HSIC transfer

Description	This state models the transfer of data across the bus.
Entry	From state T6
Action	The VIP is receiving or transmitting packet data.
Exit	The VIP moves to T-1 if it receives a request to power down (via physical service command VBUS_OFF). The VIP moves back to T6 when packet reception/transmission has completed.

6.4.6.12.4 Bus Keepers

When operating as a Host, the HSIC device is responsible for providing Bus Keepers that maintain IDLE on the bus when the bus is not being driven. When configured as a HSIC Host, the VIP provides the ability to configure the timing of its Bus Keepers. The VIP provides independent Bus Keeper enable and disable timers with half-strobe resolution.

Control of the VIP's Bus Keeper timers is through the following configuration properties:

- ❖ `usb_20_hsic_bus_keeper_on_count` - Number of half-strobe periods from IDLE detect to Bus Keepers being enabled.
- ❖ `usb_20_hsic_bus_keeper_off_count` - Number of half-strobe periods from non-IDLE detect to Bus Keepers being disabled.

By default, these timers are set to the value 3 (which translates into the nominal HSIC Bus Keeper timing requirement of 1.5 Strobe-periods).

6.4.6.12.5 Data Inversion

The original HSIC specification failed to identify any correlation between the data values transmitted on the HSIC bus and standard HS USB J and K values. The HSIC ECN that followed does clearly state this correlation. Some "legacy" devices, those designed before the ECN, may transmit and receive what is now considered inverted packet data (i.e. the

SYNC pattern terminating with two J's, rather than with two K's). "Non-legacy" devices, those designed after the ECN are required to support reception of inverted packet data, but are not allowed to transmit inverted packet data.

The VIP supports the ability to both transmit and receive inverted packet data. Control of these features is through the following configuration properties:

- ❖ `usb_20_hsic_tx_inversion_enable` - Enables transmission of inverted packet data.
- ❖ `usb_20_hsic_dut_is_legacy_device` - Used to identify when the DUT is a legacy device. A legacy device is allowed to transmit inverted packet data.

Whenever the `usb_20_hsic_tx_inversion_enable` property is set false (the default), the VIP transmits normal packets; whenever set true, the VIP transmits inverted packets.

Whenever the `usb_20_hsic_dut_is_legacy_device` property is set false (the default), the VIP will register a failure for each inverted packet it receives; whenever set true, the VIP will receive inverted packets without complaint.

6.4.6.12.6 Data EOP Signaling

Following the completion of data signaling, the transmitting device is expected to drive IDLE for 2 Strobe-Periods. However, since transmitting the last bit of a packet's EOP does not always leave the bus in an IDLE state (STROBE=1 DATA=0), the transmitter may be required to move the bus to IDLE first.

By default, the VIP will drive the end of data signaling as illustrated in [Figure 6-23](#) and [Figure 6-24](#). In the case where the last bit of EOP leaves the bus in the IDLE state, the VIP starts driving IDLE immediately. In the case where STROBE ends low, the VIP will start driving IDLE on the bus when it drives STROBE high at the next half Strobe-Period boundary, resulting in the transmission of one extra bit of data. In the case where both STROBE and DATA end high, the VIP starts driving IDLE on the bus when it drives DATA low three eighths of a Strobe-Period period after the last rising edge of Strobe.

Figure 6-10 End of signaling scenarios with DATA low






Figure 6-11 End of signaling scenarios with DATA high (fast EOP)



When `usb_20_hsic_fast_eop_to_idle_disable` is set to 1, the VIP will always terminate data signaling by entering IDLE on the rising edge of the STROBE signal. The one case affected by this is when the data signaling completes with both DATA and STROBE high. In this case, two extra bits of data will be generated following the last bit of transmitted data. This case is illustrated in [Figure 6-25](#).

Figure 6-12 End of signaling scenarios with DATA high (fast EOP disabled)

6.4.6.12.7 Modeling Power Off

The HSIC specification identifies each HSIC device as being self-powered. The VIP, considered to be in powered off state prior to being started, immediately enters the powered on state when started. After being started, the VIP can move into and out of the powered off state using the following physical service commands:

- ❖ VBUS_OFF - When configured for HSIC, moves the VIP into the powered off state.
- ❖ VBUS_ON - When configured for HSIC, moves the VIP into the powered on state.

6.4.6.12.8 Controlling Skew

The HSIC specification identifies a maximum limit on the allowable "Circuit Board Trace propagation skew" between the Strobe and Data signals. In essence, this parameter is specified to help ensure "signal timing is within specification limits at the receiver". The VIP provides the ability to configure both the skew it expects during detection of bus state transitions, and the skew it uses during the driving of bus state transitions.

Control of the VIP's Strobe/Data skew is through the following configuration properties:

- ❖ `usb_20_hsic_strobe_data_rx_skew` - Defines the maximum expected skew between Strobe and Data during detection of bus state transitions.
- ❖ `usb_20_hsic_strobe_data_tx_skew` - Defines the skew that is driven between Strobe and Data during the driving of bus state transitions.

Note these properties only effect skew during non-data signaling; they have no effect on the timing of Strobe and Data during data signaling. When transmitting data, the VIP sets up Data one eighth of a Strobe-period prior to driving an edge on Strobe, and holds data for three eighths of a Strobe-period following the driving of an edge on Strobe.

6.4.6.12.9 Controlling RX Skew

The `usb_20_hsic_strobe_data_rx_skew` value is used by the VIP to control the maximum amount of expected skew between Strobe and Data whenever the VIP is detecting a bus state transition. This value identifies the amount of time the Strobe signal may lead or lag the Data signal during detection of bus state transitions: When this timing is met, the VIP will detect a single state transition. When the timing is not met, the VIP will detect multiple state transitions.

For example, in the case of the VIP detecting a transition from SUSPEND (Strobe/Data = 10) to RESUME (Strobe/Data = 01), the VIP expects to see one of the following three scenarios:

- ❖ A bus transition where Strobe and Data change together: 10->01
- ❖ A bus transition where Strobe leads Data: 10->00->01
- ❖ A bus transition where Strobe lags Data: 10->11->01

In each of the preceding scenarios, the `usb_20_hsic_strobe_data_rx_skew` value is used to determine whether or not one or more states transitions get detected: If the end-to-end timing of the completed transition is less than or equal to the value of `usb_20_hsic_strobe_data_rx_skew`, the VIP detects a single state transition. If the end-to-end timing is greater than `usb_20_hsic_strobe_data_rx_skew`, the VIP detects multiple state transitions.

6.4.6.12.10 Controlling TX Skew

The `usb_20_hsic_strobe_data_tx_skew` value is used to control the amount of skew the inserts between Strobe and Data whenever it drives a bus state transition. This property, treated as a signed value, identifies the amount of time the Strobe signal will lead the Data signal: When positive, this value defines the length of time by which the Strobe will lead the Data signal. When negative, this value defines the length of time by which the Strobe will lag the Data signal. When zero, the Strobe and Data signals are driven simultaneously.

For example, in the case of the VIP driving a transition from SUSPEND (Strobe/Data = 10) to RESUME (Strobe/Data = 01). The `usb_20_hsic_strobe_data_tx_skew` value would have the following effect:

- ❖ If zero, the VIP drives the following Strobe/Data transition: 10->01
- ❖ If positive, the VIP drives the following Strobe/Data transition: 10->00->01
- ❖ If negative, the VIP drives the following Strobe/Data transition: 10->11->01

In each of the preceding scenarios, the `usb_20_hsic_strobe_data_tx_skew` value defines the end-to-end timing of the completed transition.

6.4.7 Using 2.0 Test Mode with UTMI

This section documents on how to use Test Mode. All high-speed capable devices/hubs must support Test Mode requests. These requests are not supported for non-high-speed devices. Otherwise, the VIP will issue a warning and Abort the protocol service.

6.4.7.1 Entering Test Mode

You enter Test Mode of a port by using a device specific standard request (for an upstream facing port) or a port specific hub class request (for a downstream facing port):

- ❖ The device standard request SetFeature (TEST_MODE) as defined in Section 9.4.9 of the USB protocol.
- ❖ The hub class request SetPortFeature (PORT_TEST) as defined in Section 11.24.2.13 of the USB protocol.

6.4.7.1.1 Using the UTMI VIP as a Device MAC

1. Issue a control transfer (set_feature with feature_selector set to TEST_MODE) command to Host (VIP/DUT).
2. The VIP will not interpret the control transfer. As a result, on *successful* completion of this transfer issue the Protocol_service to enter test mode.
 - a. Set Protocol_service with service_type to TEST_MODE and the protocol_20_command_type to one of the following values:
 - ❖ USB_20_TEST_MODE_TEST_SE0_NAK

- ✧ USB_20_TEST_MODE_TEST_J
 - ✧ USB_20_TEST_MODE_TEST_K
 - ✧ USB_20_TEST_MODE_TEST_PACKET
- b. The protocol_20_command_type enum value should match whatever has been passed in the control transfer.

6.4.7.1.2 Using the UTMI VIP as a Host MAC

1. Issue Protocol_service to enter test mode.
2. Set protocol_service with service_type set to TEST_MODE, and protocol_20_command_type set to one of the following values:
 - ✧ USB_20_TEST_MODE_TEST_SE0_NAK
 - ✧ USB_20_TEST_MODE_TEST_J
 - ✧ USB_20_TEST_MODE_TEST_K
 - ✧ USB_20_TEST_MODE_TEST_PACKET

6.4.7.2 Verifying TEST_PACKET

According to the USB 2.0 specification “Upon command, a port must repetitively transmit the following test packet until the exit action is taken. This enables the testing of rise and fall times, eye patterns, jitter, and any other dynamic waveform specifications.”

The test packet is created by concatenating the following strings. (Note: For J/K NRZI data, and for NRZ data, the bit on the left is the first one transmitted).

- ✧ "S" indicates that a bit stuff occurs, which inserts an "extra" NRZI data bit. "
- ✧ *N" is used to indicate N occurrences of a string of bits or symbols.

A port in Test_Packet mode must send this packet repetitively. The inter-packet timing must be no less than the minimum allowable inter-packet gap as defined in Section 7.1.18 and no greater than 125.

6.4.7.2.1 Using the UTMI VIP as a Device MAC

1. Issue a control transfer (set_feature with feature_selector set to TEST_MODE & TEST_SELECTOR set to TEST_PACKET) command to the host UTMI VIP using a remote phyHost (VIP/DUT).
2. The VIP does not interpret the control transfer. As a result, on a *successful* completion of this transfer, issue Protocol_service to enter test mode.
 - a. Set the Protocol_service with service_type set to TEST_MODE and protocol_20_command_type to USB_20_TEST_MODE_TEST_PACKET.
 - b. On reception of this protocol service, the device will create link_service and send it to the link layer. The link_service with service_type to LINK_20_PORT_COMMAND and link_20_command_type to USB_20_PORT_TEST_MODE_TEST_PACKET are put into the link layer service channel.
 - c. On successful completion of link_service command, the VIP will create TEST_PACKET and send it to the link layer. The Packet sent to link layer is 53 byte long, with PID set to DATA0. The payload will contain following.

```
00 00 00 00 00 00 00 00
00 AA AA AA AA AA AA AA
AA EE EE EE EE EE EE EE
EE FE FF FF FF FF FF FF
```

```
FF FF FF FF FF 7F BF DF
EF F7 FB FD FC 7E BF DF
EF F7 FB FD 7E
```

The Protocol layer will wait for a packet ENDED notification. On receiving notification it will put the same packet again into the link layer packet channel. It is the link layer responsibility to schedule the packet after the expiration of the interpacket delay.

The Protocol layer will continue to send test_packet to the link layer until TEST_Mode is exited.

6.4.7.2.2 Using the UTMI VIP as a Host MAC

1. Issue Protocol_service to enter test mode.
2. Set Protocol_service with service_type to TEST_MODE and protocol_20_command_type set to USB_20_TEST_MODE_TEST_PACKET. On reception of this protocol service, the device creates a link service and sends it to the link layer.
3. link_service with service_type to LINK_20_PORT_COMMAND and link_20_command_type to USB_20_PORT_TEST_MODE_TEST_PACKET is put into link layer service channel.
4. On completion of the link_service command, the host VIP creates TEST_PACKET and sends it to the link layer. The packet sent to link layer is 53 byte long, with PID set to DATA0. The payload will contain following.

```
00 00 00 00 00 00 00 00
00 AA AA AA AA AA AA AA
AA EE EE EE EE EE EE EE
EE FE FF FF FF FF FF FF
FF FF FF FF FF 7F BF DF
EF F7 FB FD FC 7E BF DF
EF F7 FB FD 7E
```

The Protocol layer will wait for a packet ENDED notification. On receiving the notification, it will put the same packet again into link layer packet channel. It is the link layer responsibility to schedule the packet after the expiration the of interpacket delay.

The Protocol layer will continue to send test_packet to the link layer until TEST_Mode is exited.

6.4.7.3 Verifying TEST_J

According to USB 2.0 specification regarding Test mode Test_J: “Upon command, a port's transceiver must enter the high-speed J state and remain in that state until the exit action is taken. This enables the testing of the high output drive level on the D+ line.”

6.4.7.3.1 Using the UTMI VIP as a Device MAC

1. Issue a control transfer (set_feature with feature_selector set to TEST_MODE and TEST_SELECTOR set to TEST_J) command to the Host (VIP/DUT).
2. The VIP does not interpret the control transfer. As a result, on *successful* completion of this transfer model enters test mode.
 - a. Set Protocol_service with service_type to TEST_MODE and protocol_20_command_type to USB_20_TEST_MODE_TEST_J.
 - b. On reception of protocol service, the device vip will create a link_service and send it to the link layer.

- c. The link_service with service_type set to LINK_20_PORT_COMMAND and link_20_command_type set to USB_20_PORT_TEST_MODE_TEST_J is put into link layer service channel.

6.4.7.3.2 Using the UTMI VIP as a Host MAC

1. Issue Protocol_service to enter test mode. Set Protocol_service with service_type set to TEST_MODE and protocol_20_command_type set to USB_20_TEST_MODE_TEST_J.
2. On reception of the protocol service, the device VIP will create a link_service and send it to the link layer.
3. Link_service with service_type set to LINK_20_PORT_COMMAND and set link_20_command_type to USB_20_PORT_TEST_MODE_TEST_J is put into link a layer service channel

6.4.7.4 Verifying TEST_K

According to USB 2.0 specification regarding Test Mode Test_K: “Upon command, a port's transceiver must enter the high-speed K state and remain in that state until the exit action is taken. This enables the testing of the high output drive level on the D- line.”

6.4.7.4.1 Using the UTMI VIP as a Device MAC

1. Issue a control transfer (set_feature with feature_selector set to TEST_MODE and TEST_SELECTOR set to TEST_K) command to the Host (VIP/DUT).
2. The VIP does not interpret the control transfer. As a result, on *successful* completion of this transfer issue a Protocol_service request to enter test mode.
 - a. Issue Protocol_service with service_type set to TEST_MODE, and protocol_20_command_type set to USB_20_TEST_MODE_TEST_K.
 - b. On reception of this protocol service request, the device VIP will create a link_service and send it to the link layer.
 - c. link_service (with service_type set to LINK_20_PORT_COMMAND and link_20_command_type set to USB_20_PORT_TEST_MODE_TEST_K) is put into link layer service channel.

6.4.7.4.2 Using the UTMI VIP as a Host MAC

1. Issue Protocol_service to enter test mode. Protocol_service request with service_type set to TEST_MODE and protocol_20_command_type set to USB_20_TEST_MODE_TEST_K.
2. On reception of this protocol service, the host VIP creates link_service and sends it to the link layer.
3. The link_service with service_type set to LINK_20_PORT_COMMAND and link_20_command_type set to USB_20_PORT_TEST_MODE_TEST_K is put into link layer service channel

6.4.7.5 Verifying TEST_SE0_NAK

According to USB 2.0 specification regarding Test mode Test_SE0_NAK: “Upon command, a port's transceiver must enter the high-speed receive mode and remain in that mode until the exit action is taken. This enables the testing of output impedance, low level output voltage, and loading characteristics. In addition, while in this mode, upstream facing ports (and only upstream facing ports) must respond to any IN token packet with a NAK handshake (only if the packet CRC is determined to be correct) within the normal allowed device response time. This enables testing of the device squelch level circuitry and, additionally, provides a general purpose stimulus/response test for basic functional testing.”

6.4.7.5.1 Using the UTMI VIP as a Device MAC

1. Issue a control transfer (set_feature with feature_selector set to TEST_MODE & TEST_SELECTOR set to TEST_SE0_NAK) command to the Host (VIP/DUT).
2. The VIP does not interpret the control transfer. As a result, on *successful* completion of this transfer issue Protocol_service enters test mode.
 - a. Issue Protocol_service with service_type set to TEST_MODE and protocol_20_command_type set to USB_20_TEST_MODE_TEST_SE0_NAK.
 - b. On reception of this protocol service, the device VIP creates link_service and sends it to the link layer.
 - c. link_service with service_type set to LINK_20_PORT_COMMAND and link_20_command_type set to USB_20_PORT_TEST_MODE_TEST_SE0_NAK is put into link layer service channel
 - d. If the user wants to test a NAK response, they put IN TOKEN PACKET into the packet input channel of the link layer of the host.
 - e. For any IN TOKEN PACKET received during a TEST_SE0_NAK state, the device will respond with NAK if CRC is found to be correct.

6.4.7.5.2 Using the UTMI VIP as a Host MAC

1. Issue a control transfer (set_feature with feature_selector set to TEST_MODE & TEST_SELECTOR set to TEST_SE0_NAK) command to the host.
2. The VIP does not interpret the control transfer. As a result, on *successful* completion of this transfer issues Protocol_service to enter test mode.
 - a. Issue Protocol_service with service_type set to TEST_MODE and protocol_20_command_type set to USB_20_TEST_MODE_TEST_SE0_NAK.
 - b. On reception of this protocol service, the host VIP creates link_service and sends it to the link layer.
 - c. link_service with service_type set to LINK_20_PORT_COMMAND and link_20_command_type set to USB_20_PORT_TEST_MODE_TEST_SE0_NAK is put into a link layer service channel

6.4.7.6 Exiting test_mode on Downstream Facing Ports

According to USB 2.0 specification for a downstream facing port, the exit action is to reset the hub, as defined in Section 11.24.2.13. After the test is completed, the hub (with the port under test) must be reset by the host or user. This must be accomplished by manipulating the port of the parent hub to which the hub under test is attached. This manipulation can consist of one of the following:

- ❖ Issuing a SetPortFeature (PORT_RESET) to port of the parent hub to which the hub under test is attached.
- ❖ Issuing a ClearPortFeature (PORT_POWER) and SetPortFeature (PORT_POWER) to cycle power of a parent hub that supports per port power control.
- ❖ Disconnecting and re-connecting the hub under test from its parent hub port.
- ❖ For a root hub under test, a reset of the Host Controller may be required as there is no parent hub of the root hub.

To exit TEST_MODE, issue a port_reset command. Set link_service with service_type set to LINK_20_PORT_COMMAND and link_20_command_type set to SVT_USB_20_PORT_RESET.

According to USB 2.0 specification for an upstream facing port, the exit action is to power cycle the device. It is the host/testbench responsibility to power cycle the device VIP.

6.4.7.7 Test Mode Notifications

The following notifications in `svt_usb_status` support Test Mode:

- ❖ `NOTIFY_PORT_TEST_MODE_ENTERED`
- ❖ `NOTIFY_PORT_TEST_MODE_EXITED`
- ❖ `NOTIFY_PORT_TEST_MODE_ENTERED` is issued by the link layer on reception of a `link_service` command, and on expiration of `ttest_mode_entry_delay`. It is issued when `TEST_MODE` is entered.
- ❖ `NOTIFY_PORT_TEST_MODE_EXITED` is issued when `TEST_MODE` is exited.

6.4.7.8 Test Mode Configuration Members

- ❖ `ttest_mode_entry_delay` in the `svt_usb_configuration` class. Models the delay between successful completion of a status stage and the host/device entering `TEST_MODE`.
- ❖ `ttest_mode_entry_delay`. Defaults to ``SVT_USB_20_USER_TEST_MODE_ENTRY_DELAY_MAX` which is set to 3ms. User can override this define.

6.4.8 SuperSpeed InterChip Physical (SSIC) Usage

The USB Verification IP supports SSIC RMMI interfaces connected to an M-Phy supporting an RMMI interface. The following sections show general usage of the SSIC Physical transactor.

The `svt_usb_subenv::new()` constructor takes a `svt_usb_agent_configuration` object as the `cfg` argument and a `svt_usb_configuration` object as the `remote_cfg` argument. These parameters represent

- ❖ The `cfg` object represents the VIP's view of its configuration with respect to its local side of the connection.
- ❖ The `remote_cfg` object represents the VIP's view of the remote Phy's configuration.

Note, the subsections focus on configuring parameter values `cfg` and `remote_cfg` at instantiation time for several connection scenarios.

6.4.8.1 Configuring the VIP for a DUT Without a SSIC Physical Layer

If the VIP USB Host/Device is being used to test a DUT which does not contain an SSIC Phy (i.e. if the DUT's connection is from the MAC perspective of an SSIC MAC/Phy RMMI interface) then the VIP requires two `svt_usb_subenv_configuration` objects: `cfg` and `remote_cfg`. In this case, the VIP can be thought of as containing two *virtual* Physical layers (one local, and the other remote):

6.4.8.1.1 cfg Parameter Settings

The following settings would be typical for the `cfg` parameter discussed previously:

- ❖ `ssic_profile` = <desired profile to use>
- ❖ `ssic_pairs` = must equal the number of pairs required by `ssic_profile`.
- ❖ `bottom_layer` = `SUB_PHYSICAL`
- ❖ `top_layer` >= `PROTOCOL` (assuming VIP functionality up through protocol layer *transfers* is desired)
- ❖ `component_subtype` = `MAC`
- ❖ `usb_ss_signal_interface` = `USB_SSIC_TLM`

- ❖ **usb_mphy_rx_cfg[\$]** and **usb_mphy_tx_cfg[\$]** have settings of:
 - ◆ Must size to have **cfg.ssic_pairs** entries in each array
 - ◆ **mphy_component_type == svt_mphy_configuration::PHY**
 - ◆ **mphy_interface_type == svt_mphy_configuration::RMMI_REMOTE**
 - ◆ **mphy_tlm_if_type == svt_mphy_configuration::TLM_LOCAL**

With UVM, the interfaces are assigned through the **config_db**.

6.4.8.1.2 remote_cfg Parameter Settings

The following settings would be typical for the **cfg** parameter discussed previously:

- ❖ **ssic_profile** = Must match the value in **cfg**
- ❖ **ssic_pairs** = Must match the value in **cfg**
- ❖ **component_subtype** = **PHY**
- ❖ **usb_ss_signal_interface** = **SSIC_RMMI_IF**
- ❖ **usb_mphy_rx_cfg[\$]** and **usb_mphy_tx_cfg[\$]** have settings of:
 - ◆ Must size to have **cfg.ssic_pairs** entries in each array
 - ◆ **mphy_interface_type == svt_mphy_configuration::RMMI_REMOTE**
 - ◆ **mphy_tlm_if_type == svt_mphy_configuration::TLM_REMOTE**
 - ◆ **mphy_component_type == PHY**

With UVM, the interfaces are assigned through the **config_db**.

6.4.8.2 Configuring the VIP for a DUT With a SSIC Physical Layer

In this section, configuration options are shown for a DUT with a SSIC Physical Layer.

If the VIP USB Host/Device is being used to test a DUT which contains an SSIC Phy if the DUT's connection is directly to the SSIC Serial interface), then the VIP requires one **svt_usb_subenv_configuration** object **cfg** (and no **remote_cfg**). In this case, the VIP can be thought of as containing one virtual Phy (its local phy). The **cfg** object represents the VIP's view of its configuration with respect to its local side of the connection, while the **remote_cfg** object represents the VIP's view of the remote Phy's configuration.

6.4.8.2.1 cfg Parameter Settings

- ❖ **ssic_profile** = <desired profile to use>
- ❖ **ssic_pairs** = must equal the number of pairs required by **ssic_profile**.
- ❖ **bottom_xactor** (UVM) / **bottom_layer** (UVM) = **SUB_PHYSICAL**
- ❖ **top_xactor** (UVM) / **top_layer** (UVM) **>= PROTOCOL** (assuming VIP functionality up through protocol layer *transfers* is desired)
- ❖ **component_subtype** = **MAC**
- ❖ **usb_ss_signal_interface** = **SSIC_SERIAL_IF**
- ❖ **usb_mphy_rx_cfg[\$]** and **usb_mphy_tx_cfg[\$]** have settings of:
 - ◆ Must size to have **cfg.ssic_pairs** entries in each array
 - ◆ **mphy_component_type == svt_mphy_configuration::PHY**
 - ◆ **mphy_interface_type == svt_mphy_configuration::SERIAL**

◆ `mphy_tlm_if_type == svt_mphy_configuration::TLM_NONE`

With UVM, the interfaces are assigned through the `config_db`.

6.4.8.2.2 remote_cfg Parameter Settings

For this type of connection (an SSIC Serial connection), the parameter `remote_cfg` remains null.

6.5 Implementing Functional Coverage

USB3.0 Verification IP coverage uses following mechanisms

- ❖ Pattern sequences between Initiator (USB Host) and Responder (USB Device) entities.
 - ◆ Super speed protocol layer, link layer and USB20 protocol layer coverage is based on pattern sequences
- ❖ Signaling on the bus between USB Host and device.
 - ◆ USB2.0 link layer coverage based on signaling on the bus.

6.5.1 Default Functional Coverage

The USB Verification IP supports protocol and link layer functional coverage for Super Speed (SS) and USB20 modes of operation. The protocol and link layer functional coverage items are provided by host and device components via the component callback classes.

[Table 6-15](#) lists the default functional coverage features provided with USB3.0 Verification IP.

Table 6-15 Default Functional Coverage Features

Layer/Coverage	SuperSpeed	USB20
Protocol	<ul style="list-style-type: none"> Bulk transfers Interrupt transfers Control transfers ISOC transfers 	<ul style="list-style-type: none"> Bulk Transfers Interrupt transfers Control transfers ISOC transfers Split transfers
Link	Link Management and Flow control <ul style="list-style-type: none"> Header packet Link Command Low Power Management DPP Link Initialization Link Training and Status State Machine	<ul style="list-style-type: none"> Connect/Disconnect Reset Suspend/Resume Link Power Management

The functional coverage data collected is instance based. This means that each instance of the VIP gathers and maintains its own functional coverage information.

**Note**

Detailed information about covergroups in USB3.0 Verification IP can be found in the class reference HTML located at:

[\\$DESIGNWARE_HOME/vip/svt/usb_svt/latest/doc/usb_svt_uvm_class_reference/html/index.html](#)

6.5.2 Covergroup Organization

For the coverage based on sequences (such as Protocol layer coverage), the covergroup is organized as the collection of coverpoints and the cross of these coverpoints.

The coverpoints are divided into the following four categories:

- ❖ [Normal Behavior Sequences](#)
- ❖ [Error Condition Sequences](#)
- ❖ [Packet Field Range Coverpoints](#)
- ❖ [Data Collection Coverpoints](#)

6.5.2.1 Normal Behavior Sequences

These are the sequences, in which the responder entity (host or device) responds without any error for a transaction.

Example: `svt_usb_ack_dp_packet_sequence`

6.5.2.2 Error Condition Sequences

These are the sequences, in which errors are injected in the packets sent by the host or device. Depending on the error situation there may or may not be a response sequence.

Example: `svt_usb_invalid_ack_no_response_packet_sequence`

6.5.2.3 Packet Field Range Coverpoints

These are coverpoints that define ranges for the field values in a packet. These are typically used to define data length ranges, and sequence numbers.

Example: `data_length_range_low1_mid_high1`

6.5.2.4 Data Collection Coverpoints

These are all the data points that are captured as `svt_usb_packet` attribute field (such as flow control situations, and error injections).

Examples: `eob_lpf_bit`, `rtty_bit`, `after_inactive_flow_control`, and `preexisting_flow_control_state`

These attributes can take values either 0 or 1 (`rtty_bit`, `eob_lpf_bit`, `setup_bit`), or enumerated values (`preexisting_flow_control_state`, `cov_flow_control_cause`)

6.5.2.5 Crosses

You can define crosses by crossing one or more of the coverpoints in the above categories.

Examples:

- ❖ For normal traffic, normal behavior sequences are crossed with packet field range coverpoints.
cross of (`svt_usb_ack_dp_packet_sequence`) and (`data_length_range_low1_mid_high1`)

- ❖ For erroneous traffic, the error condition sequences are crossed with data collection coverpoints.
cross of (svt_usb_invalid_ack_no_response_packet_sequence) and (invalid_hp_sequence)
- ❖ For specific scenarios (for example, flow control state) the normal behavior sequences are crossed with data collection coverpoints.
cross of (ack_nrdy_sequence) and (flow_control_cause) and (after_flow_controlled)



Note For all the cover points participating in the cross coverage, the options.weight is set to zero. This means that the individual cover points do not contribute to the coverage score in those cover groups.

6.5.3 Range Bins

Range bins are defined by dividing the total range of possible values into a few buckets. The buckets are divided as low, mid and high values. The low and high carry the min and max values. The mid values may contain all mid values as one or two buckets.

Example 1

For data length associated with bulk transfers is defined as follows:

```
data_length_range_low1_mid_high1 : coverpoint cov_data_length_range {
bins data_length_range_low1[] = { 0 };
bins data_length_range_mid = { [1:`SVT_USB_SS_MAX_PACKET_SIZE-1] };
bins data_length_range_high1[] = { `SVT_USB_SS_MAX_PACKET_SIZE }; }
```

In the above example, the data_length_range_low1_mid_high1 is divided into three buckets with low (0 value), high (MPS) and mid (1 to MPS-1), where MPS is the Max Packet Size.

Example 2

For data length with babble associated with bulk transfer is defined as follows:

```
data_length_range_low1_mid_high1_babble : coverpoint cov_data_length_range {
bins data_length_range_low1[] = { 0 };
bins data_length_range_mid = { [1:`SVT_USB_SS_MAX_PACKET_SIZE-1] };
bins data_length_range_high1[] = { `SVT_USB_SS_MAX_PACKET_SIZE };
bins data_length_range_babble = { 1030 }; }
```

Example 3

For USB20 high speed packet field range is defined as follows:

```
hs_bulk_max_packet_size_min_mid_max : coverpoint cov_20_max_packet_size {
bins max_packet_size_min = { 0 };
bins max_packet_size_mid = { [1:(`SVT_USB_STATIC_HS_BULK_MAX_PACKET_SIZE-1)] };
bins max_packet_size_max = { `SVT_USB_STATIC_HS_BULK_MAX_PACKET_SIZE }; }
```

6.5.4 Default Functional Coverage Class Hierarchy

The basic classes are:

- ❖ Pattern sequences
- ❖ Component coverage data callbacks
- ❖ Component coverage callbacks

6.5.4.1 Pattern Sequences

These classes are not part of coverage hierarchy but used to define the patterns of the sequences to be compared in the simulation data for default coverage. The protocol layer sequence objects are extended from svt_pattern class. The link layer sequence objects are extended from svt_usb_pattern class.

6.5.4.2 Component Coverage Data Callbacks


This callback class defines default data and event information that are used to implement the coverage groups. The naming convention uses “def_cov_data” in the class names for easy identification of these classes. This class also includes implementations of the coverage methods that respond to the coverage requests by setting the coverage data and triggering the coverage events. This implementation does not include any coverage groups. The def_cov_data callbacks classes are extended from component callbacks.

6.5.4.3 Component Coverage Callbacks

This class is extended from the component coverage data class. The naming convention uses “def_cov” in the class names for easy identification of these classes. It includes default cover groups based on the data and events defined in the data class.

The class hierarchy of default functional coverage described above is as shown in [Figure 6-13](#).

Figure 6-13 Default Functional Coverage Class Hierarchy



6.5.5 Coverage Callback Classes

The following naming convention is used for coverage callback classes:

svt_usb_<layer>_<speed>_<VIP config>_def_cov_<type>_callbacks

Where:

<layer>: protocol, link, physical

<speed>: ss or 20

<VIP config>: host or device

<type>: data for callback classes defining the default data, methods and event information used for coverage
none for callback classes defining default cover groups

Table 6-16 lists the coverage callback classes.

Table 6-16 Coverage Callback Classes

Class Name	Type	Layer	Configuration
svt_usb_protocol_ss_host_def_cov_data_callbacks	Data	Protocol	SuperSpeed Host
svt_usb_protocol_ss_host_def_cov_callbacks	Cover Groups	Protocol	SuperSpeed Host
svt_usb_protocol_ss_device_def_cov_data_callbacks	Data	Protocol	SuperSpeed Device
svt_usb_protocol_ss_device_def_cov_callbacks	Cover Groups	Protocol	SuperSpeed Device
svt_usb_protocol_20_host_def_cov_data_callbacks	Data	Protocol	USB20 Host
svt_usb_protocol_20_host_def_cov_callbacks	Cover Groups	Protocol	USB20 Host
svt_usb_protocol_20_device_def_cov_data_callbacks	Data	Protocol	USB20 Device
svt_usb_protocol_20_device_def_cov_callbacks	Cover Groups	Protocol	USB20 Device
svt_usb_link_ss_def_cov_callbacks	Cover Groups	Link	SS Host or Device
svt_usb_link_ss_def_cov_data_callbacks	Data	Link	SS Host or Device
svt_usb_link_20_host_def_cov_callbacks	Cover Groups	Link	USB20 Host
svt_usb_link_20_host_def_cov_data_callbacks	Data	Link	USB20 Host



Note Information about coverage callbacks in USB3.0 Verification IP can be found in the class reference HTML located at:

[\\$DESIGNWARE_HOME/vip/svt/usb_svt/latest/doc/usb_svt_uvm_class_reference/html/index.html](#)

6.5.6 Using Functional Coverage

The default functional coverage can be enabled by setting the attributes in the host or device agent configuration. The attributes are:

- ❖ enable_prot_cov - enables all protocol layer cover groups
- ❖ enable_link_cov - enables all link layer cover groups

6.5.6.1 Coverage Extensions

You can extend the coverage callback classes to specify user-defined coverage in addition to default coverage provided in the model. Callbacks are added using the following syntax.

```
uvm_callbacks#(T)::add(obj,cb);
```

6.5.7 Using the High-Level Verification Plans

High-level verification plans (HVPs) are provided for typical USB verification topologies.

The top-level verification plans can be found after installation at \$DESIGNWARE_HOME/vip/svt/usb_svt/<version>/doc/VerificationPlans directory. These plans have the following naming convention:

```
svt_<suite>_<operation_mode>_dut_<protocol_mode>_toplevel_fc_plan
```

In addition, there are several sub-plans. Each sub-plan has the following naming convention:

```
svt_<suite>_<vip_layer>_<protocol_mode>_<transfer_type>
```

6.6 Using the Passive Monitor

You can use the VIP as standalone passive monitor or can use it together as an active component of the VIP. All the steps for both the components are similar, except the instance as you will have to define the instance active or passive for their respective components.



Note

It is recommended to set the configuration parameter with DUT.

The following test bench examples explain passive monitor as Host Passive Monitor or as Device Passive Monitor:

6.6.1 VIP as Host Passive Monitor

Perform the following steps to use VIP as standalone passive monitor:

1. Create the following agent:

```
svt_usb_agent host_mon_agent;
```

2. Set the VIPs configuration similar to host(dut) configuration (assuming host configuration instance is host_cfg)

```
uvm_config_db#(svt_usb_agent_configuration)::set(this, "host_mon_agent", "cfg",  
cfg.host_cfg);
```

3. Set the VIP as passive component

```
uvm_config_db#(bit)::set(this, "host_mon_agent", "is_active", 0);
```

4. Set the following interface (for example, when host interface instance is host_usb_if)

```
uvm_config_db#(USB_IF)::set(this, "host_mon_agent", "usb_ss_if",  
this.host_usb_if);
```

6.6.2 VIP as Device Passive Monitor

Perform the following steps to use VIP as standalone passive monitor:

1. Create the following agent:

```
svt_usb_agent dev_mon_agent;
```

2. Set the VIPs configuration same as device(dut) configuration (assuming device configuration instance is dev_cfg)

```
uvm_config_db#(svt_usb_agent_configuration)::set(this, "dev_mon_agent", "cfg",  
cfg.dev_cfg);
```

3. Set the VIP as passive component

```
uvm_config_db#(bit)::set(this, "dev_mon_agent", "is_active", 0);
```

4. Set the following interface (for example, when device interface instance is dev_usb_if)

```
uvm_config_db#(USB_IF)::set(this, "dev_mon_agent", "dev_ss_if", this.dev_usb_if);
```

**Note**

Passive Monitor support is not available for physical as top layer.

7

Debug

This section provides an overview of debug tools available with SVT USB VIP.

This chapter discusses the following topics:

- ❖ [Setting Up and Using Protocol Analyzer](#)
- ❖ [Debug port](#)

7.1 Setting Up and Using Protocol Analyzer

Synopsys provides Protocol Analyzer (PA) to help you debug designs with svt USB VIP. The purpose of this chapter is to explain how to enable the generation of PA data, and an overview of PA features which support debugging testbenches with USB VIP.

7.1.1 Enabling the SVT USB VIP to Generate Data for Protocol Analyzer

To use Protocol Analyzer to debug USB transactions, you must enable the USB VIP to generate data for the Protocol Analyzer.

7.1.1.1 Environment Variable Setting

The following environment should be set in the terminal before invoking Verdi to enable PA features:

```
setenv DESIGNWARE_HOME <VIP installation path>
setenv TRANSACTION_PROTOCOL_SUPPORT 1
```

7.1.1.2 Compile Time Options

The compile time options are as follows:

```
. -lca
. -kdb // dumps the work.lib++ data for source coding view
. +define+SVT_FSDB_ENABLE // enables FSDB dumping
-debug_access
```

For more information on how to set the FSDB dumping libraries, see Appendix B section in Linking Novas Files with Simulators and Enabling FSDB Dumping guide available at:

`$VERDI_HOME/doc/linking_dumping.pdf`

**Note**

In your UVM environment class, set the following to generate LTSSM state related data for the Protocol Analyzer:

```
Cfg. enable_link_pa_gen = 4;
```

7.1.1.3 Run Time Options

You can dump the transaction database by passing the runtime switch as following:

Runtime Switch

```
+svt_enable_pa=fsdb
```

7.1.2 Using Native Protocol Analyzer for Debugging

This feature enables you to invoke Protocol Analyzer from Verdi GUI. Synchronize the Verdi wave window, smart log, and the source code with the Protocol Analyzer transaction view. Protocol Analyzer can be enabled in an interactive and post-processing mode. The new features available in Native Protocol Analyzer includes layer based grouping of the transactions, Quick filter, Call stack, Horizontal Zoom, and reverse debug with the interactive support.

7.1.2.1 Invoking Protocol Analyzer

Perform the following steps to invoke Protocol Analyzer in interactive or post-processing mode.

1. Post-processing Mode

Load the transaction dump data and issue the following command to invoke the GUI:

```
verdi -ssf <dump.fsdb> -lib work.lib++
```


2. In Verdi, navigate to Tools > Transaction Debug > Transaction and Protocol Analyzer and select the Protocol Analyzer option in the main window to invoke Protocol Analyzer.

3. Interactive Mode

Issue the following command to invoke Protocol Analyzer in an interactive mode:

```
<simv> -gui=verdi
```

The Protocol Analyzer can be invoked through Verdi. The Protocol Analyzer transaction view gets updated during the simulation.

Figure 7-1 Sample Protocol Analyzer View

7.1.2.2 Limitations

Interactive support is available only for VCS.



VERDI+PA Documentation is available in
`$VERDI_HOME/doc/Verdi_Transaction_and_Protocol_Debug.pdf`


7.1.3 Performance Analyzer

The performance analyzer tool is used to calculate the performance of sub-systems. The Performance Analyzer uses the transaction data recorded inside the FSDB which is generated for Protocol Analyzer debug.

The performance analyzer is part of Verdi and will be available for Verdi users only.

To invoke : Tools -> Transaction Debug -> Performance Analyzer

Figure 7-2 Sample Performance Analyzer View



7.2 Debug port

Synopsys provides debug port support to help you debug designs with svt USB VIP. Debug port is a special interface which map values of few VIP internal variable at runtime. This section explains how to enable debug port and its usage.

7.2.1 Enabling Debug Port

To enable debug port in your UVM environment class, set the following:

```
Cfg. enable_debug_ports=1
```

7.2.2 Invoking Debug Port Interface Signals

To access the debug port signals navigate to

```
svt_usb_if > usb_debug_if > svt_usb_<20/ess>_<link/phy>_debug_if
```

Figure 7-3 Debug Port



A

Appendix A: Reporting Problems

This chapter provides you the detailed information regarding reporting your issues to Synopsys. This chapter discusses the following topics:

- ❖ [Introduction](#)
- ❖ [Debug Automation](#)
- ❖ [Enabling and Specifying Debug Automation Features](#)
- ❖ [Debug Automation Outputs](#)
- ❖ [FSDB File Generation](#)
- ❖ [Initial Customer Information](#)
- ❖ [Sending Debug Information to Synopsys](#)
- ❖ [Limitations](#)

A.1 Introduction

This chapter provides an overview for working through and reporting issues encountered in the field. It describes the data you must submit when a problem is initially reported to Synopsys. After a review of the initial information, Synopsys may decide to request adjustments to the information being requested, which is the focus of the next section.

A.2 Debug Automation

Every Synopsys model contains a feature called debug automation. It is enabled through `svt_debug_opts` plusarg. The Debug Automation feature allows you to enable all relevant debug information. The following are critical features of debug automation:

- ❖ Enabled by the use of a command line run-time plusarg.
- ❖ Can be enabled on individual VIP instances or multiple instances using regular expressions.
- ❖ Enables debug or verbose message verbosity:
 - ◆ The timing window for message verbosity modification can be controlled by supplying `start_time` and `end_time`.
- ❖ Enables at one time any, or all, standard debug features of the VIP:
 - ◆ Transaction Trace File generation
 - ◆ Transaction Reporting enabled in the transcript

- ◆ PA database generation enabled
- ◆ Debug Port enabled
- ◆ Optionally, generates a file name `svt_model_out.fsdb` when Verdi libraries are available

When the Debug feature is enabled, then all VIP instances that are enabled for debug will have their messages routed to a file named `svt_debug.transcript`.

A.3 Enabling and Specifying Debug Automation Features

Debug Automation is enabled through the use of a run-time plusarg named `+svt_debug_opts`. This plusarg accepts an optional string-based specification to control various aspects Debug Automation. If this command control specification is not supplied, then the feature by default gets enabled on all VIP instances with the default options listed as follows:

The following plusargs are:

- ❖ The command control string is a comma separated string that is split into the multiple fields.
- ❖ All fields are optional and can be supplied in any order.
The command control string uses the following format (white space is disallowed):
`inst:<inst>,type:<string>,feature:<string>,start_time:<longint>,end_time:<longint>,<,>,verbosity:<string>`



Note

The following table explains the control string.

Table A-1 Control Strings for Debug Automation Plusarg

Field	Description
inst	Identifies the VIP instance to apply the debug automation features. Regular expressions can be used to identify multiple VIP instances. If this value is not supplied, and if a type value is not supplied, then the debug automation feature will be enabled on all VIP instances.
type	Identifies a class type to apply the debug automation features. When this value is supplied then debug automation will be enabled for all instances of this class type.
feature	Identifies a sub-feature that can be defined by VIP designers to identify smaller grouping of functionality that is specific to that title. The definition and implementation of this field is left to VIP designers, and by default it has no effect on the debug automation feature. (Specific to VIP titles)
start_time	Identifies when the debug verbosity settings will be applied. The time must be supplied in terms of the timescale that the VIP is compiled. If this value is not supplied, then the verbosity settings will be applied at time zero.
end_time	Identifies when the debug verbosity settings will be removed. The time must be supplied in terms of the timescale that the VIP is compiled. If this value is not supplied, then the debug verbosity remains in effect until the end of the simulation.

Table A-1 Control Strings for Debug Automation Plusarg

verbosity	Message verbosity setting that is applied at the <code>start_time</code> . Two values are accepted in all methodologies: <code>DEBUG</code> and <code>VERBOSE</code> . UVM and OVM users can also supply the verbosity that is native to their respective methodologies (<code>UVM_HIGH/UVM_FULL</code> and <code>OVF_HIGH/OVF_FULL</code>). If this value is not supplied then the verbosity defaults to <code>DEBUG/UVM_HIGH/OVF_HIGH</code> . When this feature is enabled, then all VIP instances that are enabled for debug will have their messages routed to a file named <code>svt_debug.transcript</code> .
-----------	--

For example,

Enable on all VIP instances with default options:

```
+svt_debug_opts
```

Enable on all instances:

- ❖ containing the string endpoint with a verbosity of `UVM_HIGH`
- ❖ starting at time zero (default) until the end of the simulation (default):

```
+svt_debug_opts=inst:/*.*endpoint.*/,verbosity:UVM_HIGH
```

Enable on all instances:

- ❖ starting at time 1000 until time 1500:

```
+svt_debug_opts=start_time:1000,end_time:1500,verbosity:VERBOSE
```

Enable debug feature on all instances using default options:

- ❖ By setting the macro `SVT_DEBUG_OPTS` to 1 in the command line, the debug feature is enabled on all instances using default options. The macro will enable the FSDBs and Trace files.

```
gmake <testname> SVT_DEBUG_OPTS=1 PA=FSDB
```

The `SVT_DEBUG_OPTS` option is available through the installed VIP examples, but if required, in customer environments, then a similar feature should be added to their environment.

**Note**

The `PA=FSDB` option is available in public examples and is required to enable Verdi libraries, and that when this option is used, then the Debug Opts file will record VIP activity to a file named `svt_model_log.fsdb`.

In addition, the SVT Automated Debug feature will enable waveform generation to an FSDB file, if the Verdi libraries are available. When enabled this feature, it should cause the simulator to dump waveform information only for the VIP interfaces. When this feature is enabled then all VIP instances that have been enabled for debug will have their messages routed to a file named `svt_debug.transcript`.

A.4 Debug Automation Outputs

The Automated Debug feature generates a `svt_debug.out` file. It records important information about the debug feature itself, and data about the environment that the VIPs are operating in. This file records the following information:

- ❖ The compiled timeunit for the SVT package
- ❖ The compiled timeunit for each SVT VIP package
- ❖ Version information for the SVT library

- ❖ Version information for each SVT VIP
- ❖ Every SVT VIP instance, and whether the VIP instance has been enabled for debug
- ❖ For every SVT VIP enabled for debug, a list of configuration properties that have been modified to enable debug will be listed
- ❖ A list of all methodology phases will be recorded, along with the start time for each phase

The following are the output files generated:

- ❖ `svt_debug.out`: It records important information about the debug feature itself, and data about the environment that the VIPs are operating. One file is optionally created when this feature is enabled, depending on if the Verdi libraries are available.
- ❖ `svt_debug.transcript`: Log files generated by the simulation run.
- ❖ `svt_model_log.fsdb`: Contains PA FSDB information (if the VIP supports this), and which contains other recorded activity. The additional information records signal activity associated with the VIP interface, TLM input (through SIPP ports), other TLM output activity, configurations applied to the VIP, and all callback activity (recorded by before and after callback execution).

A.5 FSDB File Generation

To enable FSDB writing capabilities, the simulator compile-time options and environment must be updated to enable this. The steps to enable this are specific to the simulator being used (the {LINUX/LINUX64} label needs to be replaced based on the platform being used). The ability to write to an FSDB file the Verdi dumper libraries are required while compiling the testbench. If these are not supplied then the VIP will not be enabled to generate the `svt_model_log.fsdb` file.

A.5.1 VCS

The following must be added to the compile-time command:

```
-debug_access
```

For more information on how to set the FSDB dumping libraries, see Appendix B section in Linking Novas Files with Simulators and Enabling FSDB Dumping guide available at: [\\$VERDI_HOME/doc/linking_dumping.pdf](#).

A.5.2 Questa

The following must be added to the compile-time command:

```
+define+SVT_FSDB_ENABLE -pli novas_fli.so
```

A.5.3 Incisive

The following must be added to the compile-time command:

```
+define+SVT_FSDB_ENABLE -access +r
```

A.5.4 Creating a Waveform File

For a Verilog or SystemVerilog simulation, generate a VCD waveform file by specifying the following in your top level testbench:

```
initial begin
$dumpvars;
```


end



When the simulation is completed, a VCD file named `verilog.dump` is available in the runtime directory.

A.6 Initial Customer Information

Perform the following steps to contact the Synopsys Support Center:

1. Before you contact technical support, be prepared to provide the following:
 - ◆ A description of the issue under investigation.
 - ◆ A description of your verification environment.

A.6.1 Describing Your Issue

Compose a detailed description of the issue under investigation. Include the simulation time and bus cycle of the failure, as well as any error or warning messages that are part of the failure.

A.6.2 Describing Your Verification Environment

Assemble information about your simulation environment, making sure to include:

- ❖ OS type and version
- ❖ Testbench language (SystemVerilog or Verilog)
- ❖ Simulator and version
- ❖ DUT languages (Verilog)
- ❖ Methodologies (UVM/VMM/OVM/Verilog)

Enable the Debug Opts feature.

For more information, see the Debug Automation on page 75.

A.7 Sending Debug Information to Synopsys

To help you debug testing issues, follow the given instructions to pack all pertinent debug information into one file which you can send to Synopsys (or to other users in your company):

1. Create a description of the issue under investigation. Include the simulation time and bus cycle of the failure, as well as any error or warning messages that are part of the failure.
2. Create a description of your verification environment. Assemble information about your simulation environment, making sure to include:
 - ◆ OS type and version
 - ◆ Testbench language (SystemVerilog or Verilog)
 - ◆ Simulator and version
 - ◆ DUT languages (Verilog)
3. Use the VIP case submittal tool to pack a file with the appropriate debug information. It has the following usage syntax:

```
$DESIGNWARE_HOME/bin/snps_vip_debug [-directory <path>]
```

The tool will generate a <username>.<unqid>.svd file in the current directory. The following files are packed into a single file:

- ◆ FSDB
- ◆ HISTL
- ◆ MISC
- ◆ SLID
- ◆ SVTO
- ◆ SVTX
- ◆ TRACE
- ◆ VCD
- ◆ VPD
- ◆ FSDB

If any one of the above files are present, then the files will be saved in the <username>.<unqid>.svd in the current directory. The simulation transcript file will not be part of this and it will be saved separately.

**Note**

The `-directory` switch can be specified to select an alternate source directory.

4. You will be prompted by the case submittal tool with the option to include additional files within the SVD file. The simulation transcript files cannot be automatically identified and it must be provided during this step.
5. The case submittal tool will display options on how to send the file to Synopsys.

A.8 Limitations

Enabling DEBUG or VERBOSE verbosity is an expensive operation, both in terms of runtime and disk space utilization. The following steps can be used to minimize this cost:

- ❖ Only enable the VIP instance necessary for debug. By default, the `+svt_debug_opts` command enables Debug Opts on all instances, but the 'inst' argument can be used to select a specific instance.
- ❖ Use the `start_time` and `end_time` arguments to limit the verbosity changes to the specific time window that needs to be debugged.