

Contents

Section	Page No.
Introduction	1
EV2050/H Functional Description	1
EV2050/H Contents	2
EV2050/H Connections	2
EV2050/H Configuration	2
Installing the User Interface Program	3
Using the EV2050/H Program	3
Main Menu	3
Monitor Screens	3
Data Logging	6
Program Menu	7
Measure V_{OS} Screen	8
Appendix A: AP50 User's Guide	9
Appendix B: Troubleshooting	10
Appendix C: EV2050/H Schematic	11



Introduction

The bq2050/H Power Gauge IC provides battery capacity monitoring in a single 16-pin SOIC or DIP package. The EV2050/H Evaluation Board provides a useful means to test bq2050/H functionality and easily interface with the device over the RS-232 port of a PC. The bq2050/H features:

- Battery capacity monitoring functions
- LED display of available charge
- DQ serial I/O port communications functions

Functional Description

The EV2050/H provides functional evaluation of the bq2050/H IC on a PCB. The actual implementation of a bq2050/H-based design will be significantly smaller in size. See the bq2050/H data sheet for bq2050/H specifications.

Power Source

The bq2050/H derives its V_{CC} from either an external source or from the battery connected to the BAT+ (J1) and BAT- (J2) terminal blocks. Refer to Table 4 in *Using the bq2010—A Tutorial for Gas Gauging* for the proper size of R17 as part of the V_{CC} regulation. The EV2050/H Evaluation Board is shipped with a 200K Ω resistor for R17.

Current Path

The bq2050/H uses a sense resistor (R16) on the negative terminal of the battery to measure charge and discharge of the battery. This resistor may be changed if necessary. The system load is connected between the BAT+ (J1) and RET- (J2) terminal blocks (see the schematic in Appendix C).

Parameter Programming

The EV2050/H is programmed by the segment programming pins, using jumpers PROG1-PROG5. The programming pins determine:

- Programmed full count
- Scale factor
- Discharge compensation factor

EV2050/H

- Self-discharge compensation (on/off)

EV2050/H Contents

Each package contains the following items:

1 EV2050/H PC Board

This includes the bq2050/H sample, current regulator, programming jumpers, battery divider resistors, and the PC serial port interface.

1 EV2050/H DQ/RS-232 Cable

1 EV2050/H (v2.5) User Interface Program Diskette

This program runs on *any AT-compatible computer* equipped with a standard RS-232 (COM1, COM2, COM3, or COM4) serial port, and provides the user with a complete menu-driven system to control, monitor, and log data from the EV2050/H Evaluation Board. The User Interface Program communicates with the bq2050/H over the DQ serial I/O port using the RS-232 interface.

Please check to make sure that all items are present and in good condition. If you have any problems, please contact your Benchmarq representative or call Benchmarq.

EV2050/H Connections

The connections for the EV2050/H are described below. Please refer to the attached schematic in conjunction with these descriptions.

JP1–JP8 **Battery cell divider.** JP1–JP6 are used to divide the battery voltage by 5 to 10. JP7 and JP8 are user-definable, but are configured for 11 and 12 cells on this board.

JP9 **Vcc supply.** This jumper is used to select the Vcc supply for the bq2050/H. When JP9 is near Q2, the supply is taken from the BAT+ input and is regulated by the bq2050/H and Q2. When JP9 is near R13, the Vcc supply is provided by LBAT+. If Vcc is supplied by LBAT+, it must not exceed the specified Vcc voltage range in the bq2050/H data sheet.

JP10–JP14 **Programming pins 1–5.** These jumpers are used to configure the programming pins. When the jumper is positioned near the PROG# designator, the pins are pulled high. If the jumper is in the other position, the pins are pulled low. If the jumper is removed, the pins are in the high-impedance state. The board is

JP16

shipped with all pins in the high position. Please refer to the bq2050/H data sheet for the proper configuration of PROG₁₋₅.

LED enable (LCOM connection). This jumper connects the LCOM pin of the bq2050/H to the LEDs. The board is shipped with this jumper enabled.

RBI

Register backup input. This pin is used to provide backup potential to the bq2050/H registers during periods when $V_{CC} \leq 3V$. A storage capacitor or a battery can be connected to RBI.

DSP

Display input (\overline{DISP} pin). DSP is connected in parallel with the push-button switch S1 provided on the EV2050/H board. An external switch configuration can be made using DSP. When the EV2050/H is floating and detects charging or discharging, the LED outputs are active to reflect the charge state. When the \overline{DISP} input is pulled low, the LEDs reflect the charge state.

EV2050/H Configuration

The EV2050/H Evaluation Board may be used with or without the DQ/RS-232 Interface Program. The Evaluation Board should first be configured before connecting the battery or the RS-232 cable.

Step 1 Enabling the LEDs (optional)

JP16 should be installed.

Step 2 Connecting the power supply

The EV2050/H can operate from power provided by the battery being monitored or from LBAT+. Set the battery divider (JP1–JP8) to the correct number of battery cells prior to connecting the battery. If the bq2050/H will be powered from the battery, connect JP9 closer to Q2. If the bq2050/H will be powered from an external supply, connect JP9 closer to R13. **Important: Connect the battery ONLY after setting JP1–JP8 and JP9.**

Step 3 Connecting the RS-232 cable

Connect the cable provided to the serial port of any PC. Please ensure no memory-resident programs use this serial port.

Step 4 Connecting the load

The external load is connected between BAT+ and RET- (J2) on the EV2050/H. A

June 1995

sense resistor (R16) is in series with the negative terminal of the battery. The EV2050/H board is supplied with a 0.1, 1% 3W resistor. Please ensure that the discharge load does not exceed the V_{SR} specification for the bq2050/H. R16 may be changed to a different-value resistor.

Installing the User Interface Program

The User Interface Program (named "EV2050/H") runs on any PC-compatible computer. The program may be run from the disk provided, or it may be installed on any directory on the computer's hard disk. To run the program from the hard disk, simply copy all the files from the disk supplied to the hard disk. All the files should reside in the same directory.

The User Interface Program installs a driver to control the DQ/RS-232 interface. This driver asks which COM port is connected to the EV2050/H Evaluation board. If communication is not established with the EV2050/H board, the Main Menu does not appear. Please refer to Appendix B (Troubleshooting) if the program does not establish communication with the EV2050/H.

The EV2050/H uses the PC-AT real-time clock to provide the proper bit timing for serial communication with the bq2050/H. The modem control lines are used as the single-wire serial interface to the bq2050/H. Any TSR that uses the PC real-time clock affects the operation of the EV2050/H. For proper operation, the EV2050/H should not be operated from a DOS shell program.

If the PC is a notebook or portable type, it may be configured to save battery power by adjusting the clocks according to the activity under way. Configure the notebook to run in "High Performance" mode for reliable communication between the EV2050/H and the PC. The EV2050/H UIP terminates if communication with the EV2050/H board is lost.

Start the User Interface Program as follows:

```
C>EV2050/H
```

Using the EV2050/H Program

EV2050/H is a menu-driven program. Almost all of the functions and entries are made by positioning the highlighted cursor on the function desired and pressing the ENTER key, or by typing a value and then pressing the ENTER key.

Key functions are as follows:

ARROW keys Use the arrow keys to move the highlighted cursor around the screen.

ENTER key

Press the ENTER key to select the value currently being displayed for a parameter, or to perform a function selected by the highlighted cursor.

ESCAPE key

Press the ESCAPE key to escape from any function back to the main menu, or to escape from any parameter value screen back to the menu displaying that parameter.

F3 key

Press the F3 key to display a help file for the selected function or parameter.

Main Menu

The Main Menu appears after the EV2050/H program has started. If this menu does not appear, communication with the EV2050/H has not been established; please refer to Appendix B (Troubleshooting) if the EV2050/H does not display the Main Menu.

The Main Menu shows six functions that may be activated; see Figure 1. Use the cursor keys (arrow keys) to position the highlighted cursor over the function to be activated and press the ENTER key. For help, press the F3 key, and a help note about the function appears. Press the ESCAPE key to exit from the EV2050/H program.

The Main Menu functions are as follows:

- <Initialize> Sends a reset command to the bq2050/H.
- <Program> Activates a screen showing the current program settings for the bq2050/H.
- <Monitor mWh> and <Monitor mAh> Activates a screen from which the bq2050/H activity is monitored on a real-time basis. Capacity is indicated in mWh or mAh depending on the screen selected.
- <Data Log> Allows entering a file name to which bq2050/H data will be logged, and the logging period in seconds. When the log is activated, the display changes to the Monitor mAh screen with a bottom display of:
Logging Record: xx
- <Measure V_{OS} > This allows the user to determine the apparent offset voltage of the bq2050/H under test. A minimum of 6 minutes is required to complete the V_{OS} measurement, which has a resolution of $\pm 0.15\text{mV}$ per 6 minutes.

Monitor Screens

The EV2050/H software provides two real-time monitoring screens. One reports available battery capacity in Amp-hours, the other in Watt-hours. See Figures 2 and 3. The

EV2050/H

program continually updates the monitor screen. As conditions change, the new values are displayed.

Time	Time of day in HH:MM:DD, 24-hour notation.
Empty/Full	This indicates the current value for GG in the TMPGG register of the bq2050/H. The capacity value is given in $\frac{1}{16}$ th steps.
Date	Current date in MM/DD/YY notation.
NAC	NAC register values multiplied by the scale value and divided by the sense resistor value to give mAh.
SAE	Scaled available energy expressed in terms of mWh.
LMD	Last Measured Discharge expressed in terms of mAh. This is the 8-bit LMD register value multiplied by the scale value times 256 and divided by the sense resistor to give mAh.
LMDW	Last measured discharge expressed in terms of mWh.
Sense Resistor Value	This is the sense resistor value from the Program Menu.
CAC	Compensated available capacity expressed in terms of mAh. CAC is similar to NAC but compensates for discharge rate and temperature.
Temp Step	This is a display of the active temperature step, which ranges from 0 (for temperatures $< -30^{\circ}\text{C}$) to 12 for temperatures $> 80^{\circ}\text{C}$).

Average V_{SR} Current	This is the average battery current.
Time Remaining	During discharge, this is the time remaining at the average current (NAC / Avg. V_{SR} current).
Activity	This indicates the charging/discharging activity occurring with the battery. CHARGE is displayed if the battery is charging, while DISCHARGING is displayed if the battery is being discharged, or if it is idle (no charging taking place). OVERLOAD is displayed if the discharge rate exceeds 2C. Please note that the appearance of CHARGE or DISCHARGE indicators is rate-dependent, and may take some time after the application of a charging current or a discharge load depending on the PFC and scale selected, and the rate of charge or discharge being applied.
Discharge Rate	This is the value of the V_{SR} discharge rate current step as defined in the bq2050/H data sheet.
GG Step	This is the lower four bits of the TMPGG register that correspond to the current CAC value relative to LMD. The GG step is reported as a step number from 0 to 15, with step 0 representing available capacity from 0 to $\frac{1}{16}$ of full, and 15 representing available capacity from $\frac{15}{16}$ full to full.
First EDV	This is the state of the EDV1 flag as programmed in the Program Menu. The default is 1.52V. The EDV1 flag latches ON if V_{SB} drops below the EDV1 threshold value.

Benchmark bq2050/H Evaluation Board Main Menu (v2.5)	
<Initialize>	<Monitor mAh>
<Program>	<Data Log>
<Monitor mWh>	<Measure Vos>
Please Enter SR, Avg. Pack Volts in Program Selection for Proper Operation.	
ESC to exit program	F3 for Help

Figure 1. Main Menu

Modifying NAC and LMD



EV2050/H

It is possible to change the values of the NAC and LMD parameters from the screen using the F1 and F2 function keys as follows.

Changing NAC (F1)

- 1) Press the F1 key. The NAC field is highlighted.
- 2) Enter the value in mAh and press the ENTER key to store the value.

Note: Changing NAC disqualifies a subsequent LMD update.

Changing LMD (F2)

- 1) Press the F2 key. The LMD field is highlighted.
- 2) Enter the value in mAh and press the ENTER key to store the value.

Data Logging

The data log is activated from the Main Menu by selecting the Data Log function. A filename to be used and the log sample period must be entered. For example:

Log Data to Filename: <filename.ext>
Enter Sample Period (10 sec or greater):<xx>
Opening Data Log File

When the data log is started, the Monitor Screen displays the number of the current log record in the lower right-hand corner. To terminate the data log, press the ESCAPE key. The file is closed and data logging is terminated.

The data log record contains fields of ASCII data separated by tab characters. The field names and descriptions in record order are listed below.

TIME Time record written in seconds

Milli-Watt-Hour Capacity Monitor		
Time: 99:99:99	EMPTY **** ____FULL	Date: 99-99-9999
SAE: 99999 mWh	LMDW: 99999 mWh	Sense Resistor Value: XXXXΩ
CAC: 99999 mAh	Temp Step: XX	
Avg Vsr Current: ±9999mA	Time remaining: 9999 min.	
Activity: XXXXX	Vsr Discharge Rate: XX	GG Step: XX
Charge Rate: XXXX	First EDV: XXX	
Valid Discharge: XXX	Final EDV: XXX	Batt. Replaced: XXX
Pack Voltage: XXX V		
Capacity Inaccurate: XXX	Capacity Inaccurate Count: XXX	
FLGS1: X X _ X X _ X X	FLGS2: _ X X X _ _ _ X	
C B N C V N E E	N D D D N N N O	
H R / I D / D D	/ R R R / / / V	
G P U Q U V V	U 2 1 0 U U U L	
S 1 F	D	
ESC to main menu		

Figure 3. Real-Time Monitor Screen (Milli-Watt-Hour)

LMD	LMD value in mAh
NAC	NAC value in mAh
Avg. Discharge Current	Average V _{SR} battery current
PACK V	Pack voltage
CAC	CAC value in mAh
SAE	SAE value in mWh
LMDW	LMDW value in mWh
FLAGS1	Binary setting of FLAGS1 flags:

Bit Meaning

0	EDVF flag state
1	EDV1 flag state
2	Not used
3	VDQ (valid discharge)
4	Capacity inaccurate
5	Not used
6	Battery replaced flag state
7	Charge active flag state

FLAGS2	Binary setting of FLAGS2 flags:
--------	---------------------------------

Bit Meaning

0	Overload flag state
1–3	Not used
4–6	Discharge rate
7	Not used

The log records should be readable by most spreadsheet programs.

Program Menu

This menu is accessed by selecting the <Program> function on the Main Menu. The programming menu allows the user to set and observe the program state of the bq2050/H; see Figure 4. To change the bq2050/H PFC programming, reconfigure jumpers JP10–JP14 and initialize the bq2050/H. The reset allows the bq2050/H to read the program pins.

Sense Resistor Press F1 to enter the value of sense resistor in ohms. Typical values range from 0.02 to 0.1Ω.

The sense resistor value is used by the EV2050/H UIP to develop meaningful in-

Benchmark bq2050/H Programming

Sense Resistor:	0.1 Ω	Scale Factor:	1/160
Display Mode:	RELATIVE	PFC Count:	XXXXX
		PFC (mVH):	XXXX
Self-Discharge Rate:	1/512C/day	Battery Capacity	9999 mAh
Battery Type:	X	1 = Graphite 2 = Coke	
End of Dschg:	X.XX		
Avg Pack V:	X.XX		
Divider Ratio:	X		
Programming Pin Configuration			
Prog-1 H	Prog-4 L		
Prog-2 Z	Prog-5 L		
Prog-3 Z	Prog-6 Z		

Figure 4. Program Menu

EV2050/H

	formation in terms of A, mA, mAh, and mWh in relation to battery capacity and current. The default value is 0.1. Values from 0.005 to 0.256 are saved in the battery ID RAM byte of the bq2050/H. Values greater than 0.256 must be re-entered each time EV2050/H is started.		value slightly lower than (within 5%) the rated battery capacity is recommended.
		Self-Discharge Rate	Set at $\frac{1}{512}$ C per day for lithium-ion.
Scale Factor	Select the scale factor from the available scales using JP12. Like the sense resistor, the scale factor is used to develop meaningful information for the programmed full count tables, battery full, and available capacity indications.	Battery Type	Select coke or graphite anode with J14.
		End of Dschg	Press F3 to enter the desired end of discharge voltage for the battery pack. The default value is 1.52V for the bq2050/H.
		Avg Pack V	Press F4 to enter the average pack voltage.
Display Mode	The RELATIVE display mode uses the last measured discharge capacity of the battery as the battery-full reference.	Divider Ratio	Press F5 to adjust the reported pack voltage scaled per the equation in the bq2050/H data sheet.
PFC Count	Program full count from Table 2 from the bq2050/H data sheet.	Programming Pin Configuration	This displays indicates the programming of the bq2050/H by displaying H, Z, or L depending on the state of the program pins. Please refer to the bq2050/H data sheet for further details.
PFC (mVH)	Select the programmed full count using JP10 and JP11. Note that the selected PFC and the sense resistor value are used to determine the initial battery full capacity (mAh) represented by the PFC.		
Battery Capacity	This display indicates the battery capacity represented by dividing the PFC by the sense resistor. In practice, picking a PFC and sense resistor that provide a battery full		

Measure Vos Screen

This screen is used to measure the Vos of the bq2050/H; see Figure 5. A minimum of 360 seconds is required to perform this test. Pressing the ESC key terminates the test in progress. Operating the test for a longer period

Benchmark EV2050/H Evaluation Board V_{OS} Measurement

Present DMF Setting -XXXmV=Vsrd +XXXmV=Vsrg

Current Threshold (DMF(mv)/Rsns): XXXXmA

Do you want to test Vos?: Y/N

Calculated Vos: Vos XXXmV, over last xxxx seconds

Elapsed time: XXXX seconds

****Note:** There must be no charge/discharge activity on the bq2050/H for this test to be valid. Running the test for a longer period of time increases the Vos measurement resolution. This test requires a minimum of 6 minutes before any value is displayed.

Figure 5. VOS Measurement Screen

increases the resolution of the test. A "beep" signals test completion.

Appendix A: AP50A User's Guide

The AP50 utility (AP50A.EXE) is used to communicate with the bq2050/H on a register basis. AP50 uses a driver to communicate with the EV2050/H over serial port on a PC-AT personal computer.

AP50

The AP50 utility is started by executing AP50A.EXE. After AP50 is started, the following prompt is displayed:

Select COM Port < 1 2 3 4 >

Commands

The user can respond with various commands at the prompt. Pressing "Q" causes the program to terminate.

-> ?

Pressing the ? key displays following menu:

The following commands are available:	
?	This display is shown.
A	Send break.
Q	Quit and return to DOS.
R##	Read at Address ##.
S##	Scan at Address ##.
W##=**	Write at Address ## value **.

These commands may be used to send or receive data from the EV2050/H.

-> A

If A is entered in response to ->, then a break bit is sent to the EV2050/H. This may be used to restart the communication if a problem appears. If the prompt does not return immediately, then proper communication has not been established; please refer to Appendix B for troubleshooting procedures.

-> R##

If R## is entered in response to ->, where ## is an applicable address in HEX format, AP50 returns the value at that location from the EV2050/H. The addresses are defined in the bq2050/H data sheet. For example:

-> R03

causes the display to show:

R03= ##

where ## is the current NAC value in HEX format.

Address 00 is used to read and display all readable registers.

-> S##

If S## is entered in response to ->, where ## is a valid bq2050/H address in HEX format, AP50 continuously reads and displays the value at that location. The addresses are defined in the bq2050/H data sheet. For example:

-> S03

causes the display to show:

Address 3 = ## after XXX.XX sec.

where ## is the value at location 03 and XXX.XX is the number of seconds between changes in this value. Press ESC to return to the prompt.

-> W##=**

If W##=** is entered in response to ->, where ## is an applicable address in HEX format and ** is the value to be written, AP50 writes the value to that location. The addresses are defined in the bq2050/H data sheet. For example:

-> W05 = A0


causes the program to write A0 in location 05hex (LMD register).

Appendix B: Troubleshooting

If the EV2050/H Main Menu does not appear after starting EV2050/H, then communication to the bq2050/H has not been established. Please check the following:

1. Confirm the proper serial port is being used.
2. Confirm the battery divider is properly set for the number of cells in the battery pack.
3. Confirm JP9 is properly set for either an external supply through LBAT+ (J1) or the microregulator. JP9 closer to Q2 enables the microregulator, while JP9 closer to R13 enables LBAT+. If the battery divider on JP9 is not set properly, the bq2050/H will not operate, and the EV2050/H UIP or AP50 will not work.
4. Confirm the battery is attached between BAT+ and BAT- (J1 and J2).
5. Push S1. SEG1 LED should be on indicating that the bq2050/H is properly powered.
6. If the LED is not on, check the battery voltage on pin 16 of the bq2050/H to determine if it is above 3V but below 6.5V.
7. If the LED is on, and the EV2050/H Main Menu still does not appear, try using AP50 to establish communication. Appendix A describes AP50.
8. If communication cannot be established using AP50, the problem is either the RS-232 port in the PC or the EV2050/H interface section. Please contact Benchmarq if the interface section is not working properly on the EV2050/H board.

Appendix C: EV2050/H Schematic



IMPORTANT NOTICE

Texas Instruments and its subsidiaries (TI) reserve the right to make changes to their products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgement, including those pertaining to warranty, patent infringement, and limitation of liability.

TI warrants performance of its semiconductor products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are utilized to the extent TI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

CERTAIN APPLICATIONS USING SEMICONDUCTOR PRODUCTS MAY INVOLVE POTENTIAL RISKS OF DEATH, PERSONAL INJURY, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE ("CRITICAL APPLICATIONS"). TI SEMICONDUCTOR PRODUCTS ARE NOT DESIGNED, AUTHORIZED, OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT DEVICES OR SYSTEMS OR OTHER CRITICAL APPLICATIONS. INCLUSION OF TI PRODUCTS IN SUCH APPLICATIONS IS UNDERSTOOD TO BE FULLY AT THE CUSTOMER'S RISK.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards.

TI assumes no liability for applications assistance or customer product design. TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of TI covering or relating to any combination, machine, or process in which such semiconductor products or services might be or are used. TI's publication of information regarding any third party's products or services does not constitute TI's approval, warranty or endorsement thereof.