

Using the Logitech wireless game controller:

Connecting USB receiver to laptop:

Make sure the Logitech USB receiver is plugged in

You can just plug it straight into the laptop, or you can use the receiver's extender cable, and put the receiver somewhere where reception will be good

Switching the controller on:

Switch the controller on by pressing the "Logitech" button (in the middle of the controller)

The "Mode" light may start flashing if the controller hasn't been used in a while. This is ok and doesn't mean anything is wrong.

Switching the controller off:

There is no "switch off" button

The controller automatically switches off after it hasn't been used for a few minutes

Controller modes:

There are 2 modes:

Digital mode: indicated by "Mode" light being dark

Analog mode: indicated by "Mode" light being lit up

The controller mode dictates whether you control games using the left 4-way pad, or the left joystick, or both. Using the joystick gives you finer control over movement than you get if you use the 4-way pad and is better for some games, whereas some games are better controlled with the 4-way pad. Try each mode and see which you prefer.

Unfortunately, different games have different ways of interpreting this mode so you may have to switch controller mode to get the controller working as you like for any particular game.

If you try to move in a game using either the left 4-way pad or the left joystick, and nothing happens, try switching controller mode and try to move again.

Switching controller mode:

Press the "Mode" button on the controller

The "Mode" light should toggle on/off

If the "Mode" light starts flashing on and off, that means it cannot communicate with the receiver and something is wrong. Try changing the batteries

Setting the controller's controller type:

This is done by moving a sliding switch at the front of the controller

There are two settings: X and D

The switch should ALWAYS be set to X