


1. Double click on the register to which assign the variable



2. Click on add variable

Select Variable for Pin:1

×

Scope: Global

OK

Cancel

Select Variable: NONE

Add Variable

Help

### 3. Enter variable name

Select Variable for Pin:1

Scope: Global

OK

Cancel

Select Variable: Channel no

Edit Variable

Help

Variable Name: Channel no

Address: %IW0

Variable Type: VAR\_INPUT


Initial Value:

Data Type: UINT

Retention: NO

Description:

#### 4. After adding register.



Note : 1. In Per Input variable if we put 1000 in initial value then this block will generate Maximum Output across the channel.