


## PIDT :

1. Double click on the block to configure PIDT.



If DI\_0 is pressed then PIDT block will start Auto tuning. In the auto tuning mode Tune Status (TS) will be high till PIDT block will not complete its tuning function.

## 2. Assign the below variables.

×

### Assign Variables

☒ **INPUT PIN**

SENSOR ERROR	NONE	...
PROCESS VALUE	NONE	
SET POINT	NONE	
PB(0.1C)	NONE	
INTEGRAL(SEC)	NONE	
DERIVATIVE(SEC)	NONE	
CYCLE TIME(0.1S)	NONE	
DAC(0.5-5.0)	NONE	
ARW(2.0-100.0%)	NONE	

☒ **OUTPUT PIN**

OUTPUT(0.1%)	NONE

☒ **SENSOR ERROR**

NONE

OK

Cancel

### 3. After assigning the variables

×

Assign Variables

<b>INPUT PIN</b>	
SENSOR ERROR	GVar20
PROCESS VALUE	GVar21
SET POINT	GVar22
PB(0.1C)	GVar23
INTEGRAL(SEC)	GVar24
DERIVATIVE(SEC)	GVar25
CYCLE TIME(0.1S)	GVar26
DAC(0.5-5.0)	GVar27
ARW(2.0-100.0%)	GVar28
<b>OUTPUT PIN</b>	
OUTPUT(0.1%)	GVar29 <span style="float: right;">...</span>

**OUTPUT(0.1%)**  
 NONE

OK
Cancel

Note : from PB keep retention to all variable Yes.

**EXIT**