


1. Double click on the register to which assign the variable



2. Click on add variable

Select Variable for Pin:1

×

Scope: Global

Select Variable: NONE

OK

Cancel

Add Variable


Help

3. Enter variable name

Scope:	Global	OK	Cancel
Select Variable:	NONE	Add Variable	Help


Variable Name:	Value 1	Address:	%IB2
Variable Type:	VAR_INPUT	Initial Value:	45
Data Type:	SINT		
Retention:	NO		
Description:			

4. After adding register.



Note : Base value should be greater than 0.

Example :



Calculation :

Initial Value	Calculation	Result
IN1_VAL=45	Output=45/6	OUT=3
IN2_VAL=6		
OUT=0		