

Congratulations on your purchase of the Beurer Style Pro Cordless Hair Straightener, HS20! This user manual will guide you on how to effectively and safely use your cordless hair straightener for achieving sleek and stylish hair. Please read this manual carefully before using the product.

Product Overview: The Beurer Style Pro Cordless Hair Straightener, HS20, is a versatile and convenient hair styling tool designed to give you professional-looking straight hair on the go. This cordless straightener offers freedom of movement without the need for a power cord, making it perfect for traveling or touch-ups anytime, anywhere. With its advanced heating technology and adjustable temperature settings, you can achieve desired results while protecting your hair from damage.

Important Safety Precautions:

1. Read all instructions before using the hair straightener and keep them for future reference.
2. This hair straightener is for household use only. Do not use it in a bathroom or near water sources.
3. Unplug the straightener when not in use and before cleaning.
4. Do not immerse the straightener in water or any other liquids.
5. Do not use the straightener if the cord or plug is damaged.
6. Do not use the straightener with an extension cord.
7. Keep the straightener away from heat sources and flammable materials.
8. Use the straightener on dry hair only. Do not use it on wet or damp hair.
9. Do not touch the heating plates with bare skin during or immediately after use, as they may be hot and cause burns.
10. Keep the straightener out of reach of children and pets.

Charging the Hair Straightener:

1. Before first use, ensure the hair straightener is fully charged.
2. Connect the charging cable to the charging port on the straightener and plug the other end into a suitable power source.
3. The LED indicator will show the charging progress. A solid light indicates that the straightener is charging, and a blinking light indicates a low battery.
4. Once fully charged, disconnect the charging cable from the straightener.

Usage Instructions:

1. Power On and Temperature Selection:
 - Press and hold the power button to turn on the straightener.
 - The LED indicator will light up, indicating that the straightener is powered on.
 - Use the temperature buttons to adjust the desired heat setting. The LED display will show the selected temperature.
 - Choose a lower temperature for fine or delicate hair and a higher temperature for thick or coarse hair.
2. Straightening Process:
 - Ensure your hair is clean, dry, and free of tangles or knots.
 - Divide your hair into sections for easier styling.
 - Take a small section of hair and place it between the heating plates of the straightener.
 - Gently clamp the straightener on the hair section, close to the roots.
 - Slowly glide the straightener down the hair shaft, from the roots to the ends, maintaining a steady and even pressure.
 - Repeat this process for each hair section until you achieve the desired straightness.

3. Auto Shut-Off:

- The straightener is equipped with an auto shut-off feature for safety and energy conservation.
- If the straightener remains inactive for a certain period, it will automatically shut off.
- To reactivate the straightener, press the power button again.

4. Cool Down and Storage:

- After use, turn off the straightener by pressing and holding the power button until the LED indicator turns off.
- Allow the straightener to cool down completely before storing it.
- Store the straightener in a cool, dry place, away from direct sunlight and heat sources.