

## REPLACEMENT


### 1. REMOVE FRONT WHEELS

### 2. REMOVE FRONT FENDER LINER LH


### 3. REMOVE HEIGHT CONTROL DRYER ASSY

(a) Disconnect the connector.

(b) Disconnect the air tube (see page 25-1).




(c) Remove the 3 bolts, nut and height control compressor assy and height control dryer assy.




(d) Remove the bolt and height control dryer assy.

(e) Remove the O-ring.



### 4. REMOVE HEIGHT CONTROL COMPRESSOR ASSY

(a) Remove the 3 bolts, bushing and bracket from height control compressor assy.




### 5. INSTALL HEIGHT CONTROL COMPRESSOR ASSY

(a) Install the bracket and bushing with 3 bolts to height control compressor assy.


**Torque: 5.9 N·m (60 kgf·cm, 52 in·lbf)**

### 6. INSTALL HEIGHT CONTROL DRYER ASSY

(a) Coat the O-ring with MP grease and install it to height control dryer assy.



- (b) Install the height control dryer assembly with 1 bolt.  
**Torque: 6.4 N·m (65 kgf·cm, 56 in.·lbf)**



- (c) Install the height control compressor and height control dryer assembly with 3 bolts and 1 nut.  
**Torque: 19 N·m (195 kgf·cm, 14 ft·lbf)**  
 (d) Connect the air tube (see page 25-1).  
 (e) Connect the connector.

7. INSTALL FRONT FENDER LINER LH

8. INSTALL FRONT WHEELS

**Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)**

9. INSPECT AIR LEAK (SEE PAGE 25-4)