


LUGGAGE COMPARTMENT DOOR CLOSER MOTOR CIRCUIT

CIRCUIT DESCRIPTION

Open and close operations of the luggage door is monitored and the signals are sent to the luggage room J/B ECU. The luggage compartment door closer motor is built into the luggage door lock assembly.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST USING INTELLIGENT TESTER

- (a) Select the ACTIVE TEST, use the Intelligent Tester II to generate a control command, and then check the luggage compartment door opener motor.

Luggage room J/B ECU:

Item	Test Detail	Diagnostic Note
Trunk Lid Open	Operate luggage compartment door motor OFF/ON	-

OK: Luggage compartment door is opened.

NG

Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2782)

2 INSPECT FUSE (FUEL OPN)

- (a) Remove the FUEL OPN fuse from the luggage room J/B ECU.
(b) Measure the resistance.


Standard: Below 1 Ω

NG

REPLACE FUSE

OK

3 INSPECT LUGGAGE DOOR CLOSER ASSY (OPENER MOTOR)



- (a) Apply battery voltage to the luggage compartment door opener motor.

OK:

Measurement Condition	Specified Condition
Battery positive (+) → Terminal 2 Battery negative (-) → Terminal 6	Motor shaft rotates clockwise
Battery positive (+) → Terminal 6 Battery negative (-) → Terminal 2	Motor shaft rotates counterclockwise

NG

REPLACE LUGGAGE DOOR CLOSER ASSY


OK

4


CHECK WIRE HARNESS (LUGGAGE DOOR CLOSER MOTOR - LUGGAGE ROOM J/B ECU)

Wire Harness Side

L4
Luggage Compartment
Door Closer Assy



L14
Luggage Room J/B ECU



Y B78394

- (a) Disconnect the L11 ECU connector.
- (b) Disconnect the L4 door closer connector.
- (c) Measure the resistance between the wire harness side connector.

Standard:

Tester Connection	Specified Condition
L4-2 (M+) - L11-8 (LCM+)	Below 1 Ω
L4-6 (M-) - L11-1 (LCM-)	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CON-
NECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2782)