



## INSPECTION

### 1. INSPECT WATER PUMP

- (a) Visually check the air hole and water hole for coolant leakage.

If leakage is found, replace the water pump and timing belt.

- (b) Turn the pulley, and check that the water pump bearing moves smoothly and quietly.

If necessary, replace the water pump.

### 2. INSPECT TIMING BELT COMPONENTS

(See page [EM-24](#))