

## CUSTOMIZE PARAMETERS

### HINT:

The following items can be customized.

### NOTICE:

- When the customer requests a change in a function, first make sure that customization of the function(s) is possible.
- Be sure to record the current setting before customizing.
- When troubleshooting a function, first make sure that the function is not set to OFF.

#### Theft warning:

Display (Item)	Default	Contents	Setting
P-ON D-OP BUZ/P (Push-on door-open buzzer/p)	ON	Function that makes warning available when smart key is taken outside vehicle, D-door is opened, shift position is P and ignition switch is ACC or ON (engine is not running)	ON/OFF
DOR OP-CL BUZ/P (Door open-close buzzer/p)	ON	Function that makes warning available when smart key is taken outside vehicle, any door is opened and closed, shift position is P and ignition switch is ACC or ON	ON/OFF
BUZZER LENGTH (buzzer length)	2s	Function that makes warning available when smart key is taken outside vehicle, all doors are closed, trigger switch is on, shift position is P, ignition switch is ACC or ON	2s/ 1s/ 0s/ OFF
P-ON D-OP BUZ (Push-on door-open buzzer)	ON	Function that makes warning available when smart key is taken outside vehicle, any door (except D-door) is opened and closed, shift position is not P, ignition switch is ACC or ON	ON/OFF
DOR OP-CL BUZ (Door open-close buzzer)	ON	Function that makes warning available when smart key is taken outside vehicle, any door (except D-door) is opened and closed, shift position is not P and ignition switch is ACC or ON	ON/OFF
HALF LOCK BUZ (Half lock buzzer)	ON	Function that makes warning available for locking doors with smart key when doors are opened	ON/OFF
KEY IN LOCK BUZ (key inside lock buzzer)	2s	Function that makes warning available when doors are locked by trigger switch with smart key left inside vehicle	2s/ 1s/ 0s/ OFF
KEY BATTERY BUZ (Key battery buzzer)	ON	Function that makes warning available when smart key battery is low	ON/OFF
KEY NO FIT BUZ (Key no fit buzzer)	OFF	Function that makes warning available when smart key cannot be identified	ON/OFF
SMART BUZ NUM (Smart buzzer number)	3TIMES	Function that sets number of times that wireless buzzer, which warns ignition switch is still ON, beeps	10TIMES/ 7TIMES/ 5TIMES/ 3TIMES/ 0TIMES
SMART BUZ BOL (Smart buzzer volume)	MAX	Function that sets sound volume of wireless buzzer, which warns ignition switch is still ON	MAX/MID 3/MID 2/MID 1/MID/ OFF
KEY TAKE OUT BUZ (Key take out buzzer)	OFF	Function that sets buzzer beep intervals, which beeps when key is inside vehicle	300S/ 60S/30S/ 10S/ 5S/ 3S/ OFF
E-ON D-OP BUZ/P (Engine-on door-open buzzer)	OFF	Function that makes warning available when smart key is taken outside vehicle, D-door is opened and closed, shift position is P and ignition switch is ACC or ON	ON/OFF