

POOR SOUND QUALITY IN ALL MODES (LOW VOLUME)

INSPECTION PROCEDURE

1 CHECK AUDIO SETTINGS

- (a) Set "BASS", "MID" and "TREB" to the initial value and check if sound is normal.  
OK: Return to normal.

OK END

NG

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE  
(SEE PAGE 05-1660)