

<b>DTC</b>	<b>P2716</b>	<b>PRESSURE CONTROL SOLENOID "D" ELECTRICAL (SHIFT SOLENOID SLT)</b>
------------	--------------	--

## CIRCUIT DESCRIPTION


See page 05-627.

DTC No.	DTC Detection Condition	Trouble Area
P2716	Condition (a) or (b) below is detected 1 sec. or more: (1-trip detection logic) (a) SLT- terminal: 0V (b) SLT- terminal: 12V	<ul style="list-style-type: none"> <li>• Open or short in shift solenoid valve SLT circuit</li> <li>• Shift solenoid valve SLT</li> <li>• ECM</li> </ul>

## MONITOR DESCRIPTION


When an open or short in the linear solenoid valve (SLT) circuit is detected, the ECM interprets this as a fault. The ECM will turn ON the MIL and store the DTC.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 INSPECT TRANSMISSION WIRE (SLT)



- (a) Disconnect the transmission wire connector from the transaxle.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition 20°C (68°F)
13 (SLT+) – 5 (SLT-)	5.0 to 5.6 Ω

- (c) Measure the resistance according to the value(s) in the table below.

**Standard (Check for short):**


Tester Connection	Specified Condition
13 (SLT+) – Body ground	10 kΩ or higher
5 (SLT-) – Body ground	↑

NG

Go to step 3

OK

## 2 CHECK HARNESS AND CONNECTOR (TRANSMISSION WIRE – ECM)



- (a) Connect the transmission wire connector to the transaxle.
- (b) Disconnect the ECM connector.
- (c) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition 20°C (68°F)
E7 – 5 (SLT+) – E7 – 34 (SLT-)	5.0 to 5.6 Ω

- (d) Measure the resistance according to the value(s) in the table below.

**Standard (Check for short):**

Tester Connection	Specified Condition
E7 – 5 (SLT+) – Body ground	10 kΩ or higher
E7 – 34 (SLT-) – Body ground	↑

NG


REPAIR OR REPLACE HARNESS OR  
CONNECTOR (SEE PAGE 01-44)

OK

REPLACE ECM (SEE PAGE 10-21)

3 INSPECT SHIFT SOLENOID VALVE (SLT)

Shift Solenoid Valve (SLT):



P

G20767

- (a) Remove the shift solenoid valve (SLT).  
(b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition 20°C (68°F)
1 - 2	5.0 to 5.6 Ω

- (c) Connect the positive (+) lead with a 21 W bulb to terminal 2 and the negative (-) lead to terminal 1 of the solenoid valve connector, then check the movement of the valve.

OK:

The solenoid makes an operating noise.

NG

REPLACE SHIFT SOLENOID VALVE (SLT)

OK

REPAIR OR REPLACE TRANSMISSION WIRE (SEE PAGE 40-28)