


STEERING SENSOR COMMUNICATION STOP MODE

MODE DESCRIPTION


Detection Item	Symptom	Trouble Area
STEERING SENSOR COMMUNICATION STOP MODE	<ul style="list-style-type: none">• "Steering Angle Sensor" is not displayed on the Communication Bus Check screen of the Intelligent Tester.• Applies to "STEERING SENSOR COMMUNICATION STOP MODE" in the DTC COMBINATION TABLE (see page 5-3309).	<ul style="list-style-type: none">• Power source or inside the steering sensor• Steering sensor sub bus line or connector

WIRING DIAGRAM




RHD:

D-CAN J/C



G30880


INSPECTION PROCEDURE

1 CHECK CAN BUS LINE FOR DISCONNECTION(STEERING SENSOR SUB BUS LINE)
**Steering Sensor
Wire Harness View:**


- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the steering sensor connector (S18).
- (c) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified value
S18-10 (CANH) – S18-9 (CANL)	Ignition Switch OFF	54 to 69 Ω

NG
**REPAIR OR REPLACE STEERING SENSOR
SUB BUS LINE OR CONNECTOR
(CAN-H, CAN-L)**
OK
2 CHECK WIRE HARNESS(IG1, ESS)
**Steering Sensor
Wire Harness View:**


- (a) Measure the resistance according to the value(s) in the table below.
- (b) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
S18-2 (ESS) – Body ground	Always	Below 1 Ω
S18-1 (IG1) – Body ground	Ignition Switch ON	10 to 14 V

NG
**REPAIR OR REPLACE WIRE HARNESS OR
CONNECTOR**
OK
REPLACE STEERING SENSOR (SEE PAGE 32-65)