


DTC

B1424

SOLAR SENSOR CIRCUIT (DRIVER SIDE)

CIRCUIT DESCRIPTION




A photodiode in the A/C solar sensor detects solar radiation and sends signals to the A/C amplifier.

| DTC No. | Detection Item                                     | Trouble Area   |
|---------|--|--|
| B1424   | Solar sensor circuit (Driver side) (Open or short) | <ul style="list-style-type: none"><li>• A/C solar sensor</li><li>• Harness or connector between A/C solar sensor and A/C amplifier</li><li>• A/C amplifier</li></ul> |

HINT:  
If DTC B1244 is output at the same time, troubleshoot DTC B1244 first (see page 05-1405).

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE ON INTELLIGENT TESTER

- (a) Connect the Intelligent Tester II to the DLC3.
- (b) Turn the Ignition switch to the ON position and push the Intelligent Tester II main switch on.
- (c) Select the item below in the DATA LIST, and read the display on the Intelligent Tester II.

DATA LIST / AIR CONDITIONER:

| Item   | Measure Item/Display (Range)                    | Normal Condition                                   | Diagnostic Note |
|--|---|--|-----------------|
| Solar Sensor (Driver Side)<br>(Solar Sens-D) | Solar Sensor (Driver Side)<br>min.: 0 max.: 255 | Increases as brightness increases<br>(Driver Side) | -               |

OK:  
The display is as specified in the normal condition.

Result:

|  |   |
|--|---|
| NG   | A |
| OK (Checking from the PROBLEM SYMPTOM TABLE) | B |
| OK (Checking from the DTC)                   | C |

B


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE  
(SEE PAGE 05-778)

C

REPLACE AIR CONDITIONING AMPLIFIER  
(SEE PAGE 55-16)

A

2 INSPECT AIR CONDITIONING AMPLIFIER (TSDr)



- (a) Remove the A/C amplifier with connector still connected.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

| Tester Connection           | Condition                             | Specified Condition |
|-----------------------------|---------------------------------------|---------------------|
| A14-19 (TSDr) - Body Ground | Sensor is subjected to electric light | 4.0 to 4.6 V        |
| A14-19 (TSDr) - Body Ground | Sensor is covered by a cloth          | Below 0.8 V         |

HINT:

- As the inspection light is moved away from the sensor, the voltage increases.
- Use an incandescent lamp for inspection. Bring it within 30 cm (11.8 in.) of the A/C solar sensor.

Result:

|  |   |
|--|---|
| NG   | A |
| OK<br>(Checking from the PROBLEM SYMPTOMS TABLE) | B |
| OK (Checking from the DTC)                       | C |

B

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-778)

C


REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 05-10)

A

### 3 INSPECT A/C SOLAR SENSOR

#### A/C Solar Sensor Connector

##### Front View:



- Remove the A/C solar sensor.
- Apply battery voltage between terminals A31-6 (CLTB) and A31-3 (CLTE) of the A/C solar sensor.
- Measure the voltage according to the value(s) in the table below.

#### Standard:

| Tester connection                | Condition                             | Specified condition |
|----------------------------------|---------------------------------------|---------------------|
| A31-1 (TSL) -<br>A31-3 (CLTE) *1 | Sensor is subjected to electric light | 4.0 to 4.6 V        |
| A31-1 (TSL) -<br>A31-3 (CLTE) *1 | Sensor is covered by a cloth          | Below 0.8 V         |
| A31-2 (TSR) -<br>A31-3 (CLTE) *2 | Sensor is subjected to electric light | 4.0 to 4.6 V        |
| A31-2 (TSR) -<br>A31-3 (CLTE) *2 | Sensor is covered by a cloth          | Below 0.8 V         |

#### HINT:

\*1: LHD

\*2: RHD

#### NOTICE:

The connection procedure for using a digital tester such as a TOYOTA electrical tester is shown above. When using an analog tester, connect the positive (+) lead to terminal 2 and negative (-) lead to terminal 1 of the solar sensor.

#### HINT:


- As the inspection light is moved away from the sensor, the voltage increases.
- Use an incandescent lamp for inspection. Bring it within 30 cm (11.8 in.) of the solar sensor.

NG

REPLACE A/C SOLAR SENSOR

OK

4. CHECK HARNESS AND CONNECTOR (A/C SOLAR SENSOR - AIR CONDITIONING AMPLIFIER) (SEE PAGE 01-44)



(a) Measure the resistance according to the value(s) in the table below.

Standard:

| Tester Connection              | Condition | Specified Condition |
|--------------------------------|-----------|---------------------|
| A14-19 (TSDr) - A31-1 (TSL) *1 | Always    | Below 1 Ω           |
| A14-19 (TSDr) - A31-2 (TSR) *2 | Always    | Below 1 Ω           |
| A14-19 (TSDr) - Body Ground    | Always    | 10 kΩ or higher     |

HINT:

\*1: LHD

\*2: RHD

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)