

## INSTALLATION

### 1. INSTALL REAR ACCELERATION SENSOR

Install the rear acceleration sensor with the bolt.

**Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)**

### 2. CONNECT CONNECTOR

### 3. INSTALL REAR LUGGAGE COMPARTMENT TRIM SIDE COVER, FRONT LUGGAGE TRIM COVER AND REAR FLOOR FINISH PANEL (See page BO-64)