


TERMINALS OF ECU

1. CHECK TRANSPONDER KEY ECU ASSY



- (a) Disconnect the T9 ECU connector.
 (b) Measure the voltage and resistance between each terminal of the wire harness side connector.

Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
CPUB (T9-1) – GND (T9-14)	V-Y – W-B	Battery	Constant	10 to 14 V
GND (T9-14) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω
KSW (T9-3) – GND (T9-14)	LG-B – W-B	Unlock warning switch	1: No key in ignition key cylinder → 2: Key inserted	1: 10 k Ω or higher → 2: Below 1 Ω

If the result is not as specified, there may be a malfunction on the wire harness side.


- (c) Reconnect the T9 ECU connector.
 (d) Measure the voltage between each terminal of the connector.

Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
KSW (T9-3) – GND (T9-14)	LG-B – W-B	Unlock warning switch	1: No key in ignition key cylinder → 2: Key inserted	1: 10 to 14 V → 2: 0 V

If the result is not as specified, the ECU may have a malfunction.

2. CHECK STEERING LOCK ECU



F46206

- (a) Disconnect the S46 ECU connector.
- (b) Measure the voltage and resistance of each terminal of the wire harness side connector.

Standard:

Terminal No. (Symbols)	Wiring color	Terminal description	Condition	Specified value
CPUB (S46-1) – Body ground	V-Y – Body ground	+B (CPUB) Power supply	Constant	10 to 14 V
+B (S46-10) – Body ground	R-L – Body ground	+B (+B) Power supply	Constant	10 to 14 V
KSW (S46-12) – Body ground	LG-B – Body ground	Unlock warning switch input	1: No key in starter switch → 2: Key inserted	1: 10 kΩ or higher → 2: Below 1 Ω
PUSH (S46-11) – Body ground	P-B – Body ground	Push switch input	1: No key in starter switch → 2: Key inserted	1: 10 kΩ or higher → 2: Below 1 Ω
GND (S46-9) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω

If the result is not as specified, there may be a malfunction on the wire harness side.


- (c) Reconnect the S46 ECU connector.
- (d) Measure the voltage between each terminal of the connector.

Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
KSW (S46-12) – GND (S46-9)	LG-B – W-B	Unlock warning switch	1: No key in ignition cylinder → 2: Key inserted	1: 10 to 14 V → 2: 0 V
PUSH (S46-11) – GND (S46-9)	P-B – W-B	Push switch input	1: No key in ignition cylinder → 2: Key inserted	1: 10 to 14 V → 2: 0 V

If the result is not as specified, the ECU may have a malfunction.

3. CHECK DRIVER DOOR ECU



- Disconnect the D25 ECU connector.
- Measure the voltage and resistance of each terminal of the wire harness side connector.

Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
CPUB (D25-4) – Body ground	V-Y – Body ground	+B (CPUB) power supply	Constant	10 to 14 V
SIG (D25-5) – Body ground	R-L – Body ground	+B (SIG) power supply	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 10 to 14 V
BDR (D25-6) – Body ground	R – Body ground	+B (BDR) power supply	Constant	10 to 14 V
GND (D25-1) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω
CTY (D25-15) – Body ground	P-G – Body ground	Driver door courtesy switch input	Driver door 1: CLOSED → 2: OPEN	1: 10 kΩ or higher → 2: Below 1 Ω

If the result is not as specified, there may be a malfunction on the wire harness side.