



INSPECTION

INSPECT HAZARD SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
OFF	-	No continuity
ON	1 - 2	Continuity
Illumination circuit	8 - 9	Continuity

If continuity is not as specified, replace the switch.