


## ACTUATOR POWER SOURCE CIRCUIT



### CIRCUIT DESCRIPTION

This circuit is the power source for the motors.

The ECU boosts this electric power to approximately 200 V alternating current, and then supplies it to the motors.

### WIRING DIAGRAM




**INSPECTION PROCEDURE****1 INSPECT FUSE(TI & TE)****Driver Side J/B (LHD):****Driver Side J/B (RHD):**

F46421

- (a) Remove the TI & TE fuse from the driver side J/B.
- (b) Check the continuity of the TI & TE fuse.

**Standard: Continuity****NG****INSPECT FOR SHORT IN ALL COMPONENTS  
CONNECTED TO FUSE AND REPAIR OR REPLACE  
THEM IF NEEDED, AND REPLACE FUSE****OK**

## 2 CHECK HARNESS AND CONNECTOR (MULTIPLEX TILT & TELESCOPIC ECU - BATTERY)



- Disconnect the P8 connector from the multiplex tilt & telescopic ECU.
- Measure the voltage according to the value(s) in the table below.

### Standard:


Tester Connection	Condition	Specified Condition
P8-4(+B) - Body Ground	Always	11 to 14 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

## 3 CHECK HARNESS AND CONNECTOR (MULTIPLEX TILT & TELESCOPIC ECU - BODY GROUND)



- Disconnect the P7 connector from the multiplex tilt & telescopic ECU.
- Measure the resistance according to the value(s) in the table below.

### Standard:

Tester Connection (Terminal No.)	Condition	Specified Condition
P7-6(GND) - Body Ground	Always	Below 1 $\Omega$

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTIONS SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-694)