


ABS WARNING LIGHT CIRCUIT (REMAINS ON)

CIRCUIT DESCRIPTION

During DTC read by SST (Check Wire), if the ABS warning light remains on, trouble shoot by following this inspection flow.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK DTC

(a) Is DTC output for ABS, CAN and/or MPX?

OK:

DTC is not output	A
DTC is output	B

B

REPAIR CIRCUIT INDICATED BY OUTPUT CODE

A

2 INSPECT SKID CONTROL ECU CONNECTOR (SEE PAGE 32-53)

(a) Check the ECU connector's connecting condition.

OK:

The connector is securely connected.

NG

CONNECT CONNECTOR TO ECU CORRECTLY

OK

3 INSPECT BATTERY

(a) Check the battery voltage.

Standard:

Voltage: 10 to 14 V

NG

INSPECT CHARGING SYSTEM
(SEE PAGE 19-23)

OK

4 INSPECT SKID CONTROL ECU TERMINAL VOLTAGE (IG1 TERMINAL)

- (a) Connect the intelligent tester to the DLC3.
 (b) Start the engine.
 (c) Select the DATA LIST mode on the intelligent tester.

Item	Measurement Item Range (Display)	Normal Condition
ECU IG Power Voltage	ECU power supply voltage UNDER NORMAL OVER	OVER: 14 V or over NORMAL: 9.5 V to 14 V UNDER: Below 9.5 V

- (d) Read the voltage condition output from the ECU displayed on the intelligent tester.

OK:

"Normal" is displayed.


NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

5 CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU - BODY GROUND)

Skid Control ECU
 (harness side connector) S48



- (a) Disconnect the skid control ECU connector.
 (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
S48-32 (GND) - Body ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE ABS & TRACTION ACTUATOR ASSY (SEE PAGE 32-53)

NOTICE:

When replacing ABS & TRACTION ACTUATOR assy, perform zero point calibration (see page 05-387).