

<b>DTC</b>	<b>P0607</b>	<b>INPUT SIGNAL CIRCUIT MALFUNCTION</b>
------------	--------------	---

## CIRCUIT DESCRIPTION

This DTC indicates a malfunction in the ECM.

HINT:

The ECM receives signals from each sensor to control all the functions of the cruise control with the micro-computer.

When a malfunction is detected, fail-safe remains on until the ignition switch is turned off.

DTC No.	Detection Item	Trouble Area
P0607	The ECM has a supervisory CPU and a control ECU inside. When each input STP signal is different for 0.15 sec. or more, this trouble code is output. This trouble code is output after 0.4 sec. has passed from the time the cruise cancel input signal (STP input) is input into the ECM.	•ECM

## INSPECTION PROCEDURE

1	REPLACE ECM (SEE PAGE 10-21)
---	------------------------------