

## POWER SOURCE CIRCUIT

### CIRCUIT DESCRIPTION


This circuit supplies power to the seat belt control ECU.

When the ignition switch is turned ON, the D-IG1 relay turns ON and power is supplied to the driver side J/B ECU. Power is then supplied from the driver side J/B ECU to the luggage room J/B ECU, which then turns ON the L-IG1 relay to supply power to the seat belt control ECU.

#### HINT:

There may be a malfunction in the power source circuit if either: 1) neither DTCs nor "normal system" codes are output but the pre-crash safety system is not functioning normally; or 2) DTCs are not output and a "normal system" code is output, but the pre-crash safety system is not functioning normally.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 INSPECT FUSE (LUG J/B, RR IG, S/ROOF)

- Remove the LUG J/B H-fuse from the FL block.
- Remove the RR IG and S/ROOF fuses from the luggage room J/B.
- Measure the resistance of the fuses.

**Standard: Below 1  $\Omega$**

NG

**REPLACE FUSE**


OK

### 2 CHECK WIRE HARNESS (SEAT BELT CONTROL ECU – BATTERY)

#### Wire Harness Side

S65

Seat Belt Control ECU



Y

I44437

- Turn the ignition switch OFF.
- Disconnect the cable from the negative (–) battery terminal.
- Disconnect the S65 ECU connector.
- Connect the cable to the negative (–) battery terminal.
- Measure the voltage of the wire harness side connector.

**Standard:**

Tester Connection	Condition	Specified Condition
S65–3 (IG1) – Body ground	Ignition switch ON	10 to 14 V
S65–9 (+B) – Body ground	Always	10 to 14 V

NG

**Go to step 4**


OK

### 3 CHECK WIRE HARNESS (SEAT BELT CONTROL ECU – BODY GROUND)

#### Wire Harness Side

S65

Seat Belt Control ECU



Y

I44437

- Turn the ignition switch OFF.
- Disconnect the cable from the negative (–) battery terminal.
- Measure the resistance of the wire harness side connector.

**Standard:**


Tester Connection	Specified Condition
S65–18 (PGND) – Body ground	Below 1 $\Omega$

NG

**REPAIR OR REPLACE HARNESS AND CONNECTOR**

OK

**REPLACE SEAT BELT CONTROL ECU (See page 61–1)**

**4 INSPECT RELAY (Marking: L-IG1)**


- (a) Remove the L-IG1 relay from the luggage room J/B.  
 (b) Measure the resistance of the relay.

**Standard:**


Tester Connection	Specified Condition
3 – 5	10 k $\Omega$ or higher
3 – 5	Below 1 $\Omega$ (when battery voltage is applied to terminals 1 and 2)

**NG****REPLACE RELAY****OK****5 CHECK WIRE HARNESS (LUGGAGE ROOM J/B ASSY– SEAT BELT CONTROL ECU, BATTERY AND BODY GROUND)****Wire Harness Side****LA**


Luggage Room J/B Assy

**LC**

Luggage Room J/B Assy

**LE**


Luggage Room J/B Assy

**LL**

Luggage Room J/B Assy

**S65**

Seat Belt Control ECU

**IG1****+B**

- (a) Turn the ignition switch OFF.  
 (b) Disconnect the cable from the negative (–) battery terminal.  
 (c) Disconnect the LE, LC, LL, LF and LA J/B connectors.  
 (d) Disconnect the S65 ECU connector.  
 (e) Connect the cable to the negative (–) battery terminal.  
 (f) Measure the voltage and resistance of the wire harness side connectors.

**Standard:**

Tester Connection	Specified Condition
LE-18 – S65-3 (IG1)	Below 1 $\Omega$
LB-12 – S65-9 (+B)	Below 1 $\Omega$
LB-10 – LC-8	Below 1 $\Omega$
LL-1 – Body ground	10 to 14 V
LA-5 – Body ground	Below 1 $\Omega$

**NG****REPAIR OR REPLACE HARNESS AND CONNECTOR****OK****REPLACE LUGGAGE ROOM JUNCTION BLOCK ASSY**

