

PRE-CRASH SAFETY SYSTEM

PRECAUTION

NOTICE:

When disconnecting the cable from the negative (–) battery terminal, initialize the following systems after the cable is reconnected.

System	See Page
Front Power Seat Control System	01-19
Back Guide Monitor System	01-19

CAUTION:

Wait at least 90 seconds after disconnecting the cable from the negative (–) battery terminal to prevent airbag and seat belt pretensioner activation.

1. TROUBLESHOOTING PRECAUTIONS

- (a) If a terminal contact point malfunction or part installation problem occurs, removal and reinstallation of the suspected part may return the system to normal. However, be aware that the normal condition may only be temporary.
- (b) Before disconnecting connectors or removing/installing parts, determine the malfunctioning area by checking and writing down the vehicle's condition at the time of the malfunction (DTC outputs, etc.).
- (c) Be sure to check for DTCs related to other systems. The pre-crash safety system may be influenced by malfunctions in other system.

2. HANDLING PRECAUTIONS

- (a) When removing and installing ECU, sensor, switch or other pre-crash safety system related part, perform the following:
 - After the removal/installation, check for DTCs and confirm that a normal system code is output.