

## PROBLEM SYMPTOMS TABLE

Symptoms	Suspected Area	See Page
Power window does not operate at all	1. Power source circuit on driver side 2. Power window master switch circuit 3. Driver door ECU	<a href="#">05-2022</a> <a href="#">05-2033</a> <a href="#">05-1987</a>
Driver side power window does not operate	1. Power source circuit on driver side 2. Power window motor circuit (driver) 3. Power window master switch circuit 4. Driver door ECU	<a href="#">05-2022</a> <a href="#">05-2046</a> <a href="#">05-2033</a> <a href="#">05-1987</a>
Passenger side power window does not operate	1. Power source circuit on passenger side 2. Power window motor circuit (passenger) 3. Power window regulator switch circuit 4. Passenger door ECU	<a href="#">05-2024</a> <a href="#">05-2049</a> <a href="#">05-2037</a> <a href="#">05-1987</a>
Rear LH power window does not operate	1. Power source circuit on rear LH side 2. Power window motor circuit (rear) 3. Power window regulator switch circuit 4. Rear door LH ECU	<a href="#">05-2027</a> <a href="#">05-2052</a> <a href="#">05-2040</a> <a href="#">05-1987</a>
Rear RH power window does not operate	1. Power source circuit on rear RH side 2. Power window motor circuit (rear) 3. Power window regulator switch circuit 4. Rear door RH ECU	<a href="#">05-2030</a> <a href="#">05-2055</a> <a href="#">05-2043</a> <a href="#">05-1987</a>
Jam protection function and AUTO UP/DOWN function do not operate on driver side	1. Master switch circuit 2. Limit switch circuit 3. Pulse sensor circuit	<a href="#">05-2033</a> <a href="#">05-2008</a> <a href="#">05-2008</a>
Jam protection function and AUTO UP/DOWN function do not operate on passenger side	1. Regulator switch circuit 2. Limit switch circuit 3. Pulse sensor circuit	<a href="#">05-2037</a> <a href="#">05-2012</a> <a href="#">05-2012</a>
Jam protection function and AUTO UP/DOWN function do not operate on rear LH side	1. Regulator switch circuit 2. Limit switch circuit 3. Pulse sensor circuit	<a href="#">05-2040</a> <a href="#">05-2016</a> <a href="#">05-2016</a>
Jam protection function and AUTO UP/DOWN function do not operate on rear RH side	1. Regulator switch circuit 2. Limit switch circuit 3. Pulse sensor circuit	<a href="#">05-2043</a> <a href="#">05-2019</a> <a href="#">05-2019</a>
Window lock function does not operate	1. Power window master switch circuit 2. Window lock switch circuit 3. Power window regulator switch circuit 4. Driver door ECU 5. Passenger door ECU 6. Rear door LH ECU 7. Rear door RH ECU	<a href="#">05-2033</a> <a href="#">05-2058</a> <a href="#">05-2037</a> <a href="#">05-1987</a> <a href="#">05-1987</a> <a href="#">05-1987</a> <a href="#">05-1987</a>
Window control function does not operate	1. Power window master switch circuit 2. Window lock switch circuit 3. Power window motor circuit (passenger) 4. Power window motor circuit (rear) 5. Driver door ECU 6. Passenger door ECU 7. Rear door LH ECU 8. Rear door RH ECU	<a href="#">05-2033</a> <a href="#">05-2058</a> <a href="#">05-2049</a> <a href="#">05-2052</a> <a href="#">05-1987</a> <a href="#">05-1987</a> <a href="#">05-1987</a> <a href="#">05-1987</a>
Transmitter cannot open power windows	1. Transmitter 2. Door control receiver 3. Theft deterrent ECU	<a href="#">05-2852</a> <a href="#">05-2852</a> <a href="#">05-3074</a>

Door key linked power window operation does not function	1. Door key lock and unlock warning switch 2. Door lock control system 3. Driver door ECU	<a href="#">05-2529</a> <a href="#">05-2529</a> <a href="#">05-1987</a>
Key-off operation does not function	1. Power window master switch circuit 2. Power window regulator motor circuit  3. Door courtesy switch circuit 4. Driver door ECU 5. Passenger door ECU 6. Rear door LH ECU 7. Rear door RH ECU	<a href="#">05-2033</a> <a href="#">05-2046</a> <a href="#">05-2049</a> <a href="#">05-2052</a> <a href="#">05-2055</a> <a href="#">05-2529</a> <a href="#">05-2551</a> <a href="#">05-2553</a> <a href="#">05-2556</a> <a href="#">05-2560</a>