

# WATER VALVE

AC00Y-01

## ON-VEHICLE INSPECTION

### 1. WARM UP ENGINE

### 2. DISCONNECT WATER VALVE CONTROL CABLE

### 3. INSPECT WATER VALVE OPERATION

(a) Check that warm air is blown out of the vent when the water valve lever is moved to "warm" position.

(b) Check that cool air is blown out of the vent when the water valve lever is moved to "cool" position.

### 4. CONNECT WATER VALVE CONTROL CABLE

After connection, adjust the control cable ([See page AC-73](#)).