


DTC	B1244	LIGHT SENSOR CIRCUIT MALFUNCTION
-----	-------	----------------------------------

CIRCUIT DESCRIPTION

This DTC is output when failure in the light sensor circuit is detected.

DTC No.	DTC Detecting Condition	Trouble Area
B1244	<ul style="list-style-type: none">• Malfunction in light control sensor• Open or short in automatic light control sensor circuit	<ul style="list-style-type: none">• Automatic light control sensor• Wire harness or connector• Driver side junction block ECU


WIRING DIAGRAM



INSPECTION PROCEDURE

1

CHECK HARNESS AND CONNECTOR(AUTOMATIC LIGHT CONTROL SENSOR POWER SOURCE CIRCUIT)



- (a) Disconnect the automatic light control sensor connector.
- (b) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A31-3 - A31-6	Ignition switch ON	10 to 14 V

NG


Go to step 4

OK

2 CHECK HARNESS AND CONNECTOR(DRIVER SIDE JUNCTION BLOCK - AUTOMATIC LIGHT CONTROL SENSOR)

Automatic Light Control Sensor

Connector Front View: A31



H


I37546

- (a) Disconnect the D5 connector from the driver side junction block.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A31-5 - D5-13	Always	Below 1 Ω

Driver Side Junction Block
Connector Front View:



P

E70398

HINT:

This illustration is for RHD model. The RHD and LHD models are symmetrical.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

3 REPLACE AUTOMATIC LIGHT CONTROL SENSOR


OK: Returns to normal operation.

NG

REPLACE DRIVER SIDE JUNCTION BLOCK

OK

END

4 CHECK HARNESS AND CONNECTOR(DRIVER SIDE JUNCTION BLOCK – AUTOMATIC LIGHT CONTROL SENSOR)**Automatic Light Control Sensor
Connector Front View: A31**

- (a) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A31-6 – Body ground	Ignition switch ON	10 to 14 V


NG

Go to step 6

OK

5 CHECK HARNESS AND CONNECTOR(DRIVER SIDE JUNCTION BLOCK – AUTOMATIC LIGHT CONTROL SENSOR)

**Automatic Light Control Sensor
Connector Front View: A31**



H


I37546

- (a) Disconnect the D5 connector from the driver side junction block assy.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A31-3 - D5-14	Always	Below 1 Ω

Driver Side Junction Block Connector Front View:



P

E70398

HINT:


This illustration is for RHD model. The RHD and LHD models are symmetrical.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE DRIVER SIDE JUNCTION BLOCK

6 CHECK HARNESS AND CONNECTOR(DRIVER SIDE JUNCTION BLOCK – AUTOMATIC LIGHT CONTROL SENSOR)**Automatic Light Control Sensor
Connector Front View: A31**

H


I37546

- (a) Disconnect the D5 connector from the driver side junction block assy.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A31-6 - D5-2	Always	Below 1 Ω

Driver Side Junction Block Connector Front View:



P

E70398

HINT:

This illustration is for RHD model. The RHD and LHD models are symmetrical.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE DRIVER SIDE JUNCTION BLOCK