


REPLACEMENT

HINT:

- Use the same procedures for the parking brake cable assy No.2 and No.3.
- The procedures listed below are for the parking brake cable assy No.3.

1. REMOVE REAR WHEEL




2. SEPARATE REAR DISC BRAKE CALIPER ASSY LH

- (a) Remove the 2 bolts and separate the rear disc brake caliper assy LH.

HINT:

- Do not disconnect the flexible hose from the rear disc brake caliper assy LH.
 - Do not twist or bend the rear brake caliper assy LH.
- (b) Hang the rear brake caliper assy LH with a piece of wire.




3. REMOVE REAR DISC

- (a) Place matchmarks on the disc and rear axle hub.
- (b) Remove the disc.


HINT:

If the disc cannot be removed easily, turn the shoe adjuster until the wheel turns smoothly.




4. REMOVE PARKING BRAKE SHOE RETURN TENSION SPRING

- (a) Using SST, remove the brake shoe return tension spring.
SST 09703-30010




5. REMOVE PARKING BRAKE SHOE ASSY LH NO.1


- (a) Using SST, remove the cap, shoe hold-down spring and pin.
SST 09718-00010
- (b) Disconnect the tension spring from the parking brake shoe assy LH No.1.
- (c) Remove the parking brake shoe assy LH No.1 and shoe adjuster.

**6. REMOVE PARKING BRAKE SHOE ASSY LH NO.2**

- (a) Remove the tension spring from the lower shoe.
- (b) Using SST, remove the cap, shoe hold-down spring and pin.
SST 09718-00010
- (c) Remove the parking brake shoe assy LH No.2.


**7. REMOVE PARKING BRAKE SHOE LEVER SUB-ASSY LH**

- (a) Disconnect the parking brake cable assy No.3 from the parking brake shoe lever.

8. REMOVE OXYGEN SENSOR (SEE PAGE 15-4)**9. REMOVE EXHAUST PIPE ASSY (SEE PAGE 15-4)****10. REMOVE FRONT FLOOR HEAT INSULATOR NO.1 (SEE PAGE 15-4)****11. REMOVE PARKING BRAKE CABLE ASSY NO.3**

- (a) Remove the 2 nuts and parking brake cable assy No.3 from the rear axle carrier.

- (b) Remove the 3 bolts and separate the parking brake cable assy No.3.
- (c) Remove the parking brake cable No.3 from the parking brake intermediate lever sub-assy.
- (d) Remove the 2 bolts and parking brake cable No.1 clamp from the body.
- (e) Remove the parking brake cable No.2 clamp and No.3 clamp from the parking brake cable assy No.3.
- (f) Remove the parking brake cable No.5 clamp and anchor block.



12. INSTALL PARKING BRAKE CABLE ASSY NO.3


- (a) Install the parking brake cable No.5 clamp and anchor block.
- (b) Install the parking brake cable No.2 clamp and No.3 clamp to the parking brake cable assy No.3.
- (c) Place the parking brake cable No.1 clamp to the body and tighten the 2 bolts.
Torque: 6 N·m (61 kgf·cm, 53 in·lbf)
- (d) Attach the parking brake cable assy No.3 to the parking brake intermediate lever sub-assy.

- (e) Attach the parking brake cable assy No.3 to the 2 clamps and tighten bolts A, B and C.

Torque:


Bolt A: 6 N·m (61 kgf·cm, 53 in·lbf)

Bolt B, C: 19 N·m (194 kgf·cm, 14 ft·lbf)




- (f) Install parking brake cable assy No.3 to the rear axle carrier with the 2 nuts.

Torque: 8 N·m (81 kgf·cm, 70 in·lbf)




13. INSTALL PARKING BRAKE SHOE LEVER SUB-ASSY LH

- (a) Apply high temperature grease to the parking brake shoe lever LH.
- (b) Install parking brake shoe lever to the parking brake cable assy No.3.




NOTICE:

Carefully distinguish the RH and LH on the parking brake shoe lever.




14. INSTALL PARKING BRAKE SHOE ASSY LH NO.1

- (a) Install the parking brake shoe assy LH No.1 with a pin, shoe hold-down spring and the cap.

**15. INSTALL PARKING BRAKE SHOE ASSY LH NO.2**


- (a) Apply high temperature grease to the shoe adjuster.
- (b) Place the parking brake shoe assy LH No.2 and shoe adjuster.
- (c) Connect the tension spring.
- (d) Install the pin, shoe hold-down spring and the cap.


**16. INSTALL PARKING BRAKE SHOE RETURN TENSION SPRING**

- (a) Using SST, install the brake shoe return tension spring.
SST 09703-30010


17. CHECK PARKING BRAKE INSTALLATION

- (a) Make sure that all the parts are installed properly.
If not, reinstall the parts properly.




**18. INSTALL REAR DISC**

- (a) Align the matchmarks on the disc and rear axle hub.

**19. ADJUST PARKING BRAKE SHOE CLEARANCE**

- (a) Remove the hole plug.
 (b) Turn the shoe adjuster and expand the shoes until the disc locks.
 (c) Return the shoe adjuster 7 notches.
 (d) Install the hole plug.

**20. INSTALL REAR DISC BRAKE CALIPER ASSY LH**

- (a) Temporarily tighten the brake caliper with the 2 new bolts.

NOTICE:

- Brake caliper bolts can not be reused.
- Do not twist the brake hose.
- Make sure that no damage and no foreign matter is attached on the bolts.

- (b) Pulling the brake caliper towards the outer side of the vehicle and tighten bolt A first then bolt B.

Torque: 78 N·m (800 kgf·cm, 58 ft·lbf)

NOTICE:

Do not over tighten the bolts.

21. INSTALL REAR WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

22. INSTALL FRONT FLOOR HEAT INSULATOR NO.1 (SEE PAGE 15-4)**23. INSTALL EXHAUST PIPE ASSY (SEE PAGE 15-4)****24. INSTALL OXYGEN SENSOR (SEE PAGE 15-4)****25. SETTLING PARKING BRAKE SHOES AND DISC**

- (a) Drive the vehicle at approximately 50 km/h (31 mph) on a safe, level and dry road.
 (b) Depress the parking brake pedal with a force of 150 N (15 kgf·cm, 34 lbf).
 (c) Drive the vehicle for approximately 400 meters (0.25 mile) in this condition.
 (d) Repeat this procedure 2 or 3 times.

26. CHECK PARKING BRAKE PEDAL TRAVEL ([SEE PAGE 33-3](#))
27. ADJUST PARKING BRAKE PEDAL TRAVEL ([SEE PAGE 33-3](#))