

INSTALLATION

Installation is in the reverse order of removal (See [page BO-121](#)).

HINT:

After installing the sliding roof, sliding roof need to be re-initialized.