



DISASSEMBLY

1. REMOVE SUSPENSION SUPPORT AND COIL SPRING

- (a) Using 2 SST, compress the coil spring until there is a clearance on both ends.

SST 09727-30021

NOTICE:

Do not use an impact wrench. It will damage the SST.

HINT:

- Set the 2 SST crosswise taking care not to interfere each other's arms.
 - When compressing the coil spring, tighten the 2 SST alternately so that the spring is compressed uniformly.
- (b) Remove suspension support center nut and rebound stopper.
- (c) Remove the suspension support and coil spring with insulator.

2. REMOVE INSULATOR FROM COIL SPRING