

INITIALIZATION

1. INITIALIZE FRONT POWER SEAT CONTROL SYSTEM

- (a) The power seat ECU must be initialized under any of the following conditions.
 - The battery is disconnected.
 - The D/C cut fuse is replaced.
 - The power seat switch (power seat ECU) is replaced.
 - The power seat assy is removed from the vehicle.
- (b) Initialize the power seat ECU as follows.
 - (1) Using the seat switches, fully slide the seat forward, fully recline the seatback forward, and fully raise the seat cushion and headrest.
 - (2) Using the seat switches, fully slide the seat rearward, fully recline the seatback rearward, and fully lower the seat cushion and headrest.