



AMBIENT TEMPERATURE SENSOR INSPECTION

AC3CZ-01

1. **REMOVE AMBIENT TEMPERATURE SENSOR**
 - (a) Disconnect the connector.
 - (b) Pull out the sensor.
2. **INSPECT AMBIENT TEMPERATURE SENSOR CIRCUIT (See page DI-1778)**
3. **INSTALL AMBIENT TEMPERATURE SENSOR**