

DTC C1223/43 ABS CONTROL SYSTEM MALFUNCTION

HINT:

- This DTC is output when the VSC system detects a malfunction in the ABS system.
- When DTC C1223/43 is memorized, there is no malfunction in the skid control ECU.

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1223/43	Malfunction in ABS control system	ABS control system

INSPECTION PROCEDURE

1 CHECK DTC (FOR ABS SYSTEM)

- Clear the DTC (see page 05-400).
- Turn the ignition switch to the ON position.
- Check that the same DTC is recorded (see page 05-400).

OK:

The same DTC is recorded.

NG

PROCEED TO NEXT CIRCUIT INSPECTION
SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-395)

HINT:

It is suspected that the DTCs output was caused by the poor connection of the connector terminal.

OK

REPAIR CIRCUIT INDICATED BY OUTPUT DTC