


## INSTALLATION

### NOTICE:

- Never use SRS parts from another vehicle. When replacing parts, replace them with new parts.
- Never reuse the airbag sensor assembly involved in a collision when the airbag has deployed.
- Never repair a sensor in order to reuse it.

### HINT:

For step 2 to 14, refer to page BO-143.



### 1. INSTALL AIRBAG SENSOR ASSEMBLY

- Install the airbag sensor assembly with the 3 bolts.  
**Torque: 20 N·m (205 kgf·cm, 15 ft·lbf)**
- Install the airbag wire harness to the airbag sensor assembly bracket.
- Connect the airbag sensor connectors.

### NOTICE:

- Connection of the connector is done after the sensor assembly has been installed.
  - Make sure the sensor assembly is installed with the specified torque.
  - If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.
  - When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.
  - After installing, shake the sensor assembly to check that there is no looseness.
- REMOVE CONSOLE BOX
  - REMOVE CLUSTER FINISH PANEL
  - REMOVE CENTER LOWER CLUSTER FINISH PANEL
  - REMOVE CLUSTER FINISH END PANEL
  - REMOVE LOWER CLUSTER FINISH PANEL
  - REMOVE LOWER CENTER FINISH PANEL
  - REMOVE REAR CONSOLE ARMREST
  - REMOVE CLUSTER FINISH PANEL
  - REMOVE NO. 1 SAFETY PAD
  - REMOVE NO. 1 UNDER COVER
  - REMOVE FINISH PANEL ASSEMBLY
  - REMOVE NO. 2 GARNISH
  - REMOVE NO. 2 UNDER COVER