

## INSTALLATION

### 1. INSTALL REAR HEIGHT CONTROL SENSOR

Install the rear height control sensor with the 2 bolts.

**Torque: 7.8 N·m (80 kgf·cm, 69 in·lbf)**

### 2. CONNECT HEIGHT CONTROL SENSOR LINK

(a) Align the matchmarks on the height control sensor link and bracket.

(b) Install the nut and connect the sensor link.

**Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)**

### 3. CONNECT CONNECTOR

### 4. INSTALL REAR WHEEL

**Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)**

### 5. □ CHECK □ VEHICLE □ HEIGHT □ (See page SA-5)