

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Luggage door opener does not operate	1. Luggage opener switch circuit	05-2792
	2. Luggage compartment door opener motor circuit	05-2806
	3. Luggage compartment door key lock and unlock switch circuit	05-2801
	4. Luggage compartment door push switch circuit	05-2795
	5. Driver side J/B	05-2783
	6. Theft deterrent ECU	05-2783
	7. Luggage room J/B	05-2783
Luggage door closer does not operate	1. Door lock switch (luggage) circuit	05-2798
	2. Luggage compartment door closer switch circuit	05-2803
	3. Luggage compartment door courtesy switch circuit	05-2608
	4. Driver side J/B	05-2783
	5. Theft deterrent ECU	05-2783
	6. Luggage room J/B	05-2783