



SOLAR SENSOR INSPECTION

AC3CX-01

1. REMOVE SOLAR SENSOR

Using a screwdriver, pull out the sensor then disconnect the connector.

HINT:

Tape the screwdriver tip before use.

2. Front side:

INSPECT SOLAR SENSOR CIRCUIT

(See page DI-1793, DI-1802)

3. Rear side:

INSPECT SOLAR SENSOR CIRCUIT

(See page DI-1805)

4. INSTALL SOLAR SENSOR