

ON-VEHICLE INSPECTION

1. CHECK FUEL LID OPENER SYSTEM

- (a) Pull the fuel lid opener switch and check that the fuel lid opens.

HINT:

While the theft deterrent system is operating, the fuel lid cannot be opened by switch operation in order to prevent theft.