

## INSTALLATION

Installation is in the reverse order of removal (See page SA-38).

HINT:

After installation, check the front wheel alignment (See page SA-5).