

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
No cool air comes out No warm air comes out	<ol style="list-style-type: none"> 1. Seat climate control fan motor 2. Seat climate controller 3. Air filter 4. Air duct 	05-2491
Climate control system does not operate on driver side	<ol style="list-style-type: none"> 1. Drivers side J/B <ul style="list-style-type: none"> • D S/HTR fuse • D-IG1 relay 2. Seat climate control blower (Climate control ECU) 3. Climate control switch 4. Wire harness 	05-2492
Climate control system does not operate on front passenger side	<ol style="list-style-type: none"> 1. Passenger side J/B <ul style="list-style-type: none"> • P S/HTR fuse • P-IG1 relay 2. Seat climate control blower (Climate control ECU) 3. Climate control switch 4. Wire harness 	05-2496
Climate control system does not operate on rear side	<ol style="list-style-type: none"> 1. Luggage room J/B assy <ul style="list-style-type: none"> • RR S/HTR fuse • L-IG1 relay 2. Seat climate control blower (Climate control ECU) 3. Climate control switch 4. Wire harness 	05-2500