

<b>DTC</b>	<b>P1578</b>	<b>BRAKE SYSTEM MALFUNCTION</b>
------------	--------------	---------------------------------

## CIRCUIT DESCRIPTION

This DTC is output when the VSC system has a problem. Check the VSC system when this DTC is output.

DTC No.	DTC Detection Condition	Trouble Area
P1578	This trouble code is output when the ECM receives the brake system error signal for 0.2 sec. or more while the dynamic laser cruise control is in operation.	• VSC system

## INSPECTION PROCEDURE

### HINT:

This circuit uses CAN for communication. Therefore, if there are any malfunctions in the communication circuit, one or more DTCs in the CAN communication system is/are output.

1	<b>CHECK BRAKE SYSTEM (SEE PAGE 05-381)</b>
---	---