


MICROPHONE CIRCUIT (MULTI-DISPLAY - NAVIGATION ECU)

CIRCUIT DESCRIPTION


This circuit sends a microphone signal from the multi-display to the navigation ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE


1 CHECK HARNESS AND CONNECTOR (MULTI-DISPLAY - NAVIGATION ECU)



- (a) Disconnect the connector from the multi-display M1 navigation ECU N8.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
MCO+ - MIC+	Always	Below 1 Ω
MCO- - MIC-	Always	Below 1 Ω
MCO+ - Body ground	Always	10 kΩ or higher
MCO- - Body ground	Always	10 kΩ or higher
SLD - Body ground	Always	10 kΩ or higher



NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1771)