


STABILIZER BAR REAR REPLACEMENT

270HP-01

1. REMOVE REAR WHEEL




2. REMOVE REAR STABILIZER LINK ASSY LH

- (a) Remove the 2 nuts and stabilizer link assy LH.

3. REMOVE REAR STABILIZER LINK ASSY RH

HINT:

Remove the RH side using the same procedures as for the LH side.



4. INSPECT REAR STABILIZER LINK ASSY LH

- (a) Before installing the nut, flip the ball joint stud back and forth 5 times as shown in the illustration.
- (b) Using a torque wrench, continuously turn the nut 3 to 5 seconds per turn, and take the torque reading on the 5th turn.


Turning torque:

0.05 to 0.98 N·m (0.5 to 10 kgf·cm, 0.4 to 9 in·lbf)

If there is any abnormality, replace the stabilizer link assy LH with a new one.

5. REMOVE STABILIZER BAR REAR


- (a) Remove the 4 bolts and stabilizer bar rear.
- (b) Remove the bracket and bushing.




6. INSTALL STABILIZER BAR REAR

- (a) Install the bushing and bracket.
- (b) Install the stabilizer bar rear with the 4 bolts.

Torque: 18 N·m (180 kgf·cm, 13 ft·lbf)



**7. INSTALL REAR STABILIZER LINK ASSY LH**

- (a) Install the rear stabilizer link assy LH with the 2 nuts.

Torque: 65 N·m (660 kgf·cm, 48 ft·lbf)

8. INSTALL REAR STABILIZER LINK ASSY RH

HINT:

Install the RH side using the same procedures as for the LH side.

9. INSTALL REAR WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)