

# FRONT POWER SEAT CONTROL SYSTEM

05CUS-03

## PRECAUTION

### NOTICE:

When disconnecting the negative (-) battery terminal, initialize the following systems after the terminal is reconnected.

System Name	See Page
Power Window Control System	<a href="#">05-1984</a>
Front Power Seat Control System	<a href="#">05-2280</a>
Back Guide Monitor System	<a href="#">05-1913</a>