


IGNITION SWITCH CIRCUIT

CIRCUIT DESCRIPTION

The driver side junction block receives ACC and ON information from the ignition switch and sends it to each ECU.

WIRING DIAGRAM




INSPECTION PROCEDURE

1 INSPECT DRIVER SIDE JUNCTION BLOCK

(a) Measure the voltage according to the value(s) in the table below.

Standard:

| Tester Connection | Condition | Specified Condition |
|--------------------|------------------------|---------------------|
| DF-4 - Body ground | Ignition switch ON | 10 to 4 V |
| DG-7 - Body ground | Ignition switch in ACC | 10 to 4 V |



HINT:

This illustration is for RHD model. The RHD and LHD models are symmetrical.

NG REPAIR OR REPLACE HARNESS OR CONNECTOR (IGNITION SWITCH CIRCUIT)

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1369)