

## DATA LIST/ACTIVE TEST

### HINT:

By accessing the DATA LIST displayed by the intelligent tester II, you can perform such functions as reading the values of switches and sensors without removing any parts. Reading the DATA LIST is the first step of troubleshooting and is one method to shorten labor time.

- (d) Connect the intelligent tester II to the DLC3.
- (e) Turn the ignition switch to the ON position.
- (f) Following the display on the tester screen, read the "DATA LIST".

### 1. DATA LIST FOR AIRBAG SENSOR ASSY CENTER

Item	Measurement Item/ Range (Display)	Normal Condition	Diagnostic Note
Driver Seat Position	Seat position (Driver side)/ FORWARD: Seat position forward BKWARD: Seat position back FAIL: Failure detected	FORWARD/BKWARD	–
Passenger Detection	Passenger detection/ NG: Indeterminate data NONE: Seat vacant DETECT: Seat occupied FAIL: Failure detected	NG/NONE/DETECT	–
Left side Buckle	Buckle switch (Left side)/ ON: Seat belt fastened OFF: Seat belt not fas- tened NG: Indeterminate data	ON/OFF	–
Right side Buckle	Buckle switch (Right side)/ ON: Seat belt fastened OFF: Seat belt not fas- tened NG: Indeterminate data	ON/OFF	–
Display Type Information	Display type identification information/ LR: Display indicated by LH/RH DP: Display indicated by Driver/Passenger	LR/DP	–
Number of Past DTC	Number of past DTC re- corded/ Min.: 0, Max.: 255	0	–