

<b>DTC</b>	<b>P0500</b>	<b>VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION</b>
------------	--------------	---

<b>DTC</b>	<b>P0503</b>	<b>VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION</b>
------------	--------------	---

## CIRCUIT DESCRIPTION

See [page 05-172](#).

DTC No.	DTC Detection Condition	Trouble Area
P0500	This trouble code is output when the vehicle speed signal from the vehicle speed sensor is cut for 0.14 sec. or more while the cruise control is in operation.	<ul style="list-style-type: none"><li>• Combination meter</li><li>• Vehicle speed sensor</li><li>• Vehicle speed sensor signal circuit</li><li>• ECM</li></ul>
P0503	Momentary interruption and noise are detected when a rapid change of vehicle speed occurs while the cruise control is in operation.	<ul style="list-style-type: none"><li>• Combination meter</li><li>• Vehicle speed sensor</li><li>• Vehicle speed sensor signal circuit</li><li>• ECM</li></ul>

## WIRING DIAGRAM

See [page 05-172](#).

## INSPECTION PROCEDURE

See [page 05-172](#).