

DTC	C1774	POWER SOURCE CIRCUIT
-----	-------	----------------------


CIRCUIT DESCRIPTION


When the ignition switch is turned to the ON position, the D-IG1 relay is activated and battery voltage is applied to terminal B of the suspension control ECU. When the ignition switch is turned off, the D-IG1 relay is de-energized and the power source is cut off.

This power source energizes the suspension control actuator, height control solenoid valve, D-IG1 relay, each IC and sensor.

DTC No.	DTC Detecting Condition	Trouble Area
C1774	IG voltage is detected as being below or above a constant voltage for 0.5 seconds.	<ul style="list-style-type: none"> • Battery • Power source circuit • Suspension control ECU

WIRING DIAGRAM



RHD:

INSPECTION PROCEDURE

1 INSPECT SUSPENSION CONTROL ECU

- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch to the ON position and turn the intelligent tester II main switch on.
- (c) Select the item below in the DATA LIST and read its value displayed on the intelligent tester II.

AIRSUS:

Item	Normal Condition
IG VOLTAGE	Actual ECU power supply voltage: 10 to 14 V

- (d) Check the voltage.


Standard:**10 to 14 V****NG****Go to step 5****OK**

2 CHECK SOURCE VOLTAGE

- (a) Check the battery voltage.

Standard:**11 to 14 V****NG****REPLACE BATTERY****OK**

3 INSPECT FUSE(AM1)


Driver Side J/B:

- (a) Remove the AM1 fuse from the driver side J/B.
- (b) Check fuse.
 - (1) Check continuity of the AM1 fuse.

Standard:**Continuity****NG****CHECK FOR SHORT IN ALL HARNESS AND CONNECTOR CONNECTED TO FUSE AND REPLACE FUSE****OK**

4 INSPECT FUSE (AIR SUS)

Driver Side J/B:



- (a) Remove the AIR SUS fuse from the driver side J/B.
- (b) Check fuse.
 - (1) Check continuity of the AIR SUS fuse.

Standard:
Continuity

NG


CHECK FOR SHORT IN ALL HARNESS AND CONNECTOR CONNECTED TO FUSE AND REPLACE FUSE

OK

REPLACE SUSPENSION CONTROL ECU (SEE PAGE 25-20)

5 INSPECT SUSPENSION CONTROL ECU

Suspension Control ECU:



- (a) Remove the suspension control ECU with connectors connected.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
A24-1 (B) - A24-4 (GND)	10 to 14 V

NG

Go to step 6


OK

REPLACE SUSPENSION CONTROL ECU (SEE PAGE 25-20)

6

CHECK HARNESS AND CONNECTOR (SUSPENSION CONTROL ECU - BODY GROUND) (SEE PAGE 01-44)

Suspension Control ECU:



- (a) Disconnect the suspension control ECU A24 connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
A24-4 (GND) - Body Ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE SUSPENSION CONTROL ECU (SEE PAGE 25-20)