

HEIGHT ADJUSTABLE ANCHOR SWITCH CIRCUIT ON PASSENGER SIDE DOOR


CIRCUIT DESCRIPTION

The passenger door ECU receives the height adjustable anchor switch signal.

WIRING DIAGRAM

S23*1, S22*2

Height Adjustable Anchor Switch
(Passenger Side)




*1: LHD

*2: RHD

INSPECTION PROCEDURE

1 INSPECT HEIGHT ADJUSTABLE ANCHOR SWITCH



(a) Measure the resistance of the switch.


Standard:

| Tester Condition | Switch Position | Specified Condition |
|------------------|-----------------|---------------------|
| 2 - 3 | UP | Below 1 Ω |
| 1 - 3 | UP | 10 kΩ or higher |
| 1 - 3 | DOWN | Below 1 Ω |
| 2 - 3 | DOWN | 10 kΩ or higher |

NG REPLACE HEIGHT ADJUSTABLE ANCHOR SWITCH

OK

2 CHECK WIRE HARNESS (HEIGHT ADJUSTABLE ANCHOR SWITCH - PASSENGER DOOR ECU)



(a) Disconnect F16 ECU connector.

(b) Disconnect S23/S22 switch connector.

(c) Measure the resistance between the wire harness side connector.

Standard:

| Tester Connection | Specified Condition |
|--------------------------------|---------------------|
| F16-3 (PSUP) - S22/S23-2 (UP) | Below 1 Ω |
| F16-14 (PSDN) - S22/S23-1 (DW) | Below 1 Ω |
| F16-26 (PSE) - S22/S23-3 (UL) | Below 1 Ω |

NG REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-1289)