



INSPECTION

INSPECT BALL JOINT FOR ROTATION CONDITION

- (a) Flip the ball joint stud back and forth 5 times before installing the nut.
- (b) Using a torque wrench, turn the stud continuously one turn every 2–4 seconds and take the torque reading on the 5th turn.

Torque (Turning):

0.05 – 1.5 N·m (0.5 – 15 kgf·cm, 0.4 – 13 in.·lbf)